



[Manuals.plus](#) /

> [CLIKBUTM](#) /

> CLIKBUTM Finger Ring Wireless Presenter Instruction Manual (Model: 750a0fb1-6427-48d0-981d-d5c0362b9a6d)

## **CLIKBUTM 750a0fb1-6427-48d0-981d-d5c0362b9a6d**

# **CLIKBUTM Finger Ring Wireless Presenter Instruction Manual**

Model: 750a0fb1-6427-48d0-981d-d5c0362b9a6d

## **1. INTRODUCTION**

This manual provides detailed instructions for the CLIKBUTM Finger Ring Wireless Presenter. This device is designed to enhance presentation delivery by offering convenient slide control and a laser pointer in a compact, wearable form factor. Please read this manual thoroughly before use to ensure proper operation and to maximize the product's lifespan.



Figure 1: Product Overview - Two CLIKBUTM Finger Ring Wireless Presenters, each with a USB receiver and a protective zippered case.

## 2. PACKAGE CONTENTS

Verify that all items are present in your package:

- CLIKBUTM Finger Ring Wireless Presenter (quantity as purchased)
- USB-A Receiver (one per presenter)
- USB-C Charging Cable
- Protective Carrying Case (one per presenter)
- User Manual (this document)

## 3. SETUP AND CHARGING

### 3.1 Initial Charging

Before first use, fully charge the presenter. The device features a built-in rechargeable battery.

1. Locate the USB-C charging port on the side of the presenter.
2. Connect the provided USB-C charging cable to the presenter and a compatible USB power source (e.g., computer USB port, wall adapter).
3. The LED indicator light will illuminate during charging. It will change color or turn off once fully charged.

4. A 5-minute charge can provide approximately one hour of use.



Figure 2: Component Overview - Highlighting the USB-A receiver, LED indicator, control buttons, laser button, and Type-C charging port.

### 3.2 Connecting the Receiver (Plug and Play)

The CLIKBUTM Wireless Presenter uses a plug-and-play USB receiver, requiring no software installation.

1. Insert the USB-A receiver into an available USB port on your computer (laptop or desktop).
2. Turn on the presenter using the ON/OFF switch located on the side.
3. The presenter will automatically connect to the receiver. The LED indicator may flash briefly and then remain steady to indicate a successful connection.



Figure 3: Easy Setup - The presenter and its USB receiver ready for use with a laptop.

## 4. OPERATING INSTRUCTIONS

### 4.1 Wearing the Presenter

The presenter is designed to be worn comfortably on your finger, allowing for free hand movement during presentations.

- Adjust the finger ring to fit securely but comfortably on your finger. The ring is designed to be lightweight and adjustable.
- Position the buttons so they are easily accessible by your thumb.

# Cool Magic Ring

You can gesture with both hands



Figure 4: Ergonomic Design - The presenter allows for natural hand gestures during a presentation.

# Adjustable Finger Ring Presentation Clicker



Figure 5: Adjustable Design - The finger ring can be adjusted for a comfortable fit.

## 4.2 Button Functions

The presenter features several buttons for controlling your presentation:

- **Page Up (Up Arrow):** Single click to move to the previous slide. Long press to show/exit slideshow mode.
- **Page Down (Down Arrow):** Single click to move to the next slide. Long press to activate a black screen.
- **Hyperlink Button (Chain Link Icon):** Single click to select a hyperlink. Double click to open a hyperlink. Long press to switch windows.
- **Laser Button (Red Star Icon):** Press and hold to activate the laser pointer. Release to turn off.
- **ON/OFF Switch:** Powers the device on or off.

## 4.3 Laser Pointer Usage

The integrated laser pointer can be used to highlight specific areas on your presentation screen.

- Ensure the presenter is powered on.
- Point the presenter towards the screen or surface you wish to highlight.
- Press and hold the Laser Button (red star icon) to emit the laser beam.
- Release the button to turn off the laser.

**Warning: Do not stare directly into the laser beam or point it at people or animals. Avoid pointing the laser at reflective surfaces.**

## 4.4 Wireless Range

The CLIKBUTM Wireless Presenter offers a substantial operating range:

- **Wireless Control Range:** Up to 98 feet (30 meters).
- **Laser Pointer Range:** Up to 328 feet (100 meters).



Figure 6: Range Capabilities - Demonstrating the effective wireless and laser ranges.

## 5. COMPATIBILITY

The CLIKBUTM Wireless Presenter is widely compatible with various operating systems and presentation software.

### 5.1 Supported Operating Systems

- Windows (2003, XP, Vista, 7, 8, 10)
- Mac OS
- Linux

## 5.2 Supported Software

- Microsoft PowerPoint (PPT)
- Microsoft Word
- Microsoft Excel
- Google Slides
- And other common presentation and document software.

# Widely Compatible

## Compatible with Windows, Mac os, Linux





Software






  





  





System



Windows



Mac OS



Linux

Figure 7: System and Software Compatibility - Illustrating broad compatibility.

## 6. MAINTENANCE

### 6.1 Cleaning

To clean the presenter, gently wipe it with a soft, dry cloth. Do not use harsh chemicals or abrasive cleaners.

## 6.2 Battery Care

- Recharge the presenter when the LED indicator shows low battery or when performance degrades.
- Avoid fully discharging the battery frequently to prolong its lifespan.
- If storing the device for an extended period, charge it to approximately 50% every few months.

## 7. TROUBLESHOOTING

Problem	Possible Cause	Solution
Presenter not responding	Device is off Low battery Receiver not connected Out of range	Ensure ON/OFF switch is in the 'ON' position. Charge the presenter. Ensure USB receiver is securely plugged into the computer. Move closer to the computer (within 98 feet/30 meters).
Laser pointer not working	Device is off Low battery Laser button not pressed	Ensure ON/OFF switch is in the 'ON' position. Charge the presenter. Press and hold the Laser Button.
Buttons function incorrectly (e.g., forward goes back)	Software conflict or specific application behavior.	Restart the presentation software and/or computer. Verify button mapping in your presentation software settings if available.

## 8. SPECIFICATIONS

- **Brand:** CLIKBUTM
- **Model Number:** 750afb1-6427-48d0-981d-d5c0362b9a6d
- **Item Weight:** 5 ounces
- **Package Dimensions:** 7.56 x 3.74 x 1.81 inches
- **Batteries:** 1 Lithium Ion battery (included, rechargeable)
- **Special Feature:** Rechargeable
- **Color:** Black
- **Max Number of Supported Devices:** 1 (per receiver)
- **Compatible Devices:** Computer
- **Wireless Control Range:** Up to 98 feet (30 meters)
- **Laser Pointer Range:** Up to 328 feet (100 meters)

## 9. WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the contact details provided with your purchase or visit the official CLIKBUTM website. Keep your purchase receipt as proof of purchase.

