



[Manuals.plus](#) /

> [BERIBES](#) /

> BERIBES Hybrid Active Noise Cancelling Bluetooth Over-Ear Headphones User Manual

## BERIBES WH305

# BERIBES Hybrid Active Noise Cancelling Bluetooth Over-Ear Headphones

Model: WH305 (WH202A)

Brand: BERIBES

## INTRODUCTION

Thank you for choosing the BERIBES Hybrid Active Noise Cancelling Bluetooth Over-Ear Headphones. These headphones are designed to provide a superior audio experience with advanced noise cancellation, high-resolution audio, and deep bass, perfect for travel, home, or daily use. This manual will guide you through the setup, operation, and maintenance of your new headphones.



Image: BERIBES Hybrid Active Noise Cancelling Bluetooth Over-Ear Headphones in white, showcasing the sleek design and comfortable earcups.

## SAFETY INFORMATION

Please read all safety instructions carefully before using this product. Keep this manual for future reference.

- Do not expose the headphones to extreme temperatures, humidity, or corrosive substances.
- Avoid dropping or subjecting the headphones to strong impacts.
- Do not disassemble or modify the headphones. This will void the warranty.
- Clean the headphones with a soft, dry cloth. Do not use harsh chemicals or abrasive materials.
- Listening at high volume levels for extended periods can cause hearing damage.

## **PACKAGE CONTENTS**

---

Ensure all items are present in the package:

- BERIBES Hybrid Active Noise Cancelling Bluetooth Over-Ear Headphones
- USB Charging Cable
- 3.5mm Audio Cable
- User Manual (this document)

## **PRODUCT OVERVIEW**

---

Familiarize yourself with the various parts and controls of your headphones.

# Never Power Off

Don't worry about power shortage when traveling long distances



Image: Side view of the BERIBES headphones, highlighting the control buttons, charging port, and 3.5mm audio jack. A phone screen in the background shows the headphones connected via Bluetooth.

## Key Features:

- **Hybrid Active Noise Cancellation:** Reduces ambient noise for immersive listening.
- **65 Hours Playtime:** Extended battery life for long listening sessions.
- **Hi-Res Audio & Deep Bass:** Delivers rich, detailed sound.
- **Built-in Microphone:** For clear hands-free calls.
- **Foldable Design:** For easy portability and storage.
- **Adjustable Headband & Swiveling Earcups:** Ensures a comfortable fit for various head sizes.

# Comfort for hours

suitable for long time wearing and convenient to carry everywhere



**Foldable Design**



**Adjustable Headband**



**90° Swirling**

Image: A visual representation of the BERIBES headphones' ergonomic features, including their foldable design, adjustable headband, and earcups that swivel 90 degrees for enhanced comfort and portability.

## SETUP

### 1. Charging the Headphones

Before first use, fully charge your headphones. A full charge provides up to 65 hours of music playback.

- Connect the USB charging cable to the charging port on the headphones and to a USB power source (e.g., computer, wall adapter).
- The LED indicator will show charging status (e.g., red for charging, blue for fully charged).
- A 5-minute quick charge can provide approximately 3 hours of playtime.

# Beyond Your Imagination

With 3.5mm audio cable, enjoy your music non-stop

 **5 min**  
charging = **3 Hours**  
playtime

 **950 Hours**  
Standby Time

 **65 Hours**  
Music Time



Image: An infographic detailing the impressive battery performance of the BERIBES headphones, including quick charge capabilities, total music playback time, and standby duration.

## 2. Powering On/Off

- **To Power On:** Press and hold the Power button for approximately 3 seconds until the LED indicator lights up.
- **To Power Off:** Press and hold the Power button for approximately 3 seconds until the LED indicator turns off.

## 3. Bluetooth Pairing

Pair your headphones with your Bluetooth-enabled device.

1. Ensure the headphones are powered off.
2. Press and hold the Power button for 5-7 seconds until the LED indicator flashes blue and red alternately, indicating pairing mode.
3. On your device (smartphone, tablet, PC), enable Bluetooth and search for available devices.
4. Select "BERIBES WH305" (or similar name) from the list of found devices.
5. Once successfully paired, the LED indicator will flash blue slowly.

6. The headphones will automatically connect to the last paired device when powered on, if within range.

#### 4. Wired Connection (3.5mm Audio Jack)

You can use the headphones with a wired connection even if the battery is depleted.

- Connect one end of the included 3.5mm audio cable to the audio input port on the headphones.
- Connect the other end to the 3.5mm audio output jack of your device.
- In wired mode, Bluetooth functionality and ANC may be limited or unavailable depending on the headphone's power status.

## OPERATING INSTRUCTIONS

---

### 1. Music Playback Controls

Function	Action
Play/Pause	Press the Multi-function button once.
Volume Up	Press the Volume + button.
Volume Down	Press the Volume - button.
Next Track	Press and hold the Volume + button.
Previous Track	Press and hold the Volume - button.

### 2. Call Management

Function	Action
Answer/End Call	Press the Multi-function button once.
Reject Call	Press and hold the Multi-function button for 2 seconds.
Activate Voice Assistant	Double-press the Multi-function button.

### 3. Active Noise Cancellation (ANC) Control

The headphones feature Hybrid Active Noise Cancellation to reduce ambient noise.

- Press the ANC button once to activate/deactivate Active Noise Cancellation.
- An indicator light (e.g., green LED) will confirm ANC status.

### 4. Sound Modes

The headphones offer multiple sound effects to enhance your listening experience.



# MUTIPLE SOUND EFFECTS

- **Pop**  
~~~~~
- **Rock**  
~~~~~
- **Vocal**  
~~~~~
- **Jazz**  
~~~~~
- **BassUp™**  
~~~~~
- **Classic**  
~~~~~

Image: A visual demonstrating the various sound modes available on the BERIBES headphones, including Pop, Rock, Vocal, Jazz, BassUp, and Classic, designed to optimize audio for different genres.

- Specific button or combination to cycle through modes (e.g., "EQ" button or double-press ANC button). *(Note: The exact control for cycling sound modes is not specified in the provided data, common controls are usually a dedicated EQ button or a combination of existing buttons.)*
- Available modes include: **Pop, Rock, Vocal, Jazz, BassUp™, and Classic.**

## MAINTENANCE

---

### Cleaning

- Wipe the headphones with a soft, dry, lint-free cloth.
- Do not use alcohol, cleaning sprays, or abrasive cleaners.
- Keep the charging port and audio jack free of dust and debris.

### Storage

- Store the headphones in a cool, dry place away from direct sunlight and extreme temperatures.
- If storing for an extended period, charge the headphones every few months to maintain battery health.
- Utilize the foldable design for compact storage when traveling.

## TROUBLESHOOTING

If you encounter issues with your headphones, refer to the following common problems and solutions:

Problem	Solution
Headphones won't power on.	Ensure the headphones are charged. Connect to a power source and try again.
Cannot pair with device.	<ul style="list-style-type: none"> <li>◦ Ensure headphones are in pairing mode (flashing blue/red).</li> <li>◦ Turn off Bluetooth on other nearby devices that might be connected.</li> <li>◦ Forget/remove the headphones from your device's Bluetooth list and try pairing again.</li> <li>◦ Restart both the headphones and your device.</li> </ul>
No sound or low volume.	<ul style="list-style-type: none"> <li>◦ Adjust volume on both the headphones and your connected device.</li> <li>◦ Ensure the headphones are properly connected via Bluetooth or 3.5mm cable.</li> <li>◦ Check if the audio source is playing.</li> </ul>
ANC not working effectively.	<ul style="list-style-type: none"> <li>◦ Ensure ANC is activated (check indicator light).</li> <li>◦ Ensure earcups form a good seal around your ears. Adjust fit if necessary.</li> <li>◦ ANC is most effective against low-frequency, constant noise.</li> </ul>

## SPECIFICATIONS

Feature	Detail
Model Name	WH305 (WH202A)
Brand	BERIBES
Connectivity Technology	Wireless (Bluetooth), Wired (3.5mm Jack)
Wireless Communication Technology	Bluetooth
Noise Cancellation	Hybrid Active Noise Reduction
Ear Placement	Over-Ear
Form Factor	Circum-Aural
Frequency Range	20 Hz - 40 kHz
Battery Life (Music Time)	Up to 65 hours
Charging Time	Not specified for full charge, 5 minutes charge provides 3 hours playtime.
Standby Time	Up to 950 hours

Feature	Detail
Compatible Devices	Mobile phones, PCs, iPads
Material	Plastic
Water Resistance Level	Not waterproof
Included Components	Cable (USB charging cable, 3.5mm audio cable)

## WARRANTY AND SUPPORT

BERIBES products are designed and manufactured to the highest quality standards. For warranty information and technical support, please refer to the warranty card included in your package or visit the official BERIBES website. For further assistance, please contact BERIBES customer service.