

Manuals.plus /

› BAIJAC /

› BAIJAC Spool Pin Replacement Instruction Manual for Singer Sewing Machines

BAIJAC Spool Pin Replacement

BAIJAC Spool Pin Replacement Instruction Manual

For Singer Sewing Machine Models: 3709, 3722, 3810, 3815, 3820, 3825, 6510, 7312, 7322, 7350, 7360

INTRODUCTION

This manual provides instructions for the proper installation and use of your BAIJAC Spool Pin Replacement. This part is designed to be compatible with various Singer sewing machine models, ensuring your machine can properly hold thread spools during operation. Please read these instructions carefully before proceeding with installation or use.

SAFETY INFORMATION

- Always unplug your sewing machine from the power outlet before installing or replacing any parts.
- Ensure the sewing machine is turned off and completely still before handling internal or external components.
- Keep small parts away from children.
- If you are unsure about any step, consult a qualified sewing machine technician.

PACKAGE CONTENTS

Your BAIJAC Spool Pin Replacement package should contain:

- 1 x BAIJAC Spool Pin Replacement

Inspect the package contents upon receipt to ensure all items are present and undamaged.

SETUP: INSTALLATION INSTRUCTIONS

Follow these steps to install the BAIJAC Spool Pin Replacement:

1. **Prepare the Machine:** Ensure your Singer sewing machine is unplugged from the power source and turned off.
2. **Locate the Spool Pin Slot:** Identify the designated slot or hole on your sewing machine where the spool pin

is inserted. This is typically located on the top or back of the machine.

3. **Remove Old Spool Pin (if applicable):** If an old or broken spool pin is present, gently pull it straight up to remove it. If it is stuck, avoid excessive force to prevent damage to the machine.
4. **Insert New Spool Pin:** Take the BAIJAC Spool Pin Replacement and align its base with the slot on your sewing machine. Gently push the spool pin straight down into the slot until it is firmly seated. Do not force it.
5. **Verify Stability:** Once inserted, gently tug on the spool pin to ensure it is securely in place and does not wobble excessively.



Image: The BAIJAC Spool Pin Replacement. This image shows the design of the spool pin, which is inserted into the designated slot on a sewing machine to hold a thread spool.

OPERATING: USING THE SPOOL PIN

Once the spool pin is installed:

1. **Place Thread Spool:** Slide your desired thread spool onto the spool pin. Ensure the thread unwinds smoothly from the spool, typically from the back or bottom, depending on your machine's design and thread type.
2. **Thread the Machine:** Follow your sewing machine's specific instructions for threading the upper thread path, guiding the thread from the spool through all necessary guides, tension discs, and the needle.
3. **Begin Sewing:** With the spool pin securely holding the thread, you can now proceed with your sewing project as usual.

MAINTENANCE

The BAIJAC Spool Pin Replacement requires minimal maintenance:

- **Cleaning:** Periodically wipe the spool pin with a soft, dry cloth to remove any dust or lint buildup.
- **Inspection:** Occasionally check the spool pin for any signs of wear or damage. If it becomes bent or cracked, replace it to ensure proper thread feeding.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Spool pin does not fit into the machine.	Incorrect model compatibility or obstruction in the slot.	Verify your sewing machine model is listed as compatible. Check the slot for any debris and clear it. Do not force the pin.
Thread tangles or breaks frequently.	Improper thread placement on the spool pin or incorrect threading of the machine.	Ensure the thread spool is placed correctly on the pin and unwinds smoothly. Re-thread the entire machine according to your machine's manual.
Spool pin feels loose after installation.	Not fully seated or slot is worn.	Push the spool pin down firmly until it clicks or feels secure. If the slot is worn, the machine may require professional service.

SPECIFICATIONS

- **Product Type:** Spool Pin Replacement
- **Brand:** BAIJAC
- **Compatibility:** Singer Sewing Machine Models 3709, 3722, 3810, 3815, 3820, 3825, 6510, 7312, 7322, 7350, 7360
- **Material:** Durable plastic (typical for spool pins)

COMPATIBLE MODELS

This BAIJAC Spool Pin Replacement is compatible with the following Singer sewing machine models:

Singer 3709

Singer 3722

Singer 3810

Singer 3815

Singer 3820

Singer 3825

Singer 6510

Singer 7312

Singer 7322

Singer 7350

Singer 7360

CUSTOMER SUPPORT

For further assistance or inquiries regarding your BAIJAC Spool Pin Replacement, please refer to the retailer where the product was purchased or visit the manufacturer's official website for contact information.

