

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [TechGlow](#) /

› [TechGlow Foldable Cellphone Stand with Bluetooth Speaker User Manual](#)

TechGlow B0B93C72FG

TechGlow Foldable Cellphone Stand with Bluetooth Speaker User Manual

Model: B0B93C72FG

1. INTRODUCTION

Thank you for choosing the TechGlow Foldable Cellphone Stand with Bluetooth Speaker. This device combines a versatile phone stand with a high-quality Bluetooth speaker, designed to enhance your media consumption and communication experience. Please read this manual carefully to ensure proper use and optimal performance.

2. SAFETY INFORMATION

- Keep the device away from water and excessive moisture.
- Avoid exposing the device to extreme temperatures.
- Do not attempt to disassemble or repair the device yourself. Contact customer support if service is required.
- Use only the provided charging cable or a certified equivalent.
- Keep out of reach of children.

3. WHAT'S IN THE BOX

- Phone Stand with Bluetooth Speaker
- USB-A to Type-C Charger cable




Image: Contents of the product packaging.

4. PRODUCT OVERVIEW

The TechGlow Foldable Cellphone Stand with Bluetooth Speaker features an integrated design for convenience and portability. It includes a foldable stand for various viewing angles and a built-in Bluetooth speaker for audio playback and hands-free calls.



Image: Product diagram with labeled controls.

Controls and Ports:

1. **VOL+ / Next:** Press to increase volume. Hold to skip to the next track.
2. **VOL- / Previous:** Press to decrease volume. Hold to go to the previous track.
3. **Answer/Hang up / Play/Pause:** Press to play/pause music. Press to answer/end a call. Hold to reject a call.
4. **Power ON/OFF:** Hold to power the device on or off.
5. **Charging port:** USB Type-C port for charging the device.
6. **Microphone:** For hands-free calling.

5. SETUP

5.1 Unboxing

Carefully remove all components from the packaging. Inspect the device for any damage. Retain the packaging for future storage or transport.

5.2 Charging the Device

Before first use, fully charge the device. Connect the provided USB-A to Type-C charging cable to the charging port (5) on the device and the other end to a USB power adapter (not included) or a computer USB port. The charging indicator will show the charging status (refer to LED indicators if present, not specified in input). A full charge provides approximately 14 hours of playtime at 50% volume.

Superior Playtime

listen to up to **280** songs at **50%** volume on a single charge.



Image: Device in use, highlighting 14 hours of playtime.

5.3 Folding and Unfolding the Stand

The stand is designed to be foldable for portability. Gently unfold the stand to your desired height and angle. Ensure it is stable before placing your device on it.

Foldable Adjustable Design

Find you the most comfortable viewing angle



Image: Foldable and adjustable design in use.

6. OPERATING INSTRUCTIONS

6.1 Power On/Off

To power on the device, press and hold the Power ON/OFF button (4) until you hear an audible prompt or see the indicator light illuminate. To power off, press and hold the same button until the device shuts down.

6.2 Bluetooth Pairing

1. Ensure the device is powered on and in pairing mode (indicated by a flashing Bluetooth light, if present).
2. On your smartphone or tablet, go to the Bluetooth settings.
3. Search for available devices and select "TechGlow-MXXXX" (or similar name).
4. Once connected, you will hear a confirmation sound, and the Bluetooth indicator light will become solid.



Image: Bluetooth pairing process shown on a smartphone.

6.3 Using as a Phone Stand

Place your smartphone or tablet (4-13 inches) securely on the adjustable holder. Adjust the angle for optimal viewing. The anti-slip pads on the hook and base provide stability and protect your device from scratches.



Image: Device holding both a smartphone and a tablet.

6.4 Using as a Bluetooth Speaker

Once paired, audio from your connected device will play through the integrated speaker. Use the VOL+ / Next (1) and VOL- / Previous (2) buttons to adjust the volume or skip tracks. Press the Play/Pause button (3) to control media playback.

6.5 Hands-free Calling

When a call comes in while connected via Bluetooth, press the Answer/Hang up button (3) to answer. Press again to end the call. Hold the button to reject an incoming call. The built-in microphone (6) allows for clear communication.



Image: Hands-free calling in use.

7. MAINTENANCE

To maintain your TechGlow device, wipe it with a soft, dry cloth. Do not use abrasive cleaners or solvents. Keep the charging port free of dust and debris.

8. TROUBLESHOOTING

Problem	Possible Cause	Solution
Device does not power on.	Low battery.	Charge the device using the provided USB-C cable.
Cannot pair via Bluetooth.	Device not in pairing mode or too far from source.	Ensure the device is powered on and in pairing mode. Move closer to the source device. Restart both devices.
No sound from speaker.	Volume too low or device not connected.	Increase volume on both the speaker and the connected device. Verify Bluetooth connection.
Phone is not stable on the stand.	Incorrect placement or stand not fully extended.	Ensure the phone is centered and resting on the anti-slip pads. Adjust the stand to a stable position.

9. SPECIFICATIONS

- **Product Dimensions:** 5.35 x 3.42 x 1.88 inches
- **Item Weight:** 12.6 ounces
- **Brand:** TechGlow
- **Model:** B0B93C72FG
- **Color:** Black
- **Form Factor:** Popgrip
- **Compatible Devices:** Smartphones, Tablets, E-readers (4-13 inches with Bluetooth function)
- **Date First Available:** August 9, 2022

10. WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the contact details provided with your purchase or visit the official TechGlow website. Keep your purchase receipt for warranty claims.