

[Manuals.plus](#) /

› [Bissell](#) /

› BISSELL ProHeat 2X Revolution Pet Turbo Upright Carpet Cleaner User Manual

Bissell 35799

BISSELL ProHeat 2X Revolution Pet Turbo Upright Carpet Cleaner User Manual

Model: 35799

INTRODUCTION

Thank you for purchasing a BISSELL ProHeat 2X Revolution Pet Turbo Upright Carpet Cleaner. This manual is designed to help you get the most out of your carpet cleaner, providing detailed instructions for assembly, operation, maintenance, and troubleshooting. With proper care, your BISSELL cleaner will provide years of effective cleaning performance.



The BISSELL ProHeat 2X Revolution Pet Turbo Upright Carpet Cleaner with its included accessories, including cleaning formulas, pet stain tool, 3-inch tough stain tool, and 7-foot hose.

Key Features

- **TurboStrength Motor Technology:** Delivers 40% more suction power and 50% noise reduction for efficient and quiet cleaning.
- **MAX Clean Mode:** Designed for deep cleaning, effectively removing embedded dirt, tough stains, and allergens.
- **Express Clean Mode:** Provides a quick clean, allowing carpets and area rugs to dry in approximately 30 minutes.
- **Heatwave Technology:** Helps maintain the water temperature throughout the cleaning process for optimal results.
- **Dual DirtLifter PowerBrushes:** Features 12 rows of bristles that actively loosen and lift deep-down dirt and stains from carpet fibers.
- **Included Tools:** Comes with a Pet Stain Tool, a 3-inch Tough Stain Tool, and a 7-foot hose for versatile cleaning of stairs, upholstery, and hard-to-reach areas.

IMPORTANT SAFETY INSTRUCTIONS

Before using your carpet cleaner, please read all instructions carefully. Failure to follow these instructions may result in electric shock, fire, or serious injury.

- Always connect to a properly grounded outlet.
- Unplug from outlet when not in use and before cleaning, maintaining, or servicing the appliance.
- Do not immerse in water or liquid.
- Do not use with damaged cord or plug.
- Do not allow to be used as a toy. Close attention is necessary when used by or near children.
- Use only as described in this manual. Use only manufacturer's recommended attachments.
- Do not pull or carry by cord, use cord as a handle, close a door on cord, or pull cord around sharp edges or corners. Do not run appliance over cord. Keep cord away from heated surfaces.
- Do not unplug by pulling on cord. To unplug, grasp the plug, not the cord.
- Do not handle plug or appliance with wet hands.
- Do not put any object into openings. Do not use with any opening blocked; keep free of dust, lint, hair, and anything that may reduce air flow.
- Keep hair, loose clothing, fingers, and all parts of body away from openings and moving parts.
- Turn off all controls before unplugging.
- Use extra care when cleaning on stairs.
- Do not use to pick up flammable or combustible materials (lighter fluid, gasoline, kerosene, etc.) or use in areas where they may be present.
- Do not use in an enclosed space where vapors are given off by oil base paint, paint thinner, mothproofing substances, flammable dust, or other explosive or toxic vapors.
- Do not use to pick up toxic material (chlorine bleach, ammonia, drain cleaner, etc.).
- Do not pick up anything that is burning or smoking, such as cigarettes, matches, or hot ashes.
- Do not use without filters in place.
- Do not use on hard surfaces.
- Do not use on wet surfaces.
- Do not use for any purpose other than described in this user guide.

WHAT'S INCLUDED

Your BISSELL ProHeat 2X Revolution Pet Turbo comes with the following components:

- BISSELL ProHeat 2X Revolution Pet Turbo Upright Carpet Cleaner
- Two 8 oz trial size bottles of cleaning formula (e.g., MAX Clean + Protect, Deep Clean + Antibacterial)
- Pet Stain Tool
- 3-inch Tough Stain Tool
- 7-foot hose
- Nozzle Clean Out Tool / Brush Roll Hair Remover



Includes

Pet Stain Tool, 3" Tough Stain Tool and Two 8 oz. Formulas

The included Pet Stain Tool, 3-inch Tough Stain Tool, and two 8 oz. trial formulas.

SETUP

Your BISSELL ProHeat 2X Revolution Pet Turbo is designed for easy assembly. Follow these steps to prepare your machine for use:

1. **Handle Assembly:** Insert the upper handle into the base of the unit until it clicks securely into place.
2. **Clean Water Tank:** Remove the clean water tank from the back of the machine. Unscrew the yellow cap at the bottom of the tank. Fill the tank with hot tap water to the 'WATER' fill line. Add your chosen BISSELL cleaning formula to the 'FORMULA' fill line. Replace the cap and secure the tank back onto the machine.



Easy Fill Cap

Makes measuring your formula
quick and spill-free!

The Easy Fill Cap makes measuring and adding cleaning formula quick and spill-free.

Ensure the dirty water tank is empty and properly seated before beginning operation.

OPERATING YOUR CARPET CLEANER

The BISSELL ProHeat 2X Revolution Pet Turbo offers multiple cleaning modes to suit your needs.

Cleaning Modes

- **MAX Clean Mode:** For heavily soiled areas and tough stains, select MAX Clean mode. This mode delivers maximum cleaning power to remove embedded dirt and allergens. Make slow, overlapping passes over the carpet, pressing the trigger to apply solution on forward and backward passes. Release the trigger for dry passes to extract water.



3 Modes of Cleaning

MAX Clean Mode, DEEP Clean Mode
and EXPRESS Clean Mode

The BISSELL ProHeat 2X Revolution Pet Turbo offers three cleaning modes, including MAX Clean Mode for professional-grade cleaning.

- **Express Clean Mode:** For quick clean-ups and faster drying times, choose Express Clean mode. This mode uses less water and allows carpets to dry in approximately 30 minutes. Use quick, overlapping passes, applying solution on forward and backward passes, then releasing the trigger for dry passes.



Dries in about 30 minutes with Express Clean Mode¹

Carpets dry in about 30 minutes when using Express Clean Mode.

Heatwave Technology

The integrated Heatwave Technology helps maintain the temperature of the water you put into the clean tank, ensuring effective cleaning throughout your session. This feature helps to optimize the performance of your cleaning solution.



Help Maintain Water Temperature with Heatwave Technology®

Heatwave Technology helps maintain water temperature throughout the cleaning process.

Using Attachments

For cleaning upholstery, stairs, and other hard-to-reach areas, attach the 7-foot hose to the hose port on the front of the machine. Securely connect your desired tool (Pet Stain Tool or 3-inch Tough Stain Tool) to the end of the hose. Press the trigger on the tool to spray solution and scrub the surface. Release the trigger and apply pressure to suction up the dirty solution.



The included hose and tools make it easy to clean pet messes from stairs and upholstery.

MAINTENANCE AND CARE

Regular maintenance ensures your BISSELL ProHeat 2X Revolution Pet Turbo continues to perform optimally.

After Each Use

- **Empty and Rinse Dirty Water Tank:** Remove the dirty water tank and dispose of the dirty water. Rinse the tank thoroughly with clean water.
- **Rinse Clean Water Tank:** If any solution remains, empty and rinse the clean water tank.
- **Clean Nozzle:** The clear nozzle cover can be removed for cleaning. Pull the blue tab labeled "PULL TO REMOVE NOZZLE" to detach the nozzle. Use the provided Nozzle Clean Out Tool to clear any debris or hair from the suction path. Rinse the nozzle under running water.



The nozzle can be removed for easy cleaning of accumulated debris.

- **Clean Brush Rolls:** The brush rolls can accumulate hair and debris. To clean, remove the nozzle cover. Use the brush roll hair remover feature on the Nozzle Clean Out Tool to cut and remove any tangled hair or fibers from the brush rolls. You can also gently wipe down the brush rolls with a damp cloth.



The Dual DirtLifter PowerBrushes effectively clean carpets and can be maintained by removing hair and debris.

- **Wipe Down Machine:** Wipe down the exterior of the machine with a soft, damp cloth.
- **Store:** Store the cleaner in a dry, protected area.

TROUBLESHOOTING

If you encounter any issues with your BISSELL ProHeat 2X Revolution Pet Turbo, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
---------	----------------	----------

Problem	Possible Cause	Solution
Reduced Spray or No Spray	Clean water tank empty or not seated correctly.	Refill clean water tank and ensure it is firmly seated.
Reduced Suction	Dirty water tank full or not seated correctly; nozzle clogged.	Empty dirty water tank and ensure it is firmly seated. Clean the nozzle and brush rolls as per maintenance instructions.
Machine Not Turning On	Power cord not securely plugged in; blown fuse/tripped breaker.	Check power plug. Check household fuse/breaker.
Brush Rolls Not Turning	Brush belt broken or dislodged; brush rolls clogged with debris.	Inspect brush belt. Clean brush rolls of any hair or debris.

PRODUCT SPECIFICATIONS

Specification	Detail
Brand	Bissell
Model Name	ProHeat 2X Revolution Pet Turbo
Item Model Number	35799
Color	Blue/Black
Item Weight	17.5 Pounds
Product Dimensions	15"D x 12.5"W x 43.5"H
Capacity	1 Gallons
Power Source	Corded
Form Factor	Upright
Assembly Required	No
Batteries Required	No

WARRANTY AND SUPPORT

BISSELL stands behind the quality of its products. For detailed warranty information, please refer to the documentation included with your purchase or visit the official BISSELL website.

Protection Plans

Consider enhancing your product protection with extended plans:

- 2-Year Protection Plan
- 3-Year Protection Plan
- Complete Protect: One plan covers all eligible past and future purchases (monthly billing option available)

For further assistance, you can access the official User Guide in PDF format:[Download User Guide \(PDF\)](#)

Visit the official Bissell Store for more products and information:[Bissell Store on Amazon](#)