

Amika 2559326

Amika Hair Blow Dryer Brush 2.0

Instruction Manual

Model: 2559326 | UPC: 840117807433

[Introduction](#)[Safety Information](#)[Product Overview](#)[Setup](#)[Operation](#)[Maintenance](#)[Troubleshooting](#)[Specifications](#)[Warranty & Support](#)

1. INTRODUCTION

Thank you for choosing the Amika Hair Blow Dryer Brush 2.0. This innovative hair tool combines the functionality of a round brush and a blow-dryer, designed to provide a voluminous blowout with enhanced shine. This manual provides essential information for the safe and effective use of your new device. Please read it thoroughly before first use and retain it for future reference.

2. IMPORTANT SAFETY INFORMATION

WARNING: To reduce the risk of electric shock, burns, fire, or injury to persons:

- Do not use this appliance near water, such as in a bathtub, shower, or sink.
- Always unplug the appliance immediately after use.
- Do not reach for an appliance that has fallen into water; unplug it immediately.
- Do not place or store the appliance where it can fall or be pulled into a tub or sink.
- Keep the cord away from heated surfaces.
- Never use while sleeping.
- Never drop or insert any object into any opening.

- Do not operate where aerosol (spray) products are being used or where oxygen is being administered.
- This appliance is for household use only.
- Do not use an extension cord with this appliance.
- Always inspect the appliance before use. If the cord is damaged, do not use.

3. PRODUCT OVERVIEW

The Amika Hair Blow Dryer Brush 2.0 features an innovative design for efficient and effective hair styling.



Figure 1: Amika Hair Blow Dryer Brush 2.0. This image shows the complete blow dryer brush, highlighting its ergonomic handle and oval brush head with bristles.

Key Features:

- **Oval Barrel Design:** Provides extra root lift and volume.
- **Detangling Bristles:** Designed to detangle, smooth, and minimize hair breakage.

- **Temperature Control Dial:** Allows selection of desired heat settings.
- **Tourmaline Coated Barrel:** Generates negative ions for a smooth, shiny finish.



Figure 2: Close-up view of the brush head, illustrating the long and short bristles for minimizing breakage, the large oval barrel for added volume, and the tourmaline-coated barrel for a smooth finish.

4. SETUP

Before using your Amika Hair Blow Dryer Brush 2.0 for the first time, please follow these steps:

1. **Unpack:** Carefully remove the blow dryer brush from its packaging.
2. **Inspect:** Check the appliance and its cord for any signs of damage. Do not use if damaged.
3. **Placement:** Ensure you have access to a standard electrical outlet and a clear, dry surface for styling.
4. **Plug In:** Insert the power plug into a suitable electrical outlet.

5. OPERATING INSTRUCTIONS

Follow these steps for optimal results when using your Amika Hair Blow Dryer Brush 2.0:

1. **Prepare Hair:** Begin with towel-dried hair. For best protection against heat damage, apply a heat protectant such as The Wizard Detangling Primer or Blockade Heat Defense Serum (each sold separately).
2. **Select Setting:** Turn the brush on by rotating the temperature control dial clockwise to your desired heat setting.
3. **Section Hair:** Divide your hair into manageable sections.
4. **Style:** Working section by section, maneuver the brush through your hair from root to tip.
5. **Add Volume:** For additional volume, over-direct sections at the crown of your head by lifting them upwards as you dry.
6. **Finish:** Once styling is complete, rotate the temperature control dial to the 'OFF' position and unplug the appliance.

Styling Results:



Figure 3: Before and after comparison of hair with a curly texture, demonstrating the smoothing and styling capabilities of the blow dryer brush.

before

after



amika:

hair blow dryer brush

Figure 4: Before and after comparison of hair with a wavy texture, showing improved smoothness and volume after using the blow dryer brush.

before

after



Figure 5: Before and after comparison of medium-length hair, illustrating the transformation to a smoother, styled look.

6. MAINTENANCE AND CARE

Proper maintenance ensures the longevity and performance of your Amika Hair Blow Dryer Brush 2.0.

- **Cleaning:** Ensure the appliance is unplugged and completely cool before cleaning. Gently remove any hair tangled in the bristles. Wipe the barrel and handle with a soft, damp cloth. Do not use abrasive cleaners or immerse the appliance in water.
- **Storage:** Store the appliance in a cool, dry place, away from moisture and direct sunlight. Do not wrap the cord around the appliance, as this can damage the cord.
- **Air Filter:** Regularly check the air inlet filter at the bottom of the handle for lint and dust. Clean it gently with a small brush or vacuum cleaner attachment to maintain airflow.

7. TROUBLESHOOTING

If you encounter issues with your Amika Hair Blow Dryer Brush 2.0, refer to the following common problems and

solutions:

Problem	Possible Cause	Solution
Appliance does not turn on.	Not plugged in; power outlet malfunction; damaged cord.	Ensure the plug is fully inserted. Test the outlet with another device. Inspect the cord for damage; if damaged, discontinue use and contact support.
Low airflow or heat.	Blocked air inlet filter.	Unplug the appliance and clean the air inlet filter as described in the Maintenance section.
Hair tangles in bristles.	Too much hair in one section; improper technique.	Work with smaller sections of hair. Ensure hair is towel-dried and detangled before use.
Unusual smell or noise.	Internal malfunction.	Immediately unplug the appliance and discontinue use. Contact customer support.

8. SPECIFICATIONS

Feature	Detail
Brand	Amika
Model Number	2559326
UPC	840117807433
Product Dimensions	16.02 x 5.79 x 4.25 inches
Item Weight	2.6 Pounds
Color	Black
Shape	Oblong
Handle Material	Plastic
Special Feature	Heat Resistant
Manufacturer	amika

9. WARRANTY AND CUSTOMER SUPPORT

Amika stands behind the quality of its products. For specific warranty details, please refer to the warranty card included with your purchase or visit the official Amika website. Keep your proof of purchase for warranty claims. If you have any questions, require technical assistance, or need to report an issue, please contact Amika customer support:

- **Website:** www.amika.com
- **Email:** Refer to the website for contact forms or email addresses.
- **Phone:** Refer to the website for customer service phone numbers.

When contacting support, please have your product model number (2559326) and purchase date available.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question