Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

amika 2436863

Amika Double Agent 2-in-1 Straightening Blow Dryer Brush User Manual

Model: 2436863

Introduction

The Amika Double Agent 2-in-1 Straightening Blow Dryer Brush is designed to simplify your hair styling routine by combining the functions of a blow dryer and a straightening brush. This innovative tool features far-infrared heat to help lock in moisture, a negative-ion generator for smooth and shiny results, and three distinct heat settings to cater to various styling needs. It is equipped with flexible outer teeth for a good grip during use and an extra-long 360° swivel cord for ease of maneuverability.



Image: The Amika Double Agent 2-in-1 Straightening Blow Dryer Brush, highlighting its flexible outer teeth, far-infrared heat, negative-ion generator, 3 heat settings, and extra-long 360° swivel cord.

Setup

1. **Unpack:** Carefully remove the Amika Double Agent from its packaging. Inspect the device for any signs of damage.
2. **Power Connection:** Plug the device into a standard electrical outlet. Ensure the voltage is compatible with your region's power supply.
3. **Hair Preparation:** For best results, ensure your hair is clean and detangled. If using the blow dryer function, towel-dry your hair until it is damp, not soaking wet. For straightening, hair should be mostly dry.

Operating Instructions

Understanding the Settings

The Amika Double Agent features three distinct heat settings, controlled by a dial on the handle:

- **Blow Dryer Setting (Air Only):** This setting provides airflow to dry your hair while brushing. Ideal for damp hair to achieve a smooth blowout.
- **Combo Setting (Dry + Straighten):** This combines airflow with thermal heat, allowing you to dry and straighten your hair simultaneously. Suitable for damp hair that requires both drying and initial straightening.
- **Thermal Setting (Straighten + Touch Up):** This setting provides direct heat without significant airflow, perfect for straightening dry hair or for touch-ups.



Image: A close-up view of the Amika Double Agent's handle, illustrating the three heat settings: Blow Dryer, Combo, and Thermal.

Step-by-Step Usage

1. **Prepare Hair:** Ensure hair is towel or air-dried to the desired dampness. Apply a heat protectant product. Comb out any tangles thoroughly.
2. **Section Hair:** Divide your hair into manageable sections using clips. Smaller sections generally yield better results, especially for straightening.
3. **Select Setting:** Turn the dial to your desired setting (Blow Dryer, Combo, or Thermal) based on your hair's dampness and styling goal.

4. **Glide Through Hair:** Take one section of hair and slowly glide the brush through it from root to tip. Ensure the hair passes through both the top and bottom bristles for even heat distribution and effective styling. Repeat as necessary until the desired smoothness and dryness are achieved.



Image: A visual step-by-step guide demonstrating the process of preparing hair, selecting a setting, and gliding the Amika Double Agent brush through hair sections.

Styling Results

The Amika Double Agent is designed to deliver various styles, from sleek and straight to bouncy and smooth, depending on the chosen setting and technique.



Image: Before and after comparison of curly hair styled with the Amika Double Agent, showing a sleek, straightened result.



Image: Before and after comparison of wavy hair styled with the Amika Double Agent, demonstrating a smooth, straightened finish.



Image: Before and after comparison of red hair, showing both sleek and bouncy styles achieved with the Amika Double Agent.



Image: Before and after comparison of wet hair, demonstrating the drying and smoothing capabilities of the Amika Double Agent.

Maintenance

Proper maintenance ensures the longevity and optimal performance of your Amika Double Agent.

- **Cleaning the Brush Head:** After each use, ensure the device is unplugged and cool. Carefully remove any loose hair from the bristles. Use a soft, damp cloth to wipe down the brush head and handle. Do not use harsh chemicals or abrasive cleaners.
- **Storage:** Store the device in a cool, dry place, away from direct sunlight and moisture. Do not wrap the cord tightly around the device, as this can cause damage.

Troubleshooting

If you encounter issues with your Amika Double Agent, refer to the following common problems and solutions:

Problem	Possible Cause	Solution

Problem	Possible Cause	Solution
Hair is frizzy or not smooth	Hair not fully detangled; incorrect setting; too-fast passes.	Ensure hair is thoroughly detangled before use. Use the Combo or Thermal setting for straightening. Glide the brush slowly through hair sections.
Hair gets caught or pulled	Hair not detangled; large sections; bristles not fully engaging hair.	Always detangle hair completely. Work with smaller, manageable sections. Ensure hair is properly threaded through the bristles.
Device not heating or blowing air	Not plugged in; power switch off; internal malfunction.	Check power connection. Ensure the setting dial is not on 'Off'. If the issue persists, contact customer support.
Device feels too hot	Using the Thermal setting for too long on one section; touching heated plates.	Avoid prolonged contact with hair sections. Be mindful of where you touch the brush head, as some areas can get very hot. Use caution near the scalp.

Specifications

- **Model Number:** 2436863
- **UPC/GTIN:** 840117803787
- **Manufacturer:** Amika
- **Package Dimensions:** 14.76 x 5.59 x 2.91 inches
- **Item Weight:** 2.36 Pounds
- **Features:** Far-infrared heat, Negative-ion generator, 3 heat settings, Flexible outer teeth, 360° swivel cord

Warranty Information

For detailed warranty information, please refer to the official Amika website or the warranty card included with your product. Warranty terms and conditions may vary by region and retailer.

Customer Support

If you require further assistance, have questions about your Amika Double Agent, or need to report an issue, please contact Amika customer support through their official website or the contact information provided in your product packaging.

© 2023 Amika. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0B94QSZ88

More documents and user manuals: **https://manuals.plus/**