

[Manuals.plus](#) /

› [B. toys](#) /

› B. toys Pop-Up Buddies Interactive Toy Instruction Manual

B. toys BX2063Z

B. toys Pop-Up Buddies Interactive Toy Instruction Manual

Model: BX2063Z

[Introduction](#) [Safety Information](#) [Setup](#) [Operating](#)
[Instructions](#) [Maintenance](#) [Troubleshooting](#) [Specifications](#) [Warranty & Support](#)

1. INTRODUCTION

The B. toys Pop-Up Buddies is an interactive educational toy designed for toddlers aged 18 months and over. This toy features five unique pop-up activities that engage children in cause-and-effect play while developing fine motor skills and sensory development. Each activity requires a different action—turning, pushing, toggling, sliding, or flipping—to reveal a friendly character inspired by nature.



Figure 1: The B. toys Pop-Up Buddies interactive toy.

2. SAFETY INFORMATION

- **Age Recommendation:** This toy is suitable for children 18 months and older.
- **Material Safety:** The toy is BPA-free, phthalate-free, and lead-safe.
- **Supervision:** Always supervise children during play to ensure safe interaction with the toy.
- **Inspection:** Before each use, inspect the toy for any damage or loose parts. Discontinue use if any damage is found.
- **Cleaning:** Refer to the Maintenance section for proper cleaning instructions.

3. SETUP

The B. toys Pop-Up Buddies toy requires no assembly. Simply remove it from its packaging. Ensure all packaging materials are safely discarded before giving the toy to a child.

- Unpack the toy and remove any ties or plastic fasteners.
- Inspect the toy for any manufacturing defects or damage.
- Place the toy on a flat, stable surface for play.

4. OPERATING INSTRUCTIONS

The Pop-Up Buddies toy features five distinct interactive mechanisms, each designed to reveal a character. Encourage your child to explore each button and discover its unique action.

1. **Flower Button (Sun Pop-Up):** Turn the red flower button clockwise or counter-clockwise to make the sun character pop out from its compartment.
2. **Cloud Button (Rainbow Pop-Up):** Press down on the white cloud button to reveal the rainbow character.
3. **Star Button (Moon Pop-Up):** Toggle the yellow star button from side to side to make the moon character appear.
4. **Raindrop Button (Cloud Pop-Up):** Slide the blue raindrop button horizontally to make the cloud character pop up.
5. **Mushroom Button (Tree Pop-Up):** Flip the red mushroom button up or down to make the tree character emerge.



Figure 2: Detailed view of the interactive buttons and pop-up characters.

Official Product Video

Video 1: An official demonstration of the B. toys Pop-Up Buddies toy, showcasing its interactive features and how each button activates a pop-up character.

5. MAINTENANCE

To ensure the longevity and hygiene of your B. toys Pop-Up Buddies toy, follow these simple maintenance guidelines:

- **Cleaning:** Wipe the toy with a damp cloth and mild soap. Rinse thoroughly with a clean, damp cloth to remove any soap residue.
- **Drying:** Allow the toy to air dry completely before storing or allowing a child to play with it again.
- **Storage:** Store the toy in a clean, dry place away from direct sunlight and extreme temperatures to prevent material degradation.

- **Avoid Harsh Chemicals:** Do not use abrasive cleaners, solvents, or harsh chemicals, as these can damage the plastic and colors.

6. TROUBLESHOOTING

If you encounter any issues with your Pop-Up Buddies toy, refer to the following common troubleshooting tips:

- **Pop-Up Mechanism Not Working:**
 - Ensure the corresponding button is fully engaged (turned, pressed, toggled, slid, or flipped) as described in the Operating Instructions.
 - Check for any small debris or foreign objects obstructing the mechanism.
- **Stiff Buttons:**
 - New toys may have slightly stiffer mechanisms. Continued use will typically loosen them.
 - Ensure the toy is clean and free from sticky residues that might affect button movement.

If problems persist, please contact customer support as detailed in the Warranty & Support section.

7. SPECIFICATIONS

Feature	Detail
Brand	B. toys
Model Number	BX2063Z
Age Range	18 Months +
Material Type	Plastic
Item Dimensions (LxWxH)	13.89 x 6.5 x 4 inches
Operation Mode	Manual
Batteries Required	No
Educational Objective	Develop fine motor skills and introduce the concept of cause-and-effect
Included Components	Toy

8. WARRANTY & SUPPORT

Warranty: This product is sold without a manufacturer's warranty. Please refer to the retailer's return policy for any issues or concerns within the applicable return period.

Customer Support: For any questions, concerns, or assistance with your B. toys Pop-Up Buddies toy, please contact the retailer where the product was purchased. They will be able to provide guidance or direct you to the appropriate support channels.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question