

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Sanag](#) /

› [Sanag M13S Pro Bluetooth Speaker Instruction Manual](#)

## Sanag M13S

# Sanag M13S Pro Bluetooth Speaker Instruction Manual

MODEL: M13S PRO

## Introduction

The Sanag M13S Pro is an ultra-portable Bluetooth speaker designed for high-quality audio on the go. It features dynamic RGB lighting, powerful 360° stereo sound with enhanced bass, and IPX7 waterproofing for durability in various environments. With Bluetooth 5.3 connectivity and an 18-hour playtime, it offers a seamless and extended listening experience. This manual provides essential information for setting up, operating, and maintaining your speaker.

## What's in the Box

- RGB Portable Bluetooth Speaker
- Type-C Charging Cable
- Aux Cable
- User Manual

## Product Features

- **Beat-Driven RGB Light Show:** Dynamic lighting effects pulsate and sparkle to the beat of your music.
- **Hi-Fi Stereo Sound:** Full-range drivers and passive radiators deliver powerful 360° stereo sound with enhanced bass, tight mids, and crystal-clear highs. Advanced digital signal processor ensures distortion-free sound.
- **IPX7 Waterproof:** Designed to withstand water splashes, spray, and rain, making it suitable for outdoor use.
- **Ultra Portable Design:** Compact size with an integrated loop for easy carrying.
- **Clear Call & 18H Playtime:** Built-in noise-cancelling microphone for crystal clear calls and up to 18 hours of continuous music playback.

## Setup

### Charging the Speaker

Before first use, fully charge the speaker. Connect the provided Type-C charging cable to the speaker's charging port and a suitable USB power source. The charging indicator light will show the charging status.



**Image:** Sanag M13S Pro speaker with the rubber flap open, revealing the USB-C charging port and TF card slot. A detailed view of the speaker's connectivity options.

## Bluetooth Pairing

1. Power on the speaker by pressing and holding the power button. The RGB light will begin to flash, indicating it is in pairing mode.
2. On your device (smartphone, tablet, etc.), enable Bluetooth and search for available devices.
3. Select "Sanag M13S Pro" from the list of devices.
4. Once connected, the speaker will emit a confirmation tone, and the RGB light will stop flashing and display a steady pattern.

# 2 Choices



TF Card

Bluetooth 5.3



**Image:** Sanag M13S Pro speaker positioned next to a smartphone displaying the Bluetooth 5.3 logo, illustrating the wireless connection capability. The speaker also shows its TF card slot.

Your browser does not support the video tag.

**Video:** This video demonstrates the unboxing and initial setup of the Sanag Bluetooth Speaker, including how to power it on and connect it via Bluetooth to a mobile device. It highlights the speaker's compact size and features.

## Operating Instructions

### Power On/Off

Press and hold the power button (usually marked with 'O') for a few seconds to turn the speaker on or off.

### Volume and Track Control

- **Volume Up:** Short press the '+' button.
- **Volume Down:** Short press the '-' button.
- **Next Track:** Long press the '+' button.
- **Previous Track:** Long press the '-' button.
- **Play/Pause:** Short press the power button ('O').

## RGB Light Modes

The speaker features multiple RGB light modes. To switch between modes, press the power button ('O') three times quickly. Available modes include:

- Gradient mode (music-synced light changes between various colors).
- Flowing mode (light changes brightness according to music volume).
- No indicator mode (lights off to conserve battery).



**Image:** Multiple Sanag M13S Pro speakers in different colors (red, black, orange, green, purple) showcasing their vibrant RGB light show, with lights pulsing from the bottom edge.

Your browser does not support the video tag.

**Video:** This video from the seller demonstrates the RGB pulsing light feature of the Sanag M13S Pro speaker, showcasing how the lights react to music.

## TF Card Playback


Insert a TF (Micro SD) card with pre-loaded music into the designated slot. The speaker will automatically switch to TF card mode and begin playback. To switch back to Bluetooth mode, double-click the power button ('O').

## Hands-Free Calling

The built-in noise-cancelling microphone allows for clear hands-free calls. When a call comes in, short press the power button ('O') to answer or end the call. Long press to reject a call.

# Clear Call

Enjoy crystal clear calls from your speaker with noise-cancelling microphone



**Image:** A woman in a car holding the Sanag M13S Pro speaker, highlighting its clear call feature with a noise-cancelling microphone.

## Maintenance

---

### Waterproof Care (IPX7)

The Sanag M13S Pro is IPX7 waterproof, meaning it can be submerged in up to 1 meter of water for 30 minutes. Ensure the rubber flap covering the charging port and TF card slot is securely closed before exposing the speaker to water. After exposure to water, wipe the speaker dry with a soft cloth.



# IPX7 WATER RESISTANT

Just enjoy your outdoor adventure

**Image:** Sanag M13S Pro speaker placed on the edge of a swimming pool, emphasizing its IPX7 water-resistant feature for outdoor adventures.



**Image:** A red Sanag M13S Pro speaker partially submerged in water, with splashes, illustrating its IPX7 true waterproof capability.

## General Care

Clean the speaker with a soft, dry cloth. Avoid using harsh chemicals or abrasive materials. Store the speaker in a cool, dry place when not in use.

## Troubleshooting

- Speaker will not power on:** Ensure the speaker is fully charged.
- Cannot pair via Bluetooth:** Make sure the speaker is in pairing mode (flashing RGB light) and your device's Bluetooth is enabled. Try restarting both the speaker and your device.
- No sound:** Check the volume levels on both the speaker and your connected device. Ensure the speaker is correctly paired.
- RGB lights not working:** Cycle through the RGB light modes by pressing the power button three times quickly. Ensure the speaker is not in "No indicator mode."

## Specifications

Feature	Specification
Model Name	M13
Speaker Type	Subwoofer
Special Feature	Portable
Wireless Communication Technology	Bluetooth 5.3
Water Resistance Level	Waterproof (IPX7)
Speaker Maximum Output Power	10 Watts

Item Weight	7.7 ounces
Product Dimensions	3.03"D x 3.8"W x 1.6"H
Power Source	Battery Powered (1 Lithium Polymer battery included)
Audio Output Mode	Stereo
Compatible Devices	iPhone, Samsung, Xiaomi, OnePlus

## Warranty and Support

---

Sanag is committed to your satisfaction. We provide a 30-day no-reason return policy and a 180-day warranty. If you encounter any problems, please contact us promptly through one of the following options:

- Go to your Amazon account: [Account Service] > [Order History] > [Seller Contact].
- Click on our business name "NIEWEILI-US" on the product page, then click the yellow "Questions" button to send us an email.