



[Manuals.plus](#) /

> [RCA](#) /

> RCA 32V-type FHD Tunerless Smart TV RCA-32D1 User Manual

RCA RCA-32D1

RCA 32V-type FHD Tunerless Smart TV RCA-32D1 User Manual

Model: RCA-32D1 | Brand: RCA

INTRODUCTION

Thank you for purchasing the RCA 32V-type FHD Tunerless Smart TV, model RCA-32D1. This television is designed for seamless access to online streaming content without the need for traditional terrestrial broadcast tuners. It features a Full HD display, built-in Wi-Fi, Chromecast functionality, and voice control for an enhanced viewing experience. This manual provides essential information for setting up, operating, maintaining, and troubleshooting your new TV.



Figure 1: Front view of the RCA 32V-type FHD Tunerless Smart TV.

SAFETY INFORMATION

Please read all safety instructions carefully before using the product. Keep this manual for future reference.

- Do not expose the TV to rain or moisture to prevent fire or electric shock.
- Ensure proper ventilation. Do not block ventilation openings.
- Use only the power cord supplied with the TV.
- Do not open the TV casing. Refer all servicing to qualified personnel.
- Keep batteries out of reach of children. Dispose of used batteries responsibly.
- Avoid placing the TV on unstable surfaces.

PACKAGE CONTENTS

Verify that all items are present in the package:

- RCA 32V-type FHD Tunerless Smart TV Unit
- Remote Control
- AAA Batteries (x2)
- TV Stand (Base and Screws)
- Power Cable
- User Manual (This document)

SETUP

1. Physical Setup

Attach the TV stand or mount the TV to a wall. For wall mounting, ensure you use a VESA-compatible bracket (40 x 40mm) and appropriate screws (M6 10mm x 2 for upper two points, screws for lower two points are included with the TV). Always ensure the TV is securely mounted to prevent accidents.




Figure 2: TV dimensions and connection terminal layout.

2. Connections

Connect the power cable to the TV and then to a power outlet. This TV requires only a power connection and Wi-Fi for internet streaming.

チューナーレスだから
コンセントとWi-FiがあればOK!!



面倒なアンテナ配線が不要です♪

Figure 3: Power and Wi-Fi connectivity for the tunerless TV.

For external devices, use the available ports:

- **HDMI Ports (x3):** Connect game consoles, Blu-ray players, or other HDMI-compatible devices.
- **USB 2.0 Ports (x2):** Connect USB storage devices for media playback.
- **LAN Port:** For wired internet connection (optional, Wi-Fi is also available).
- **Audio Output:** For connecting external audio systems.

HDMI端子 3ポート搭載

あれもこれも接続して楽しめる♪



Figure 4: Connecting external devices via HDMI ports.

3. Initial Power On

After connecting the power, press the power button on the remote control. Follow the on-screen instructions to complete the initial setup, including connecting to your Wi-Fi network and logging into your Google account to access smart TV features.

OPERATING

1. Remote Control

The included remote control allows for easy navigation and features voice control capabilities. Dedicated buttons provide quick access to popular streaming services.

- **Voice Control:** Press the voice assistant button and speak commands like "Play cat videos on YouTube" or "Increase volume."
- **Dedicated App Buttons:** Quickly launch NETFLIX, YouTube, and Prime Video with a single press.
- **Navigation:** Use the directional pad and OK button to navigate menus and select options.

Googleアシスタント対応リモコン



かんたん音声操作が とっても便利♪

“テレビを
消して”



数字ボタン付き &
日本語表記で使いやすい



“YouTubeで
ねこの動画を
再生して”

“音量を
上げて”

専用ボタンで
見たいアプリを
すぐに起動

Figure 5: Remote control with voice command functionality and dedicated app buttons.

2. Smart TV Features

This tunerless TV provides access to a wide range of online video distribution services and features:

- **Streaming Services:** Enjoy content from NETFLIX, YouTube, Prime Video, Tver, U-NEXT, AbemaTV, and more.
- **Chromecast Built-in:** Cast content directly from your smartphone or tablet to the TV screen.
- **Android OS:** Access a variety of apps from the Google Play Store.



動画をテレビで再生しながら スマホで他を探すことも可能

スマホに保存している動画や画像も大画面で視聴できます。

*スマートフォンやタブレットの一部機種では著作権保護規制により動画配信サービスを出力できない場合があります。

Figure 6: Using Chromecast to cast content from a smartphone to the TV.

Video 1: Demonstration of the Google TV interface and voice control for content discovery.

3. Basic Operations

- **Power On/Off:** Press the power button on the remote control.
- **Volume Control:** Use the Volume Up/Down buttons on the remote.
- **Input Selection:** Press the Input button to switch between HDMI and other connected sources.

MAINTENANCE

1. Cleaning

To clean the TV screen, gently wipe it with a soft, lint-free cloth. For stubborn marks, slightly dampen the cloth with water or a screen-cleaning solution. Do not spray liquid directly onto the screen. Clean the TV casing with a soft, dry cloth.

2. Storage

If storing the TV for an extended period, disconnect it from the power outlet and store it in a cool, dry place away from direct

sunlight and extreme temperatures.

TROUBLESHOOTING

If you encounter issues with your TV, refer to the following common problems and solutions:

Problem	Solution
No power	Ensure the power cable is securely connected to both the TV and the power outlet. Try a different outlet.
No picture/Sound but no picture	Check the input source. Ensure external devices are powered on and connected correctly.
Remote control not working	Replace the batteries. Ensure there are no obstructions between the remote and the TV's IR sensor.
Cannot connect to Wi-Fi	Check your router and internet connection. Re-enter the Wi-Fi password. Move the TV closer to the router.
App is slow or freezes	Restart the TV. Clear the app's cache in the TV settings. Ensure your internet connection is stable.

If the problem persists, please contact customer support.

SPECIFICATIONS

The following are the technical specifications for the RCA-32D1 Tunerless Smart TV:

Feature	Detail
Model Number	RCA-32D1
Screen Size	31.5 inches (32V-type)
Display Technology	LCD, VA Panel, LED Backlight
Resolution	Full HD (1920 x 1080)
Refresh Rate	60 Hz
Contrast Ratio	3000:1
Operating System	Android
Connectivity	Wi-Fi, HDMI (x3), USB 2.0 (x2), LAN, Audio Output
Special Features	Chromecast Built-in, Voice Control
Supported Streaming Services	Netflix, YouTube, Prime Video, Tver, U-NEXT, AbemaTV
Product Dimensions (D x W x H)	16.1 x 73.1 x 47 cm

Feature	Detail
Item Weight	4.9 kg
VESA Mount Standard	40 x 40mm
Included Batteries	2 AAA batteries



Figure 7: High-definition VA panel for vivid image quality.

WARRANTY AND SUPPORT

This product is covered by the manufacturer's warranty. Please refer to the warranty card included in your package for specific terms and conditions.

Customer Support

For technical assistance or inquiries, please contact the KEIYO Support Center:

Phone: 050-8880-2812

Reception Hours: Weekdays 10:00-12:00, 13:00-17:00 (Excluding summer holidays, year-end/New Year holidays, Golden Week, and public holidays).