

- Manuals.plus /
- › TOZO /
- › TOZO A2 Mini Wireless Earbuds Instruction Manual

TOZO A2

# TOZO A2 Mini Wireless Earbuds User Manual

Model: A2  
Brand: TOZO

## INTRODUCTION

Thank you for choosing the TOZO A2 Mini Wireless Earbuds. This manual provides essential information for setting up, operating, and maintaining your earbuds to ensure optimal performance and longevity. Please read it thoroughly before use.



Image: TOZO A2 Mini Wireless Earbuds and their charging case.

## WHAT'S IN THE BOX

- TOZO A2 Mini Wireless Earbuds
- Charging Case
- Eartips (multiple sizes)
- USB-C (A to C) cable (30cm)

## SETUP

---

### 1. Initial Charging

Before first use, ensure both the earbuds and the charging case are fully charged. Place the earbuds into the charging case. Connect the USB-C cable to the charging port on the case and plug the other end into a compatible USB power source. The indicator lights on the case will show charging status.

### 2. Pairing with Your Device

The TOZO A2 earbuds feature one-step pairing. Simply open the charging case, and the earbuds will automatically enter pairing mode. On your device (smartphone, tablet, laptop), go to Bluetooth settings and select "TOZO-A2" from the list of available devices. Once connected, you will hear a confirmation tone.

# One Step Pairing

Auto Pairing When Open the Charging Case After First Connection.  
Easy Connection with Bluetooth <TOZO-A2>  
Compatible with iOS/ Android/ Windows etc.




Image: Illustration of the one-step pairing process with a smartphone.

## 3. Wearing the Earbuds

Select the appropriate eartip size for a comfortable and secure fit. The earbuds are designed to fit snugly in your ear canal. Gently insert each earbud and twist slightly to ensure a stable position. A proper fit is crucial for optimal sound quality and noise isolation.

# ORIGX Acoustic

TOZO research HI-FI digital, material and cavity acoustic technology that compensates for the frequency lost when the sound passes through the ear canal curve, keeping the sound that reaches the eardrum is closest to reality.



The Advanced  
Bluetooth 5.3  
Technology



**TOZO ORIGX**  
**Acoustic**  
**Technology**

Image: A person wearing the TOZO A2 earbuds, highlighting their comfortable and discreet fit.

# Ultra lightweight design

A single earbud weighs only 3.7g ,  
holding it in hand as if it were nothing.



Image: The earbuds are shown to be ultra-lightweight, weighing only 3.7g each.

## OPERATING INSTRUCTIONS

### Touch Controls

The TOZO A2 earbuds support smart touch control for convenient operation:

- **Volume Control:** Tap the left or right earbud to adjust volume (specific tap patterns may vary, refer to quick start guide for details).
- **Previous/Next Song:** Double-tap the left or right earbud to skip tracks.
- **Pause/Play:** Single-tap either earbud to pause or resume playback.
- **Answer/End Calls:** Single-tap either earbud during an incoming call to answer, or during a call to end.
- **Voice Assistant:** Triple-tap either earbud to activate your device's voice assistant.

## Call Functions

The earbuds feature a built-in microphone for clear calls. Ensure the earbuds are properly connected to your device for call functionality.

### Superior Clear Calls

Long diameter speaker with Crystal Clear Call .

Built-in microphone can make others hear your voice very clearly.



Image: A man demonstrating the use of TOZO A2 earbuds for clear communication.

## Battery Life

The earbuds provide approximately 5 hours of listening time on a single charge. The charging case holds an additional 3 charges, extending the total playtime to up to 20 hours. The charging case has a battery capacity of 315 mAh.

# 20-Hour Playtime

With earbuds 30 mAh and charging case 315 mAh, earbuds last for 5 hours of listening per charge and a maximum of 20 hours on 3 additional charges from the case.

**5** hrs  
Single charge

**20** hrs  
With charging case

**315** mAh  
Battery capacity



Image: Visual representation of the 20-hour total playtime with the charging case.

## MAINTENANCE

### Cleaning

Regularly clean your earbuds and charging case to maintain optimal performance and hygiene. Use a soft, dry, lint-free cloth. For the eartips, you can gently wipe them with a damp cloth and mild soap, then dry thoroughly before reattaching.

### Water Resistance

The TOZO A2 earbuds are IPX5 waterproof. This means they are resistant to splashes and sweat, making them suitable for workouts and light rain. However, they are not designed for submersion in water. Avoid exposing them to strong jets of water or prolonged immersion.

## TROUBLESHOOTING

- **Earbuds not pairing:** Ensure both earbuds are in the charging case, then open the lid. Check your device's Bluetooth settings to ensure Bluetooth is enabled and "TOZO-A2" is selected. If issues persist, try forgetting the device on your phone and re-pairing.
- **Only one earbud working:** Place both earbuds back into the charging case, close the lid, wait a few seconds, then open it again. This often resets the connection between the two earbuds.
- **No sound:** Check the volume level on both your device and the earbuds. Ensure the earbuds are properly connected via Bluetooth.
- **Charging issues:** Verify the USB-C cable is securely connected to both the case and the power source. Ensure the charging pins on the earbuds and inside the case are clean and free of debris.

## SPECIFICATIONS

| Feature                        | Detail                   |
|--------------------------------|--------------------------|
| Model Name                     | A2                       |
| Brand                          | TOZO                     |
| Connectivity Technology        | Wireless (Bluetooth 5.3) |
| Ear Placement                  | In Ear                   |
| Water Resistance Level         | IPX5 (Waterproof)        |
| Battery Life (Earbuds)         | 5 Hours (single charge)  |
| Total Playtime (with case)     | 20 Hours                 |
| Charging Case Battery Capacity | 315 mAh                  |
| Charging Time                  | 2 Hours                  |
| Control Method                 | Touch                    |
| Audio Driver Size              | 6 Millimeters            |
| Frequency Response             | 20 Hz - 20 kHz           |
| Sensitivity                    | 100 dB                   |
| Impedance                      | 32 Ohm                   |

| Feature              | Detail                   |
|----------------------|--------------------------|
| Item Weight (Earbud) | 3.7g (single earbud)     |
| Product Dimensions   | 1.27 x 0.87 x 0.9 inches |

## WARRANTY AND SUPPORT

For warranty information and customer support, please refer to the official TOZO website or contact their customer service directly. Keep your purchase receipt for warranty claims.

© 2024 TOZO. All rights reserved.

### ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

---

Open the live page

<https://manuals.plus/asin/B0B979SXNT>

More documents and user manuals: <https://manuals.plus/>