

[Manuals.plus](#) /

> [Momcozy](#) /

> Momcozy Bottle Warmer Instruction Manual

## Momcozy MW01

# Momcozy Bottle Warmer Instruction Manual

Model: MW01 | Brand: Momcozy

## 1. INTRODUCTION

The Momcozy Bottle Warmer is a multifunctional device designed to simplify baby feeding by offering fast warming, food heating, steaming, thawing, and a 24-hour keep warm function. It features accurate temperature control and automatic shut-off for safety and convenience. Please read this manual thoroughly before first use to ensure proper operation and maintenance.

### Important Safety Information

- Always keep the appliance out of reach of children.
- Do not immerse the main unit in water or other liquids.
- Ensure the appliance is placed on a stable, level, and heat-resistant surface.
- Unplug the appliance when not in use and before cleaning.
- Do not operate if the cord or plug is damaged.

## 2. PRODUCT OVERVIEW

The Momcozy Bottle Warmer (Model MW01) is engineered for efficiency and ease of use, providing multiple functions to meet your baby's feeding needs.

### Components

- Main Unit (with control panel)
- Bottle Basket
- Lid/Cover
- Measuring Cup

### Key Features

- **Fast Warming:** Heats milk from cold to feeding temperature in as little as 2-5 minutes.
- **Thawing:** Safely thaws frozen breastmilk or baby food.
- **Food Heating:** Warms baby food jars evenly.

- **Steaming/Sterilizing:** Provides steam up to 100°C (212°F) for sterilization.
- **24H Keep Warm:** Maintains desired temperature for up to 24 hours.
- **Accurate Temperature Control:** Heats to a temperature closest to breast milk.
- **Material Selection:** Compatible with various bottle types including plastic, silicone, and glass.



Figure 1: Momcozy Bottle Warmer with its packaging.



Figure 2: The control panel highlighting the 10-in-1 multifunctionality.

### 3. SETUP

Before first use, ensure all components are clean. Refer to the 'Maintenance and Cleaning' section for initial cleaning instructions.

#### Initial Preparation

1. Place the main unit on a flat, stable, and heat-resistant surface.
2. Ensure the power cord is securely plugged into a suitable electrical outlet.
3. Insert the bottle basket into the main unit.

### 4. OPERATING INSTRUCTIONS

The Momcozy Bottle Warmer offers various modes for different warming needs. The device features a touch-sensitive control panel for easy operation.

#### General Steps for Warming

1. Add the appropriate amount of water to the heating chamber (typically 40ml for warming modes, or to the milk level for thawing).
2. Place the bottle containing milk or food into the bottle basket.
3. Cover the unit with the lid.
4. Press the power button to turn on the device.
5. Select the desired working mode (Cold, Normal, Thaw, Steam, Food).
6. Select the bottle material (Plastic, Silica, Glass) and the milk volume (ounces).
7. Press the start button to begin warming. The device will beep three times when warming is complete.

### Specific Warming Modes

- **Warming Cold Bottle (Refrigerator 39-43°F / 4-6°C):**Add 40ml water using the measuring cup. Select 'Cold' mode, then choose bottle material and milk volume.
- **Warming Room Temperature Bottle (68-77°F / 20-25°C):**Add 40ml water using the measuring cup. Select 'Normal' mode, then choose bottle material and milk volume.
- **Defrosting/Frozen Milk (-0.4-32°F / -18-0°C) & 24H Constant Warming:**Fill the warmer with water to reach the level of the milk. Select 'Thaw' mode, then choose bottle/bag material and milk volume. The device will automatically thaw and then maintain the temperature for up to 24 hours.
- **Steaming:** The device can sterilize bottles and baby food jars. Fill the heating chamber with water (refer to specific instructions for water level for sterilization). Select 'Steam' mode.
- **Food Heating:** Place baby food jar in the basket. Add water to the heating chamber. Select 'Food' mode.

# Warm Milk in Just 2-5 Mins

Time saver, get ready for feedings



Figure 3: Fast warming capability of the Momcozy Bottle Warmer.

# One Touch Thawing

Easily keep all the nutrients while thawing



Figure 4: One-touch thawing function for breastmilk.

Video 1: This video demonstrates important precautions and usage tips for the Momcozy Bottle Warmer.

## 5. MAINTENANCE AND CLEANING

Regular cleaning is essential to maintain the hygiene and performance of your Momcozy Bottle Warmer.

### Daily Cleaning

- Unplug the appliance and allow it to cool completely before cleaning.
- Discard any remaining water from the heating chamber.
- Wipe the exterior of the main unit with a damp cloth. Do not use abrasive cleaners.
- The bottle basket and lid are dishwasher safe. Hand wash with mild soap and water if preferred.

### Descaling (Monthly or as needed)

Mineral deposits can build up on the heating plate over time. Descaling helps maintain efficiency.

1. Ensure the unit is unplugged and cool.
2. Add 40ml of white vinegar and 40ml of water to the heating chamber.

3. Plug in the unit and select 'Steam' mode. Allow the cycle to complete.
4. After the cycle, unplug and let it cool. Rinse the heating chamber thoroughly with clean water.



Figure 5: Visual guide for cleaning the Momcozy Bottle Warmer.

## 6. TROUBLESHOOTING

If you encounter any issues with your Momcozy Bottle Warmer, refer to the following common problems and solutions.

Problem	Possible Cause	Solution
Device not turning on	Not plugged in; Power outlet issue	Ensure power cord is securely plugged in; Try a different outlet.
Milk not warming or inconsistent temperature	Insufficient water; Incorrect settings; Mineral buildup	Add correct amount of water; Verify selected mode, material, and ounces; Descale the heating plate.
Device beeps continuously	Water shortage; Cycle complete	Add water if heating; Remove bottle if cycle is complete.

If the problem persists after trying these solutions, please contact Momcozy customer support.

## 7. SPECIFICATIONS

- **Product Dimensions:** 4.53 x 4.53 x 10.43 inches
- **Item Model Number:** MW01
- **Target Gender:** Unisex
- **Batteries Required:** No
- **Dishwasher Safe (Accessories):** Yes
- **Item Weight:** 11 ounces

## 8. WARRANTY AND SUPPORT

For warranty information and customer support, please refer to the official Momcozy website or contact their customer service directly. Keep your purchase receipt for any warranty claims.

---