

[Manuals.plus](#) /

› [AGARO](#) /

› AGARO Signify Handheld Garment Steamer Instruction Manual - Model 33654

AGARO 33654

AGARO Signify Handheld Garment Steamer Instruction Manual

Model: 33654

[Introduction](#)

[Safety Instructions](#)

[Product Components](#)

[Setup](#)

[Operating Instructions](#)

[Maintenance](#)

[Troubleshooting](#)

[Specifications](#)

[Warranty & Support](#)

1. INTRODUCTION

The AGARO Signify Handheld Garment Steamer is designed for efficient and quick wrinkle removal from various fabrics. This manual provides essential information for safe operation, setup, maintenance, and troubleshooting to ensure optimal performance and longevity of your appliance.

Primary Features



Figure 1: AGARO Signify Handheld Garment Steamer. This image shows the overall design of the steamer, highlighting its compact and ergonomic form factor.

2. IMPORTANT SAFETY INSTRUCTIONS

Please read all safety instructions carefully before using the appliance to prevent injury or damage.

- Always use **purified water** in the water tank to prevent mineral buildup and ensure optimal performance.
- Do not fill the water tank above the **MAX level** indicated.
- After plugging in the steamer, wait approximately **45 seconds** for it to heat up before pressing the steam button.
- The steamer is equipped with **Dry Boiling Protection** and an **auto cut-off feature** for overheating protection. The machine will automatically turn off if the water level is too low or if there is no water in the tank.
- For safety, this 1500W appliance requires a **16A plug**. Ensure your power outlet is compatible.
- Exercise caution when handling the steamer, especially the steam plate, as it becomes very hot. Use the provided **heat protective gloves** to prevent burns.

- Keep the appliance out of reach of children and pets.
- Do not immerse the steamer in water or other liquids.



Figure 2: Important tips for using the steamer, including water type, fill level, and heat-up time.

3. PRODUCT COMPONENTS

Familiarize yourself with the parts of your AGARO Signify Handheld Garment Steamer:

- **Ceramic Coated Steam Plate:** Ensures even heat distribution and fast heating.
- **Power / Steam Button:** Activates and controls steam output.
- **LED Power Indicator:** Shows the operational status of the steamer.
- **Water Tank Opening Button:** Releases the detachable water tank.
- **260 ml Removable Water Tank:** Holds water for steaming.
- **1.8-meter Power Cord:** Provides ample reach for use.
- **Detachable Fabric Brush:** Ideal for normal clothes, occasion wear, heavily layered or pleated attires.
- **Detachable Lint Brush:** Perfect for jackets and blazers, helps remove lint and dust.
- **Heat Protective Gloves:** For safe handling during operation.

Tips & Tricks



Use purified water only



Don't fill above MAX level



Wait 45 seconds after plugging in before pressing the steam button



To achieve better ironing, ensure the fabric is pulled smoothly

Figure 3: The steamer shown with its detachable fabric brush, lint brush, and heat protective gloves.

4. SETUP

1. **Fill the Water Tank:** Detach the 260 ml water tank by pressing the water tank opening button. Fill it with purified water up to the MAX level. Reattach the tank securely.
2. **Attach the Desired Brush:** Depending on your fabric, attach either the fabric brush or the lint brush to the steam plate. Ensure it clicks into place.
3. **Connect to Power:** Plug the 1.8-meter power cord into a compatible 16A power outlet. The LED power indicator will light up.
4. **Pre-heating:** Allow the steamer to pre-heat for approximately 40-45 seconds until it is ready to produce steam.

Suitable for a **Wide Range** of **Fabrics**



Note: Not suitable for starch fabric



Figure 4: Demonstrates the process of detaching and filling the water tank with purified water.

5. OPERATING INSTRUCTIONS

The AGARO Signify steamer is versatile, allowing for both vertical and horizontal steaming.

5.1. Steaming Process

1. Once the steamer is pre-heated (after 40-45 seconds), press the power/steam button to release steam.
2. Hold the garment taut with one hand (using a heat protective glove) and move the steamer slowly over the fabric with the other hand.
3. For best results, ensure the fabric is pulled smoothly to allow the steam to penetrate effectively and remove wrinkles.
4. The steamer provides up to **15 minutes of continuous steam** with a full 260 ml water tank, releasing **25g/min** of steam.

5.2. Suitable Fabrics

This steamer is ideal for a wide range of fabrics and garments, including:

- Delicate clothes that are difficult to iron.
- Heavily embroidered garments.
- Versatile designer wear and occasion-wear.
- Heavily layered or pleated attires.
- Jackets, coats, and blazers.
- Common fabrics like Nylon, Silk, Linen, Wool, and Cotton.

Note: Not suitable for starch fabric or heavily starched cotton fabric.

A Garment Steamer is not an IRON


 Garment Steamer	 Iron
Ideal on delicate clothes which are difficult to iron	Ideal for perfectly crisp look
Cannot be used on starched cotton fabric	Ideal on starched cotton fabric
Quickly de wrinkling, no board required	Longer ironing session required with ironing board
For daily outfit, 3-5 garments at a time, smaller water tank	For bigger pile of clothes-bigger water tank
Light & compact-suitable for travelling	Large and heavy-perfect for home

Figure 5: The steamer being used to remove wrinkles from a hanging garment.

Easy to hold, Easy to use

Effortless Steaming With One Touch



Figure 6: Visual representation of various fabric types suitable for steaming with the AGARO Signify.

5.3. Steamer vs. Traditional Iron

It is important to understand that a garment steamer is not a direct replacement for a traditional iron. Each has its specific advantages:

Feature	Garment Steamer	Traditional Iron
Fabric Suitability	Ideal for delicate clothes, heavily embroidered, layered, or pleated attires.	Ideal for perfectly crisp look on starched cotton fabric.
Board Requirement	Quick de-wrinkling, no board required.	Longer ironing session required with ironing board.
Usage Volume	For daily outfits, 3-5 garments at a time, smaller water tank.	For bigger pile of clothes, bigger water tank.
Portability	Light & compact, suitable for traveling.	Large and heavy, perfect for home.



Figure 7: A visual comparison highlighting the differences and ideal uses for a garment steamer versus a traditional iron.

6. MAINTENANCE

Proper maintenance ensures the longevity and efficiency of your steamer:

- **Empty Water Tank:** After each use, always empty any remaining water from the tank.
- **Cleaning:** Wipe the exterior of the steamer with a soft, damp cloth. Do not use abrasive cleaners.
- **Descaling:** If you notice reduced steam output or mineral residue, descale the steamer according to the instructions provided in the full product manual (if available). Using purified water helps minimize descaling needs.
- **Storage:** Store the steamer in a cool, dry place, away from direct sunlight and moisture.

7. TROUBLESHOOTING

Here are solutions to common issues you might encounter:

- **No Steam:**
 - Check if the water tank is filled with water. The steamer has dry boiling protection and will not operate without sufficient water.
 - Ensure the steamer is properly plugged into a 16A power outlet.
 - Allow adequate pre-heating time (40-45 seconds).
- **Steamer Turns Off Automatically:**
 - This is a safety feature (overheating protection). It indicates low water level or no water in the tank. Refill the water tank.
- **Water Dripping from Steam Plate:**

- Ensure the steamer has fully pre-heated before use.
- Avoid tilting the steamer too much during vertical steaming.

8. SPECIFICATIONS

Feature	Detail
Brand	AGARO
Model Number	33654
Colour	Blue
Product Dimensions	15.2L x 10.2W x 25.4H Centimeters
Item Weight	1000 Grams (1 kg)
Style	Handheld
Wattage	1500 Watts
Voltage	230 Volts
Heat Time	40 Seconds
Product Benefits	Efficient Wrinkle Removal, Fabric Safety, Convenient and Portable Design
Water Tank Capacity	260 Milliliters
Steam Output	25g/min
Continuous Steam Time	15 minutes
Included Components	Lint Brush, Fabric brush

9. WARRANTY & SUPPORT

The AGARO Signify Handheld Garment Steamer comes with a **1-year standard brand warranty**. For any product-related queries, issues, or to claim warranty, please contact AGARO customer support.

Extended warranty plans may also be available for purchase, offering additional coverage beyond the standard warranty period.

10. PRODUCT VIDEOS

AGARO Signify Handheld Garment Steamer Overview

Your browser does not support the video tag.

Video 1: A brief overview of the AGARO Signify Handheld Garment Steamer, showcasing its key features and quick operation. This video is a short preview from the seller.

AGARO Signify Handheld Garment Steamer in Action

Your browser does not support the video tag.

Video 2: This video demonstrates the AGARO Signify Handheld Garment Steamer being used on various garments, highlighting its ease of use and wrinkle-removing capabilities. This video is a short preview from the seller.

