

[Manuals.plus](#) /

> [Sanag](#) /

> Sanag M13S Portable Bluetooth Speaker Instruction Manual

Sanag M13S

Sanag M13S Portable Bluetooth Speaker Instruction Manual

Model: M13S

PRODUCT OVERVIEW

The Sanag M13S is an ultra-portable Bluetooth speaker designed for high-quality audio on the go. It features dynamic RGB lighting, robust waterproofing, and extended battery life, making it suitable for various environments.



Image: Sanag M13S Portable Bluetooth Speaker in black with orange accents.

WHAT'S IN THE BOX

- RGB Portable Bluetooth Speaker
- Type-C Charging Cable
- Aux Cable
- User Manual

SETUP

1. Charging the Speaker

Before first use, fully charge the speaker. Connect the provided Type-C charging cable to the speaker's charging port and a suitable USB power source. The charging indicator light will illuminate red while charging and turn green when fully charged.

2. Powering On/Off

To power on the speaker, press and hold the power button (located in the middle of the control panel) for a

few seconds until you hear an audible prompt and the RGB lights activate. To power off, press and hold the power button again.

3. Bluetooth Pairing

When powered on, the speaker will automatically enter Bluetooth pairing mode, indicated by a blinking blue light. On your device (smartphone, tablet, etc.), enable Bluetooth and search for "Sanag M13S". Select it to connect. A successful connection will be confirmed by an audible prompt and a solid blue light.

4. TF Card Mode

Insert a TF (MicroSD) card with pre-loaded music into the designated slot. The speaker will automatically switch to TF card mode. Double-click the power button to switch between TF card mode and Bluetooth mode.

OPERATING INSTRUCTIONS

1. Volume Control

Press the '+' button to increase the volume. Press the '-' button to decrease the volume. An audible prompt will indicate maximum volume.

2. Music Playback

In Bluetooth mode, use the central power button to play or pause music. To skip to the next song, long press the '+' button for 2 seconds. To go to the previous song, long press the '-' button for 2 seconds.




Image: Diagram illustrating the internal components of the Sanag M13S speaker, highlighting its polymer diaphragm, acoustic cavity, voice enhance technology, and Bluetooth 5.1 connection for Hi-Fi sound, shocked bass, and 360° stereo sound.

3. RGB Light Modes

The speaker features ambient RGB lighting with multiple modes. Press the power button three times to switch between different light modes:

- **Gradient Mode:** The lights slowly fade between various colors, syncing with the music.
- **Flowing Mode:** The light display changes brightness according to the size of the music.
- **No Indicator Mode:** The light goes out and does not display.



Image: Five Sanag M13S speakers in different colors (red, blue, orange, green, purple) showcasing their RGB light effects, labeled as 'RGB Light Show: Breathing light & Pulsing light'.

4. Hands-Free Calling

The built-in noise-cancelling microphone allows for clear hands-free calls. Press the power button once to answer or end a call.



Image: A person in a car holding a Sanag M13S speaker, with text 'Clear Call: Enjoy crystal clear calls from your speaker with noise-cancelling microphone'.

MAINTENANCE

1. Waterproofing

The Sanag M13S speaker is IPX7 waterproof, meaning it can be submerged in up to 1 meter of water for 30 minutes. Ensure the charging port and TF card slot cover is securely closed before exposing the speaker to water.




Image: A red Sanag M13S speaker partially submerged in clear blue water, with text 'IPX7 TRUE WATERPROOF: A speaker that can breathe underwater'.

2. General Care

Clean the speaker with a soft, damp cloth. Avoid using harsh chemicals or abrasive materials. Store in a cool, dry place when not in use.

TROUBLESHOOTING

- **No Power:** Ensure the speaker is fully charged.
- **Cannot Pair:** Make sure the speaker is in pairing mode (blinking blue light) and within range of your device. Disconnect from other Bluetooth devices if necessary.
- **No Sound:** Check the volume levels on both the speaker and your connected device. Ensure the speaker is correctly paired.
- **Muffled Sound after Water Exposure:** Allow the speaker to dry completely. The sound quality should return to normal once dry.

SPECIFICATIONS

Feature	Specification
Brand	Sanag

Model Name	Sanag M13S
Model Number	JP-M13S
Connectivity Technology	Bluetooth 5.3
Speaker Maximum Output Power	10 Watts
Audio Output Mode	Stereo
Speaker Type	Subwoofer
Water Resistance Level	IPX7 Waterproof
Playtime	Up to 18 Hours
Item Weight	7.68 ounces
Item Dimensions (D x W x H)	3.8"D x 3.03"W x 1.6"H
Power Source	Battery Powered (1 Lithium Polymer battery included)
Additional Features	Portable, Built-in Microphone, RGB Lighting

OFFICIAL PRODUCT VIDEO

Your browser does not support the video tag.

Video: An official product video showcasing the Sanag portable Bluetooth speaker with its RGB light features in various usage scenarios.

WARRANTY & SUPPORT

Sanag is committed to your satisfaction. We provide a 30-day no-reason return policy and a 180-day warranty for this product. If you encounter any problems, please contact us promptly.

Contact Options:

1. [Account Service] - [Order History] - [Seller Contact]
2. Click our business name "NIEWEILI-US" and then click the yellow "Questions" button to send us an email.