

[Manuals.plus](#) /

› [SANODESK](#) /

› SANODESK Electric Standing Desk 48x24 Inch Instruction Manual

SANODESK 156E

SANODESK Electric Standing Desk 48x24 Inch Instruction Manual

Model: 156E

1. INTRODUCTION

Thank you for choosing the SANODESK Electric Standing Desk. This manual provides essential information for the safe assembly, operation, and maintenance of your new desk. Please read these instructions carefully before use and retain them for future reference.



Image: The SANODESK Electric Standing Desk in a home office environment, showcasing its design and functionality for both sitting and standing work.

2. SAFETY INFORMATION

- **Weight Limit:** Do not exceed the maximum weight capacity of **132 pounds (60 kg)** on the desktop.
- **Stability:** Ensure the desk is placed on a level surface and is stable before use. Keep objects balanced on the desktop to avoid tipping.
- **Assembly:** Assembly requires two people. Do not attempt to assemble alone.
- **Power:** Use only the provided power adapter. Keep cables tidy to prevent tripping hazards.
- **Children and Pets:** Keep children and pets away from the desk during operation to prevent injury.
- **Maintenance:** Do not attempt to disassemble or repair the motor or control system yourself. Contact customer support for assistance.

3. PACKAGE CONTENTS

Before assembly, verify that all components are present and undamaged. If any parts are missing or damaged, please contact customer service.

- Desktop (48" x 24")
- Desk Frame (Legs and Crossbar)
- Electric Lifting System Motor
- 6-Button Control Panel
- Power Adapter and Cable
- Assembly Hardware (screws, bolts, etc.)
- Keyboard Tray (optional accessory, may be included)
- Headphone Hook (optional accessory, may be included)
- Instruction Manual

4. SETUP AND ASSEMBLY

Assembly of the SANODESK Electric Standing Desk requires two individuals. While some tools are included, a drill may be beneficial for certain steps. Follow the detailed assembly instructions provided in the separate assembly guide included with your product. Ensure all connections are secure before powering on the desk.

| One-Piece Desk

Spacious and neat desk surface



Image: A top-down view highlighting the spacious, one-piece desktop design, which simplifies assembly and provides a stable work surface.

5. OPERATING INSTRUCTIONS

5.1. Height Adjustment

The desk features an electric lifting system allowing for smooth height adjustments between **29.5 inches (75 cm)** and

43.3 inches (110 cm). Use the Up (▲) and Down (▼) buttons on the control panel to adjust the desk to your desired height.



Image: A visual representation of the desk's adjustable height range, illustrating the minimum and maximum operational heights.

5.2. Memory Presets

The 6-button control panel includes four memory preset buttons (1, 2, 3, 4) to store and recall your preferred sitting and standing heights.

1. To Set a Memory Preset:

- Adjust the desk to your desired height using the Up/Down buttons.
- Press and hold one of the memory buttons (1, 2, 3, or 4) until the display flashes or a beep is heard, indicating the height has been saved.

2. To Recall a Memory Preset:

- Press the corresponding memory button (1, 2, 3, or 4) once. The desk will automatically move to the saved height.



Intelligent Keyboard

Four memory height adjustment buttons

Image: A detailed view of the intelligent control panel, showing the LED display and the four programmable memory buttons for convenient height adjustments.

The electric lifting system operates quietly, ensuring minimal disruption in your workspace.

Glide Smoothly, Whisper Quietly

Effortless & whisper-quiet
height adjustment



Image: This graphic highlights the desk's quiet operation, indicating a noise level below 50dB, comparable to a whisper, for an undisturbed work environment.

6. MAINTENANCE

To ensure the longevity and optimal performance of your SANODESK Electric Standing Desk, follow these maintenance guidelines:

- **Cleaning:** The desktop and frame surfaces are waterproof and rustproof. Wipe surfaces with a soft, damp cloth and mild detergent. Avoid abrasive cleaners or solvents.
- **Inspection:** Periodically check all screws and bolts to ensure they are tight. Retighten if necessary.
- **Cable Management:** Keep all cables organized and free from entanglement to prevent damage to the motor or control system.
- **Weight Distribution:** Distribute weight evenly across the desktop to prevent strain on the lifting mechanism.




Image: A close-up view of the desk's high-quality wood desktop, highlighting its thick, waterproof, and eco-friendly properties, which

7. TROUBLESHOOTING

If you encounter any issues with your SANODESK Electric Standing Desk, please refer to the following common solutions or contact customer support.

- **Desk Not Moving:**
 - Check if the power cable is securely connected to both the desk and the power outlet.
 - Ensure no obstructions are blocking the desk's movement.
- **Error Code on Display:**
 - If an error code appears, try unplugging the desk from the power outlet for 10-15 seconds, then plug it back in. This often resets the system.
 - If the error persists, contact customer support with the specific error code displayed.
- **Uneven Movement:**
 - Ensure the desk is not overloaded and weight is evenly distributed.
 - Check that all assembly screws are tightened.

8. SPECIFICATIONS

Product Size




Image: A clear diagram illustrating the primary dimensions of the desk, 48 inches in width and 24 inches in depth.

Feature	Detail
Brand	SANODESK
Model Name	156E
Product Dimensions (D x W x H)	24"D x 48"W x 28.6"H

Feature	Detail
Adjustable Height Range	29.5" - 43.3"
Color	White Frame + White Top
Style	Modern
Base Material	Alloy Steel
Top Material Type	Wood
Finish Type	Wood
Special Feature	Adjustable, Electric
Included Components	Desk, Keyboard Tray, Headphone Hook
Item Weight	55 Pounds
Maximum Weight Recommendation	132 Pounds
Required Assembly	Yes
Recommended Number of People for Assembly	2
Warranty Type	Limited

9. WARRANTY AND SUPPORT

Your SANODESK Electric Standing Desk comes with a limited warranty. For specific warranty details, please refer to the documentation included with your purchase.

We offer a **30-day return or exchange service** if you encounter any problems upon receiving or using the product. For assistance, please contact customer service through your order page on Amazon. Our team is ready to provide support and resolve any issues you may have.

For further inquiries or support, please visit the [SANODESK Store on Amazon](#).

© 2023 SANODESK. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for

conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question