Manuals+

Q & A | Deep Search | Upload

manuals.plus /

- OHLUX /
- > OHLUX Floor Lamp MF18228 User Manual

OHLUX MF18228

OHLUX Floor Lamp MF18228 User Manual

Model: MF18228

INTRODUCTION

This manual provides detailed instructions for the safe and efficient use of your OHLUX MF18228 LED Floor Lamp. This modern torchiere lamp features 36W/3000LM brightness, 5 adjustable color temperatures, and convenient remote and touch controls. Please read this manual thoroughly before installation and operation, and retain it for future reference.

SAFETY INSTRUCTIONS

- Ensure the power supply voltage matches the lamp's requirements (110V).
- This product is designed for indoor use only. Do not expose to water or high humidity.
- Do not attempt to disassemble or modify the lamp. There are no user-serviceable parts inside.
- · Keep the lamp away from heat sources and direct sunlight.
- Always unplug the lamp from the power outlet before cleaning or performing any maintenance.
- Ensure the lamp is placed on a stable, level surface to prevent tipping. The weighted base is designed for stability.
- Keep the remote control and its batteries out of reach of children.

PACKAGE CONTENTS

Verify that all components are present before assembly:

- · LED Lamp Head
- Lamp Pole Sections (typically 3-4 sections)
- · Weighted Base
- · Power Adapter/Cord

- Remote Control (AAA batteries not included)
- User Manual

SETUP AND ASSEMBLY

Follow these steps to assemble your OHLUX Floor Lamp:

- 1. Attach the Base: Carefully screw the lowest pole section into the weighted base until secure.
- 2. **Assemble the Pole:** Connect the remaining pole sections by screwing them clockwise. Ensure each section is tightly fastened to prevent wobbling.
- 3. **Attach the Lamp Head:** Screw the lamp head onto the top pole section. Ensure the power cord passes freely through the pole.
- 4. Connect Power: Plug the power cord into a standard 110V AC outlet.
- 5. **Install Remote Batteries:** Open the battery compartment on the back of the remote control and insert two AAA batteries (not included), observing polarity.



Figure 1: Exploded view and features of the OHLUX Floor Lamp, highlighting its stable base, 360-degree rotation, and remote

control.



Figure 2: Dimensions of the OHLUX Floor Lamp, illustrating its 69-inch height and stable base.

OPERATING INSTRUCTIONS

Your OHLUX Floor Lamp can be controlled via the included remote control or the touch buttons located on the lamp

Remote Control Functions




Figure 3: Remote control and touch control buttons on the OHLUX Floor Lamp.

- Power Button: Turns the lamp On or Off.
- Color Temperature Buttons (CCT+ / CCT-): Adjusts the color temperature steplessly from 2700K (warm white)

to 6500K (cool white).

- Brightness Buttons (+ / -): Adjusts the brightness steplessly from 10% to 100%.
- Night Light Button: Activates a preset low brightness, warm color temperature mode suitable for sleeping environments.
- Magnetic Attachment: The remote can be conveniently attached to the lamp pole or any metal surface.



Figure 4: Stepless color temperature adjustment from warm white (2700K) to cool white (6500K).



Figure 5: Demonstration of brightness levels from 5% to 100%.

Touch Control Functions



Figure 6: Detailed view of the sensitive touch control buttons on the lamp pole.

- On/Off/Short Press: A short press cycles through 4 preset color temperatures (e.g., 2700K, 4000K, 5000K, 6500K).
- Long Touch (Color Temperature): Press and hold to steplessly adjust the color temperature from 2700K to 6500K.
- **Short Touch (Brightness):** A short press cycles through 4 preset brightness levels (e.g., 25%, 50%, 75%, 100%).
- Long Touch (Brightness): Press and hold to steplessly adjust the brightness from 10% to 100%.

Memory Function

The lamp features a memory function that remembers your last brightness and color temperature settings. These settings are retained even after the lamp is turned off via the wall switch or in case of a power outage, saving you from frequent adjustments.



Figure 7: The lamp's memory function retains your preferred light settings.

Night Light Mode

Activate the dedicated night light mode via the remote control for a soft, low-intensity light, ideal for nighttime use without disturbing sleep.



Figure 8: Night light mode provides gentle illumination for a peaceful environment.

MAINTENANCE

- Cleaning: Ensure the lamp is unplugged before cleaning. Use a soft, dry cloth to wipe the lamp's surface. Do not use abrasive cleaners, solvents, or harsh chemicals, as these may damage the finish.
- **LED Light Source:** The LED light source is integrated and not user-replaceable. Do not attempt to replace the LEDs.
- **Remote Control:** Replace AAA batteries in the remote control when its range decreases or it becomes unresponsive.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Lamp does not turn on.	No power, loose connection, remote batteries dead.	Check if the power cord is securely plugged in. Ensure the wall outlet is functional. Replace remote control batteries.
Remote control is unresponsive.	Dead batteries, remote too far, interference.	Replace remote batteries. Ensure you are within the 50ft (15m) range. Remove any obstructions between the remote and the lamp.
Lamp flickers or dims unexpectedly.	Unstable power supply, internal issue.	Try plugging the lamp into a different outlet. If the problem persists, contact customer support.
Cannot adjust brightness or color temperature.	Remote issue, touch control issue.	Ensure remote batteries are fresh. Try using the touch controls on the lamp pole. If both fail, contact customer support.

SPECIFICATIONS

Feature	Specification	
Model Number	MF18228	
Brand	OHLUX	
Power Source	Corded Electric	
Voltage	110 Volts	
Wattage	36 Watts	
Brightness	3000 Lumens	
Color Temperature	2700K - 6500K (Stepless Adjustable)	
Color Rendering Index (CRI)	85.00	

Feature	Specification	
Control Method	Remote, Touch	
Product Dimensions	9.8"D x 9.8"W x 69"H (24.9cm D x 24.9cm W x 175.3cm H)	
Item Weight	7.7 pounds (3.5 Kilograms)	
Material	Powdered Metal Steel	
Finish Type	Powder Coated	
Lamp Type	LED	
Indoor/Outdoor Usage	Indoor	
Special Features	Extended Cord, Improved Cooling System, Smooth Bright Dimmable, Smooth Color Temperature Dimmable, Super Bright	

WARRANTY INFORMATION

Specific warranty details for the OHLUX MF18228 Floor Lamp are not provided in the product description. For information regarding warranty coverage and terms, please contact OHLUX customer support directly.

CUSTOMER SUPPORT

For technical assistance, service inquiries, or any questions regarding your OHLUX Floor Lamp, please contact OHLUX customer support. The manufacturer aims to reply within 24 hours to ensure customer satisfaction. Please refer to the official OHLUX website or your purchase documentation for the most current contact methods.

© 2023 OHLUX. All rights reserved.

Related Documents - MF18228

OHLUX Smart LED Bulb FAQ: Common Questions and Answers

Find answers to frequently asked questions about OHLUX Smart LED Bulbs, covering compatibility, setup, features, and troubleshooting. Learn about Wi-Fi requirements, voice assistant integration, and more.



OHLUX Smart LED Bulb User Manual and Setup Guide

Comprehensive user manual for the OHLUX Smart LED Bulb. Learn how to download and install the Smart Life app, register, connect to Wi-Fi, control the bulb, and integrate with Amazon Alexa, Google Home, and Siri for smart home automation.



POVISON MF18228 LED Floor Lamp User Manual

User manual for the POVISON MF18228 LED Floor Lamp, detailing installation, specifications, product care, and remote control functions. Includes FCC statement.



Outon Smart Floor Lamp MF18228: Setup, Control, and Specifications

Comprehensive guide for the Outon Smart Floor Lamp MF18228, covering installation, remote control functions, app setup, and technical specifications. Learn how to assemble, connect, and control your smart lamp for a brighter, more colorful home.