Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

JVC HA-Z66T-W-E

JVC Gumy Mini True Wireless Earbuds User Manual

Model: HA-Z66T-W-E

Product Overview

The JVC HA-Z66T Gumy Mini True Wireless Earbuds are designed for a comfortable and high-quality audio experience. As the successor to the Z55T model, the HA-Z66T offers improved battery life and additional features like multiple sound modes. These lightweight and compact earbuds deliver powerful sound, making them ideal for daily use, music listening, and calls.



The JVC Gumy Mini True Wireless Earbuds in white, showcasing their compact and sleek design.



The earbuds are small and ultra-lightweight, weighing only 3.8g each, ensuring comfort during extended wear.

Key Features:

- **Gumy Mini Design:** Weighing only 3.8g, these earbuds offer a lightweight feel even during prolonged use. The compact charging case is convenient for portability.
- **High-Quality Sound:** Despite their small size, the neodymium magnet speaker delivers high-quality audio reproduction.
- **3 Sound Modes / Touch Control:** Choose from Normal, Bass, or Clear sound modes with simple touch operations on the earbuds.
- **Long Battery Life:** Enjoy a total of 23 hours of playback with the built-in earbud battery (7.5 hours) and the charging case (15.5 hours).
- **Water Resistance:** Featuring IPX4 water resistance, these earbuds are protected against splashes from any direction, making them suitable for workouts and outdoor activities.

Setup Guide

1. Charging the Earbuds and Case

Before first use, fully charge the earbuds and the charging case. Place the earbuds into the charging case. Connect the charging case to a USB power source using the provided USB cable. The indicator lights on the case will show the charging status.

- **Earbuds:** Approximately 7.5 hours of playback on a full charge.
- **Charging Case:** Provides an additional 15.5 hours of charge, for a total of 23 hours.

2. Initial Pairing (Bluetooth)


1. **Power On:** Open the charging case. The earbuds will automatically power on and enter pairing mode. You will hear an audible prompt.
2. **Activate Bluetooth:** On your device (smartphone, tablet, etc.), enable Bluetooth.
3. **Select Device:** In your device's Bluetooth settings, look for "JVC HA-Z66T" in the list of available devices and select it.
4. **Confirm Connection:** Once connected, you will hear a confirmation tone from the earbuds. The earbuds are now ready for use.

Note: The earbuds will automatically reconnect to the last paired device when removed from the case, if Bluetooth is enabled on the device.

Operating Instructions

Touch Controls

The JVC Gumy Mini earbuds feature intuitive touch controls on each earbud. A fingerprint icon on the image below indicates the touch sensor area.



The touch sensor area on the earbuds allows for easy control of various functions.

Earbud Touch Control Functions

Action	Function
Single Tap (Left/Right)	Play/Pause music, Answer/End call
Double Tap (Right)	Next Track
Double Tap (Left)	Previous Track
Triple Tap (Left/Right)	Activate Voice Assistant
Long Press (Left/Right)	Cycle through Sound Modes (Normal, Bass, Clear)
Incoming Call (Long Press)	Reject Call

Sound Modes

The earbuds offer three distinct sound modes to enhance your listening experience:



Easily switch between Normal, Bass, and Clear sound modes to suit your audio preference.

- **Normal:** Balanced sound profile suitable for most audio content.
- **Bass:** Enhanced bass for a richer, more impactful low-end sound.
- **Clear:** Optimized for vocal clarity, ideal for podcasts and audiobooks.

To switch between modes, perform a long press on either earbud's touch sensor until you hear the mode change confirmation.

Maintenance

Cleaning Your Earbuds

To ensure optimal performance and hygiene, regularly clean your earbuds and charging case. Use a soft, dry, lint-free cloth to wipe down the surfaces. For stubborn dirt, slightly dampen the cloth with water. Avoid using harsh chemicals or abrasive materials.

Water Resistance (IPX4)

The HA-Z66T earbuds are rated IPX4, meaning they are resistant to splashing water from any direction. This makes them suitable for light rain or sweaty workouts. However, they are not designed for submersion in water or exposure to pressurized water jets. Do not wear them while swimming or showering.



The IPX4 rating ensures the earbuds are sweat-proof and resistant to splashes, ideal for active use.

Troubleshooting

If you encounter issues with your JVC Gumy Mini earbuds, please refer to the following common solutions:

- **No Sound:**
  - Ensure earbuds are charged.
  - Check if Bluetooth is enabled on your device and connected to "JVC HA-Z66T".
  - Adjust volume on both your device and the earbuds.
  - Try playing different audio content.
- **Earbuds Not Pairing:**
  - Ensure earbuds are in pairing mode (out of case, indicator lights flashing).
  - Turn off and on Bluetooth on your device.
  - Forget "JVC HA-Z66T" from your device's Bluetooth list and try pairing again.
  - Ensure earbuds are fully charged.
  - Move closer to your device; avoid obstacles.
- **One Earbud Not Working:**
  - Place both earbuds back into the charging case, close the lid, wait a few seconds, then take them out again.
  - Ensure both earbuds are charged.
  - Try resetting the earbuds (refer to manufacturer's website for specific reset instructions if needed).
- **Charging Issues:**
  - Ensure the charging cable is securely connected to both the case and the power source.
  - Try a different USB cable or power adapter.
  - Clean the charging contacts on both the earbuds and the case with a dry cotton swab.

Specifications

Feature	Detail
Model Name	HA-Z66T-W-E
Brand	JVC
Connectivity Technology	Wireless (Bluetooth 5.1)
Form Factor	In-Ear
Ear Placement	In-Ear
Color	White
Item Weight	4 Grams (per earbud)
Water Resistance Level	IPX4 (Splash-proof)
Frequency Range	20 Hz - 20,000 Hz
Impedance	16 ohms
Control Type	Touch Control
Battery Life	Up to 7.5 hours (earbuds) + 15.5 hours (charging case) = 23 hours total

Feature	Detail
Special Features	Fast charging, Sweat resistant
Compatible Devices	Bluetooth compatible devices
Included Components	Wireless charging case

Warranty and Support

For detailed warranty information and customer support, please refer to the official JVC website or contact JVC customer service directly. The product typically comes with a manufacturer's warranty covering defects in materials and workmanship.

Return Policy: This product is subject to a 30-day refund/replacement return policy when purchased from Amazon.

For further assistance, please visit the JVC Official Website or consult your local retailer.

© 2024 JVC. All rights reserved. Information subject to change without notice.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0B9C6WQLN

More documents and user manuals: **https://manuals.plus/**