

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Nuby](#) /

› [Nuby Super Quench Spill-Free Water Bottle User Manual](#)

Nuby 048526890491

Nuby Super Quench Spill-Free Water Bottle User Manual

Model: 048526890491

PRODUCT OVERVIEW

The Nuby Super Quench Water Bottle is designed for active children aged 18 months and older, providing a convenient and spill-free hydration solution. This 540 ml capacity bottle features an easy-grip design and a practical carry handle, making it ideal for travel and daily use. Its free-flow, leak-free pop-open soft spout allows for easy drinking, similar to an adult cup, promoting independent hydration.



Image: Two Nuby Super Quench water bottles, featuring a vibrant traffic design. One bottle is teal with a dark blue lid, and the other is blue with a lighter blue lid. Both have a convenient carry handle and a pop-up spout.

Key Features:

- **Free-Flow Spout:** Allows water to flow freely, making it easy for children to drink.
- **Leak-Free Design:** Engineered to prevent spills and leaks, ensuring a mess-free experience.
- **Durable & Bite-Resistant:** The spout is designed to withstand biting, ensuring longevity.
- **Easy-Grip Handle:** A soft silicone handle makes it simple for small hands to hold.
- **Large Capacity:** 540 ml capacity to keep children hydrated throughout the day.
- **BPA-Free:** Made from safe, non-toxic materials.
- **Easy to Clean:** Dishwasher (top rack) and sterilizer safe for convenient cleaning.

COMPONENTS

Each Nuby Super Quench package contains two (2) complete water bottles. Each bottle consists of the following main components:

- Bottle body (540 ml capacity)
- Lid with integrated pop-open soft spout and carry handle
- Straw (internal)

OPERATING INSTRUCTIONS

1. **Filling the Bottle:** Unscrew the lid from the bottle body. Fill the bottle with your desired liquid (water, juice, etc.). Do not overfill.
2. **Securing the Lid:** Screw the lid back onto the bottle body firmly until it is hand-tight. Ensure the straw is properly aligned inside the bottle.
3. **Opening the Spout:** To drink, simply push the pop-open button on the lid to release the soft spout. The spout will extend, allowing free flow of liquid.
4. **Closing the Spout:** After use, push the spout back down until it clicks securely into place. This ensures the bottle remains leak-free when not in use.
5. **Using the Carry Handle:** The integrated handle is designed for easy carrying by children or attaching to bags.



Image: A young child happily drinking from a Nuby Super Quench water bottle, demonstrating the ease of use of the spout and handle.



Image: A detailed view of the pop-up spout mechanism, highlighting its design for easy access and secure closure.

CLEANING & MAINTENANCE

Proper cleaning and maintenance are essential to ensure the longevity and hygiene of your Nuby Super Quench water bottle.

Cleaning Instructions:

- **Before First Use:** Disassemble all components and wash thoroughly.
- **Daily Cleaning:** After each use, rinse all parts with warm, soapy water. Use a bottle brush for the interior of the bottle and a small brush for the spout and straw to ensure all residue is removed.
- **Dishwasher Safe:** The bottle and its components are safe for cleaning on the **top rack** of a dishwasher.
- **Sterilizer Safe:** For thorough sanitization, the bottle can be used with a sterilizer. Follow the sterilizer manufacturer's instructions.
- **Drying:** Allow all parts to air dry completely before reassembling or storing to prevent mold or mildew growth.

Important Warnings:

- Do not clean or allow the bottle to come into contact with harsh solvents or aggressive chemicals, as this may damage the product.
- Avoid contact with oil-based products or sunscreen, as damage to the decoration or coloration may occur.
- Regularly inspect all components for any signs of wear, tear, or damage. Discard and replace the bottle if any damage is observed.

SPECIFICATIONS

Feature	Detail
Brand	Nuby
Model Number	048526890491
Capacity	540 Milliliters
Material	Polypropylene (PP)

Feature	Detail
Color/Design	Vehicles (Traffic)
Dimensions (L x W x H)	7.5 x 7.5 x 21.5 cm
Item Weight	370 grams
Special Features	Free-flow, Soft silicone handle, Leak-proof, Dishwasher safe, BPA-free
Recommended Age	18 months and up



21.5cm

7.5cm

Image: The Nuby Super Quench water bottle with its approximate dimensions indicated: 21.5 cm in height and 7.5 cm in width.

TROUBLESHOOTING

While the Nuby Super Quench bottle is designed for reliability, here are some common points to check if

you encounter issues:

- **Leaking:**

- Ensure the lid is screwed on tightly and correctly aligned.
- Check that the pop-open spout is fully closed and clicked into place.
- Inspect the silicone seal within the lid and around the spout for any damage or misalignment.
- Verify that the straw is properly inserted and not obstructing the seal.

- **Difficulty Drinking/No Flow:**

- Ensure the spout is fully popped open.
- Check if the straw is clogged or bent. Clean the straw thoroughly.
- Make sure the vent hole (if present on the lid) is not blocked.

- **Odor/Taste:**

- Thoroughly clean all parts as per the "Cleaning & Maintenance" section.
- Ensure the bottle is completely dry before storage.

If problems persist, please contact Nuby customer support for further assistance. Contact information is typically found on the product packaging or the official Nuby website.

WARRANTY AND SUPPORT

Specific warranty details for the Nuby Super Quench water bottle are not provided in the available product data. For information regarding warranty coverage, product support, or to inquire about replacement parts, please refer to the product packaging or visit the official Nuby website. You may also contact Nuby customer service directly through their official channels.

Manufacturer: Nuby UK