

[Manuals.plus](#) /

> [Epson](#) /

> Epson EpiqVision Flex CO-FH02 Full HD 1080p Smart Streaming Portable Projector, 3-Chip 3LCD, 3,000 Lumen Color/White Brightness, Android TV, Bluetooth, 5W Speaker, Home Entertainment

Epson V11HA85020

Epson EpiqVision Flex CO-FH02 Projector User Manual

Full HD 1080p Smart Streaming Portable Projector

INTRODUCTION

The Epson EpiqVision Flex CO-FH02 is a versatile and portable projector designed for both remote work and home entertainment. It delivers a stunning Full HD 1080p picture, capable of projecting images up to 300 inches, which is significantly larger than typical flat-panel displays. Featuring 3,000 lumens of color and white brightness, this projector ensures crisp, colorful images even in well-lit environments. Its compact design allows for easy portability, fitting conveniently into bags and backpacks. The integrated Android TV interface provides access to popular streaming services, and a high-quality built-in speaker enhances the viewing experience. Chromecast is also included for wireless content casting.



Front view of the Epson EpiqVision Flex CO-FH02 Projector, showcasing its compact and sleek design.

WHAT'S IN THE BOX

Upon unboxing your Epson EpiqVision Flex CO-FH02 projector, you should find the following components:

- Epson EpiqVision Flex CO-FH02 projector
- Power cable
- Projector remote control
- Batteries for remote control

- Quick Start Guide
- Android TV Streaming Media Player with remote
- Mini-USB cable for Android TV power
- HDMI cable



An illustration showing all the items included in the Epson EpiqVision Flex CO-FH02 product box, including the projector, cables, remotes, and guides.

SETUP

Setting up your Epson EpiqVision Flex CO-FH02 projector is straightforward. Follow these steps for initial configuration:

1. **Placement:** Position the projector on a stable, flat surface. Ensure there is adequate ventilation around the unit.
2. **Power Connection:** Connect the power cable to the projector and then to a power outlet.
3. **Connect Devices:** Use the provided HDMI cable to connect your laptop, streaming device, or gaming console to the projector's HDMI port. The projector also features a USB port for additional connectivity.

4. **Android TV Setup:** Insert the Android TV Streaming Media Player into its dedicated slot on the projector and connect it using the mini-USB cable for power. Follow the on-screen prompts to connect to your wireless network (5 Mbps or faster recommended) and set up your Google account for smart streaming capabilities.
5. **Power On:** Press the power button on the projector or the remote control to turn on the unit.
6. **Adjust Image:** Use the focus dial on the projector to sharpen the image. The projector also features automatic keystone correction to square the image if the projector is not perfectly aligned with the screen or wall. Manual adjustments can be made via the remote control if needed.



The rear panel of the projector, displaying the HDMI, Service, and DC Out (2.0A) ports for connecting external devices.

OPERATING THE PROJECTOR

The Epson EpiqVision Flex CO-FH02 is designed for ease of use, offering various features for an enhanced viewing experience.

Basic Operation

- **Power On/Off:** Use the power button on the projector or the main remote control.
- **Input Selection:** Switch between HDMI and Android TV inputs using the remote control.
- **Focus and Keystone:** Fine-tune the image clarity with the focus dial and use the keystone correction feature (automatic or manual via remote) to ensure a perfectly rectangular image.
- **Brightness Modes:** Adjust brightness settings (e.g., Eco mode for energy efficiency and extended lamp life) via the remote control.



The remote control for the Epson EpiqVision Flex CO-FH02 projector, showing buttons for power, input, brightness, and image adjustments.

Smart Streaming and Connectivity

With the integrated Android TV and Chromecast, your projector becomes a smart entertainment hub.

- **Android TV:** Access a wide range of streaming applications like Netflix, Apple TV+, Amazon Prime, Hulu, Disney+, HBO Max, and YouTube directly through the Android TV interface. The Android TV remote includes voice search with Google Assistant.
- **Chromecast:** Wirelessly cast content from your smartphone, tablet, or computer directly to the projector.

- **HDMI Connectivity:** Easily connect external devices such as Blu-ray players, gaming consoles, or other streaming devices.
- **Bluetooth:** Connect Bluetooth audio devices for an enhanced sound experience.




A woman relaxing on a couch, watching a movie projected onto a wall by the Epson EpiqVision Flex CO-FH02 projector, demonstrating its home entertainment capabilities.

Versatile Applications


The projector's features make it suitable for various uses:

- **Home Entertainment:** Enjoy movies, TV shows, and sports with a large, immersive display.
- **Gaming:** Connect your gaming console for a big-screen gaming experience.
- **Virtual Meetings & Learning:** Enhance online meetings and educational content with detailed, life-sized images, perfect for Zoom calls or collaborative learning.

In The Box




AAA
Batteries



Android TV
Streaming Stick



Android TV
Remote Control



Quick Setup Guide



Power Supply



Remote control

A child learning to play the guitar with a lesson projected onto the wall by the Epson EpiqVision Flex CO-FH02 projector, highlighting its use in educational settings.

MAINTENANCE

To ensure the longevity and optimal performance of your Epson EpiqVision Flex CO-FH02 projector, follow these maintenance guidelines:

- **Cleaning the Lens:** Gently wipe the projector lens with a soft, lint-free cloth designed for optical surfaces. Avoid using abrasive cleaners.
- **Cleaning the Casing:** Use a soft, dry cloth to clean the exterior casing. For stubborn marks, a slightly damp cloth can be used, but ensure no moisture enters the device.
- **Ventilation:** Ensure the projector's ventilation openings are clear and not obstructed to prevent overheating. Do not place the projector on soft surfaces that might block airflow.
- **Storage:** When not in use for extended periods, store the projector in a cool, dry place, ideally in its original packaging or a protective case.

TROUBLESHOOTING

If you encounter any issues with your projector, refer to the following common troubleshooting tips:

- **No Power:** Ensure the power cable is securely connected to both the projector and a working power outlet. Try a different outlet.
- **No Image:** Check that the correct input source is selected on the projector. Verify that the HDMI cable (if used) is securely connected to both the projector and the source device.
- **Blurry Image:** Adjust the focus dial on the projector. Ensure the projector is placed at an appropriate distance from the projection surface.
- **Image is Crooked/Distorted:** Use the keystone correction feature (automatic or manual via remote) to adjust the image shape.
- **No Sound:** Check the volume level on both the projector and the source device. If using external speakers, ensure they are properly connected and powered on. If using Bluetooth, ensure the device is paired correctly.
- **Android TV Issues:** Ensure the Android TV Streaming Media Player is correctly inserted and powered. Check your wireless network connection.

For more detailed troubleshooting and advanced solutions, please consult the official [User Manual \(PDF\)](#).

SPECIFICATIONS

Feature	Detail
Product Dimensions	8.3 x 12.5 x 3.4 inches
Item Weight	5.7 pounds
Item Model Number	V11HA85020
Brand	Epson
Recommended Uses	Gaming, Home Entertainment, Business Presentations
Special Features	Built-In Speaker, Lightweight, Smart Streaming (Android TV), Chromecast
Connectivity Technology	HDMI, USB, Bluetooth, Wi-Fi
Display Resolution	1920 x 1080 (Full HD)
Brightness	3,000 lumens (Color and White Brightness)
Projection Size	Up to 300 inches

WARRANTY AND SUPPORT

Epson provides support for its products. While specific warranty details may vary by region and retailer, general protection plans are often available for purchase. For detailed warranty information and technical support, please visit the official Epson support website or refer to the documentation included with your product.

For additional assistance and to resolve any queries, you may visit the Epson support portal [Epson Support](#).

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0B9CG7QZK>

More documents and user manuals: <https://manuals.plus/>