

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [CYBORIS](#) /

› [CYBORIS Wireless Bluetooth Headphones User Manual](#)

CYBORIS SM608

CYBORIS Wireless Bluetooth Headphones User Manual

Model: SM608

1. PRODUCT OVERVIEW

The CYBORIS Wireless Bluetooth Headphones (Model SM608) are designed for active lifestyles, featuring IPX8 waterproofing, a built-in 16GB MP3 player, and bone conduction technology. These headphones are suitable for various activities including running, cycling, and swimming.



Image: CYBORIS Wireless Bluetooth Headphones, showcasing their waterproof design with the lower part submerged in water.

2. KEY FEATURES

- **Upgrade Bone Conduction Horn:** Equipped with 10mm nano-composite film for wide dynamic range and enhanced water resistance.
- **Highest IPX8 Waterproof Rating:** Designed for use during swimming, workouts, and other water-related activities.
- **16GB MP3 Mode:** Built-in memory to store over 5000 songs, allowing music playback without a connected device.
- **Bluetooth 5.0 Connectivity:** Provides a stable and fast wireless connection for audio streaming and calls.
- **Long Battery Life:** 250mAh lithium battery offers up to 24 hours of playback time.

New Upgrade

Breakthrough bone conduction dynamic earphone speakers with better waterproof performance.



Image: Diagram illustrating the internal structure of the bone conduction speaker, highlighting the composite diaphragm, noise reduction net, and vibration unit.

3. SETUP AND FIRST USE

3.1. Charging the Headphones

Before first use, fully charge the headphones. Use the provided magnetic charging cable. Connect the magnetic end to the

charging port on the headphones and the USB end to a power source (e.g., computer USB port, USB wall adapter).

- Charging time: Approximately 1.5 hours for a full charge.
- Indicator: The charging indicator light will change color or turn off when fully charged.

3.2. Wearing the Headphones

The headphones feature an ear-hook design for a secure and comfortable fit. Place the ear hooks over your ears, ensuring the bone conduction speakers rest comfortably on your cheekbones, just in front of your ears.




Image: Illustration demonstrating the correct way to wear the headphones, with the ear-hooks positioned over the ears and the speakers resting near the temples.

4. OPERATING INSTRUCTIONS

4.1. Power On/Off

- **Power On:** Press and hold the Power button for 3 seconds.
- **Power Off:** Press and hold the Power button for 5 seconds.

4.2. Bluetooth Mode

To connect the headphones to your smartphone or other Bluetooth-enabled device:

1. Ensure the headphones are powered on and in Bluetooth pairing mode (indicated by a flashing LED).
2. On your device, enable Bluetooth and search for available devices.
3. Select "CYBORIS SM608" (or similar) from the list of devices.
4. Once connected, the LED indicator will stop flashing.

Note: Bluetooth signal cannot transmit effectively underwater. Switch to MP3 mode for underwater use.

Bluetooth 5.0

Music and calls have zero delay, low power consumption, and calls are more stable.



Image: The CYBORIS headphones shown wirelessly connected to a smartphone, illustrating Bluetooth 5.0 connectivity.

4.3. MP3 Mode

The headphones have a built-in 16GB memory for storing music files. This mode is ideal for activities where a Bluetooth connection is not feasible, such as swimming.

4.3.1. Transferring Music Files

1. Connect the headphones to your computer using the magnetic charging cable.

2. The headphones will appear as a removable disk drive.
3. Drag and drop your desired music files (MP3/WMV/WAV/Flac/APE formats supported) into the headphone's storage.
4. Safely eject the device from your computer before disconnecting the cable.

4.3.2. Switching to MP3 Mode

Press the Mode button (if available, or refer to specific button functions) to switch between Bluetooth and MP3 modes. The headphones will indicate the current mode.

16GB MP3 Mode

Download your favorite music, and manage different folders.
From now on, put down the phone to do sports.

Download up to
5000 songs

Personalized
music folders

Leave phone
to exercise




Image: A woman on a beach wearing the CYBORIS headphones, symbolizing the freedom of exercising without a phone due to the 16GB MP3 mode.

4.4. Controls


The headphones feature intuitive controls for playback and calls:

Button/Action	Function
Power Button (Long Press)	Power On/Off
Volume Up (+)	Increase Volume / Next Track (Long Press)
Volume Down (-)	Decrease Volume / Previous Track (Long Press)
Multi-function Button (Play/Pause)	Play/Pause Music, Answer/End Call
Mode Button	Switch between Bluetooth and MP3 modes

Professional Waterproof

In-ear design, no water enter ear, no sound leakage underwater.
Focus on exercise, for your every sweating profusely.

IPX8



*Please switch to MP3 mode when swimming.

Image: A visual representation of the headphone controls, including play/pause, volume up/next track, and volume down/previous track buttons.

5. MAINTENANCE AND CARE

- **Cleaning:** Wipe the headphones with a soft, damp cloth after each use, especially after swimming or heavy sweating. Do not use abrasive cleaners or solvents.
- **Drying:** Ensure the headphones are completely dry before charging. Pay special attention to the magnetic charging contacts.

- **Storage:** Store the headphones in a cool, dry place away from direct sunlight and extreme temperatures.
- **Water Exposure:** While IPX8 waterproof, prolonged exposure to saltwater or chlorinated water should be followed by rinsing with fresh water and thorough drying.

New Upgrade

Breakthrough bone conduction dynamic earphone speakers with better waterproof performance.



Composite diaphragm

Noise reduction net

Vibration unit

Image: Diagram illustrating the internal structure of the bone conduction speaker, highlighting the composite diaphragm, noise reduction net, and vibration unit. This image also serves to show the robust internal design that contributes to the product's durability and waterproof features, relevant for maintenance.

6. TROUBLESHOOTING

Problem	Possible Cause	Solution
Headphones do not power on.	Low battery.	Charge the headphones fully.
Cannot connect via Bluetooth.	Headphones not in pairing mode; device Bluetooth off; too far from device.	Ensure headphones are in pairing mode. Turn device Bluetooth off/on. Move closer to device.
No sound in MP3 mode.	No music files loaded; incorrect file format; volume too low.	Transfer supported music files. Increase volume.
Sound cuts out underwater.	Attempting to use Bluetooth underwater.	Switch to MP3 mode before entering water. Bluetooth does not transmit underwater.
Headphones not charging.	Magnetic contacts dirty or corroded; faulty cable/power source.	Clean magnetic contacts. Try a different USB port or power adapter.

7. PRODUCT SPECIFICATIONS

Feature	Detail
Model	SM608
Brand	CYBORIS
Waterproof Rating	IPX8
Internal Storage	16GB
Supported Audio Formats	MP3/WMV/WAV/Flac/APE
Bluetooth Version	5.0
Battery Capacity	250mAh
Playback Time	Up to 24 hours
Charging Time	Approx. 1.5 hours
Weight	29 Grams
Material	Plastic

8. WARRANTY INFORMATION

This product comes with a standard manufacturer's warranty. Please refer to the warranty card included in your product packaging for specific terms and conditions. Keep your purchase receipt as proof of purchase for warranty claims.

9. CUSTOMER SUPPORT

For any questions, technical assistance, or warranty claims, please contact CYBORIS customer service. Contact information can typically be found on the product packaging or the official CYBORIS website.

"For a better customer experience, please get in touch with store customer service for any questions."

