

## Naomi Home 81521-03

# Naomi Home Vienna 9ft Prelit Slim Artificial Christmas Tree

Model: 81521-03

Brand: Naomi Home

## 1. INTRODUCTION

This manual provides instructions for the assembly, operation, and maintenance of your Naomi Home Vienna 9ft Prelit Slim Artificial Christmas Tree. This tree features 1455 branch tips, 500 warm incandescent lights, and a sturdy metal stand. Its slim design is ideal for various spaces, offering a realistic and natural appearance.

## 2. SAFETY INFORMATION

- Ensure the tree is placed on a level, stable surface to prevent tipping.
- Keep the tree away from heat sources, open flames, and flammable materials.
- The tree materials are flame retardant and non-allergenic.
- Do not overload electrical outlets. Use only as directed.
- Unplug the tree when not in use or before performing any maintenance.

## 3. PARTS LIST

Please ensure all parts are present before beginning assembly:

- Top Section of the Tree (1)
- Middle Section of the Tree (1)
- Bottom Section of the Tree (1)
- Metal Stand (1)
- Eyebolts for Stand (3)
- Assembly Instruction File (1)

## 4. SETUP AND ASSEMBLY

Follow these steps to assemble your artificial Christmas tree. Refer to the assembly video for visual guidance.

Official Naomi Home Vienna Slim Pre-Lit Artificial Christmas Tree Assembly Video. This video demonstrates the step-by-step process of setting up the tree, from assembling the stand to connecting the sections and fluffing the branches.

1. **Assemble the Stand:** Pull apart the legs of the metal stand so they form an X-shape. Thread the eyebolts into the stand to prepare for securing the tree sections.
2. **Insert Bottom Section:** Carefully insert the bottom section of the tree into the assembled stand. Tighten the eyebolts until the pole is firmly secured.
3. **Attach Middle Section:** Place the middle section of the tree onto the top of the bottom section. Ensure it is seated properly.
4. **Attach Top Section:** Place the top section of the tree onto the top of the middle section.
5. **Connect Lights:** Connect the pre-assembled light wires between the bottom and middle sections, and then between the middle and top sections. Ensure all connections are secure.
6. **Shape the Branches (Fluffing):** Starting from the bottom, gently spread out each branch and individual tip to fill in any gaps and achieve a full, natural appearance. The hinged branches are designed for easy shaping.



Image illustrating the tree's dimensions, sturdy metal stand, pre-lit design, and realistic branch tips for a dense, fluffy look.



Visual details of the tree's construction, highlighting the metal hinges for easy assembly and non-flammable PVC branches, along with the stable folding metal base.

## 5. OPERATING INSTRUCTIONS

Your Naomi Home Vienna Christmas Tree comes pre-lit with 500 warm incandescent lights. To operate the lights, simply plug the tree into a standard electrical outlet. Some models may include a foot pedal for convenient on/off control. Ensure all light connections between sections are secure for proper illumination.



Our Pre lit Christmas tree comes with bright incandescent lights. The superior white Lighting in our artificial Christmas tree bring home the sparkling christmas cheer.

The branch tips in our lighted Christmas tree gives you a denser fluffy look. The four-layer leaves design appears realistic and fuller.

The hinged branches that drop down for a simple set-up gives the perfect shape.

Built with high quality metal hinges and non-flammable PVC branches.



Detailed view of the tree's pre-lit branches, emphasizing the warm incandescent lighting and the multi-layered leaf design that contributes to its realistic fullness.

## 6. MAINTENANCE

- **Cleaning:** To clean the tree, use a damp cloth and a mild detergent. Avoid using bleach or abrasive cleaners, as these can damage the materials.
- **Storage:** The hinged branches allow for easy folding. For convenient storage, disassemble the tree into its sections and store it in its original packaging or a suitable storage container in a cool, dry place.

## 7. TROUBLESHOOTING

- **Lights Not Working:** If the lights do not illuminate, check all electrical connections between the tree sections and ensure the main power plug is securely inserted into a working outlet. Inspect individual bulbs for looseness or damage.
- **Tree Instability:** Ensure the metal stand legs are fully extended and the eyebolts are tightened securely to prevent wobbling.
- **Gaps in Branches:** After assembly, take time to properly "fluff" the branches by spreading out each tip. This will help fill any visible gaps and achieve the desired full appearance.

## 8. SPECIFICATIONS

<b>Brand</b>	Naomi Home
<b>Model Number</b>	81521-03
<b>Product Dimensions</b>	37"D x 37"W x 108"H (9ft Tall, 37" Girth)
<b>Material</b>	Metal, Polyethylene, Polyvinyl Chloride
<b>Item Weight</b>	20 Pounds
<b>Branch Tips</b>	1455
<b>Lights</b>	500 Warm White Incandescent Lights (Built-in)
<b>Tree Type</b>	Fir, Pine
<b>Base Type</b>	Metal Stand
<b>Special Feature</b>	Tree with lights, Hinged Branches

## 9. WARRANTY AND SUPPORT

This product comes with a 90-day Manufacturer's Warranty. In case of any issues or for support, please contact Naomi Home customer service for assistance with refunds or replacements. Refer to the contact information provided with your purchase or visit the official Naomi Home website.