

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [UGREEN](#) /

› [UGREEN 3-in-1 Bluetooth Selfie Stick Tripod User Manual](#)

UGREEN 15062

UGREEN 3-in-1 Bluetooth Selfie Stick Tripod User Manual

Model: 15062

INTRODUCTION

Welcome to your UGREEN 3-in-1 Bluetooth Selfie Stick Tripod. This versatile device combines a selfie stick, a tripod, and a detachable Bluetooth remote control, designed to enhance your mobile photography and videography experience.

This manual provides detailed instructions for setup, operation, maintenance, and troubleshooting to ensure optimal performance and longevity of your device.

PRODUCT OVERVIEW

The UGREEN 3-in-1 Bluetooth Selfie Stick Tripod is engineered for stability and portability. It features an extendable pole, a stable tripod base, and a detachable Bluetooth remote for convenient remote capture.

Key Features:

- **3-in-1 Design:** Selfie stick, tripod, and Bluetooth remote.
- **Extendable Length:** Up to 150 cm (approximately 60 inches).
- **Stable Bluetooth 5.0 Remote:** Operates up to 10 meters, powered by a CR1632/120 mAh battery for up to 20,000 photos.
- **Adjustable Angle:** 360° rotation for horizontal and vertical shooting, 200° tilt.
- **Compact and Portable:** Folds down to 32 cm (12.5 inches).
- **Wide Compatibility:** Supports smartphones 4.7 to 6.1 inches (with case), iOS 5.0+ and Android 4.0+, and devices up to 1kg with a 1/4" standard screw (e.g., GoPro, cameras, LED lights).
- **Durable Construction:** Aluminum material with anti-slip silicone clip and triangular base for enhanced stability.

Super Stabilité

Base du Support Plus Large



Alliage d'Aluminium



Patin Antidérapant

Image: Close-up view of the UGREEN selfie stick tripod's stable base, highlighting its aluminum construction and anti-slip pads for enhanced stability.

Package Contents:

- UGREEN 3-in-1 Bluetooth Selfie Stick Tripod
- Detachable Bluetooth Remote Control
- User Manual

SETUP

Unfolding the Selfie Stick Tripod:

1. Hold the handle firmly.
2. Gently pull the top section upwards to extend the pole.
3. To deploy the tripod legs, push the bottom part of the handle downwards. The legs will spread out to form a stable base.

4. Ensure the tripod legs are fully extended and locked into position for maximum stability.



Image: The UGREEN 3-in-1 Bluetooth Selfie Stick Tripod shown in both its fully extended tripod configuration with a phone mounted,

and its compact, folded selfie stick form. This illustrates the dual functionality and portability of the device.

Attaching Your Device:

1. Locate the phone clip at the top of the selfie stick.
2. Gently pull the spring-loaded clip open.
3. Insert your smartphone into the clip, ensuring it is securely held. The clip supports phones with a width between 5.8 cm and 8.2 cm (including case).
4. For cameras or GoPro devices, use the standard 1/4" screw mount if applicable, ensuring the device weight does not exceed 1kg.



Image: A person is shown using the UGREEN selfie stick in its extended tripod mode, with a smartphone mounted. The image highlights the extended pole length and the stable tripod base, demonstrating its use for hands-free recording or photography.

Compatible avec les téléphones & GoPro



Cell Phone



Camera



GoPro

Image: An image demonstrating the wide compatibility of the UGREEN selfie stick tripod. It shows a smartphone securely mounted, alongside illustrations of how a traditional camera and a GoPro can also be attached, highlighting the versatile mounting options.

OPERATING INSTRUCTIONS

Bluetooth Remote Control Pairing:

1. Press and hold the power button on the Bluetooth remote control for 2 seconds. The green indicator light will illuminate for 3 seconds, then begin to flash, indicating it is in pairing mode.
2. On your smartphone, activate Bluetooth and search for available devices.
3. Select "UGREEN-LP586" (or similar model name) from the list to connect.
4. Once successfully paired, the green indicator light on the remote will illuminate for 3 seconds and then turn off. The remote is now ready for use.

Structure en Triangle



Coussinet
Antidérapant



Image: An image detailing the Bluetooth pairing process for the remote control. It shows the remote control and a smartphone screen with Bluetooth settings, guiding the user through pressing the power button, searching for 'UGREEN-LP586', and connecting.

Taking Photos/Videos:

Once paired, simply open your camera application on your smartphone. Press the camera button on the Bluetooth remote control to capture photos or start/stop video recording.



Télécommande Bluetooth

Libérez vos mains et fixez les moments de bonheur.

Image: A family with a golden retriever dog is shown posing for a group photo, with the UGREEN selfie stick tripod set up in front of them, demonstrating its use for capturing moments with ease.

Adjusting Length and Angle:

The selfie stick can be extended to your desired length by pulling the pole sections.

The phone holder allows for 360° rotation to switch between landscape and portrait modes, and a 200° tilt for precise angle adjustments. Loosen the knob, adjust, and tighten to secure.

Parfait pour les selfies



Image: A visual representation of the UGREEN selfie stick's extendable design, showing its compact folded size (12.5 inches/32cm) and various extended lengths up to 60 inches (150cm). This demonstrates its versatility for different shooting distances.

Support Trépied Téléphone à Angle Réglable et Rotatif



Image: Diagram illustrating the adjustable angles of the phone holder. It shows a 360-degree rotation for switching between horizontal and vertical orientations, and a 200-degree tilt for finding the perfect shooting angle.

MAINTENANCE

Cleaning:

Wipe the device with a soft, dry cloth. Do not use abrasive cleaners or solvents.

Storage:

Store the selfie stick tripod in a cool, dry place away from direct sunlight and extreme temperatures.

Ensure the device is fully collapsed and the tripod legs are folded before storage to prevent damage.

Battery Replacement (Bluetooth Remote):

The Bluetooth remote uses a CR1632 battery. When the remote's performance degrades or it fails to power on, replace the battery.

1. Locate the battery compartment on the remote control.
2. Use a small tool (e.g., a coin or small screwdriver) to open the compartment.
3. Remove the old battery and insert a new CR1632 battery with the positive (+) side facing up.
4. Close the battery compartment securely.




Image: A close-up image of the UGREEN Bluetooth remote control, highlighting its sleek design and the UGREEN branding. This image visually represents the remote that controls the selfie stick tripod.

TROUBLESHOOTING

Remote Control Not Pairing:

- Ensure the remote control is charged or has a fresh battery (CR1632).
- Make sure Bluetooth is enabled on your smartphone.
- Move the remote closer to your phone (within 10 meters).
- Forget the device in your phone's Bluetooth settings and try pairing again.
- Restart both your phone and the remote control.

Device Not Stable on Tripod:

- Ensure the tripod legs are fully extended and locked.
- Place the tripod on a flat, stable surface.
- Verify that your phone or camera is securely clamped in the holder and its weight does not exceed 1kg.
- Avoid extending the pole to its maximum length if using a heavy device, as this can affect stability.

Phone Not Fitting in Clip:

- Check the phone width against the clip's supported range (5.8-8.2 cm).
- Remove bulky phone cases if necessary.

SPECIFICATIONS

Feature	Detail
Model	15062

Feature	Detail
Material	Aluminum
Color	Black
Folded Length	32 cm (12.5 inches)
Max Extended Length	150 cm (60 inches)
Product Dimensions (L x W x H)	4 x 4 x 30 cm (folded)
Item Weight	368.54 grams (approx. 13 ounces)
Bluetooth Version	V5.0
Remote Control Range	Up to 10 meters
Remote Battery Type	CR1632 (120 mAh)
Phone Clip Stretch Range	5.8 - 8.2 cm
Max Load Capacity	1 kg
Compatible OS	iOS 5.0 and above, Android 4.0 and above

WARRANTY AND SUPPORT

UGREEN products come with a standard manufacturer's warranty. For specific warranty details and duration, please refer to the warranty card included with your purchase or visit the official UGREEN website.

For technical support, troubleshooting assistance, or warranty claims, please contact UGREEN customer service through their official channels.

Official UGREEN Website: www.ugreen.com

© 2025 UGREEN. All rights reserved.

This manual is subject to change without notice.