

[Manuals.plus](#) /

› [Satisfyer](#) /

› Satisfyer Air Pump Booty 5 Connect App Vibrator User Manual

Satisfyer 7102840

Satisfyer Air Pump Booty 5 Connect App Vibrator User Manual

Model: 7102840

Brand: Satisfyer

1. INTRODUCTION

Thank you for choosing the Satisfyer Air Pump Booty 5 Connect App Vibrator. This device is designed for anal stimulation, featuring an innovative inflatable shaft and multiple vibration programs. It can be controlled directly via the device buttons or through the Satisfyer Connect App for an expanded range of functions. Please read this manual carefully before first use to ensure safe and optimal operation.

Satisfyer



Inflatable Shaft for Intensified Stimulation:

- Diameter individually adjustable
- Perfect for anal training

The Satisfyer Air Pump Booty 5 features a sleek design with an ergonomic handle and an inflatable shaft.

2. SAFETY INFORMATION

- This product is intended for adult use only.
- The device is made from body-friendly silicone. Discontinue use if irritation occurs.
- Always clean the device before and after each use.
- Do not use with damaged skin or if you have any medical conditions that may be aggravated by its use. Consult a healthcare professional if unsure.
- Use only water-based lubricants with this device. Oil-based lubricants can damage silicone.
- The wide base design ensures safe use and prevents over-insertion.
- Keep out of reach of children.

3. PACKAGE CONTENTS

Your Satisfyer Air Pump Booty 5 package should include:

- Satisfyer Air Pump Booty 5 Device
- USB Magnetic Charging Cable
- User Manual

4. SETUP

1. **Initial Charge:** Before first use, fully charge the device. Connect the magnetic charging cable to the charging contacts on the device and plug the USB end into a suitable USB power source (e.g., computer, USB wall adapter). The LED indicator will show charging status.
2. **First Cleaning:** Clean the device thoroughly with warm water and a mild, toy-safe soap or specialized toy cleaner. Rinse well and allow to air dry completely.

5. OPERATING INSTRUCTIONS

The Satisfyer Air Pump Booty 5 features intuitive controls for easy operation.



Comfortable to Hold and Easy to Use:



VIBRATION



PROGRAMS

Press to cycle through 12 vibration programs when the device is on.



INFLATABLE



INFLATE/DEFLATE

Hold to INFLATE the shaft. Quickly press twice to DEFLATE the shaft.



POWER

Press and hold for 2 seconds to turn the device on.



FREE APP



BLUETOOTH

Press and hold for 5 seconds until you feel a double pulse to prepare the device for Bluetooth pairing



LED lights starts flashing when the device is ready for pairing

This image illustrates the various control buttons on the device, including power, vibration programs, inflate/deflate, and Bluetooth pairing.

- **Power On/Off:** Press and hold the **Power button** () for 2 seconds to turn the device on or off.
- **Vibration Programs:** Once the device is on, press the **Programs button** () to cycle through the 12 available vibration patterns.
- **Inflate/Deflate:** To inflate the shaft, press and hold the **Inflate/Deflate button** (). To deflate the shaft, quickly press the **Inflate/Deflate button** () twice. The shaft can increase its diameter by up to 15 mm.

6. APP CONNECTION

Enhance your experience by connecting your device to the Satisfyer Connect App.

1. **Download the App:** Download the free Satisfyer Connect App from the App Store (iOS) or Google Play Store (Android).
2. **Enable Bluetooth on Device:** With the device turned off, press and hold the **Bluetooth button** () for 5 seconds until you feel a double pulse and the LED lights begin to flash. This indicates the device is ready for pairing.

3. **Pair with App:** Open the Satisfyer Connect App on your smartphone and follow the on-screen instructions to connect to your Air Pump Booty 5.

7. MAINTENANCE AND CLEANING

Proper care ensures the longevity and hygiene of your device.

- **Cleaning:** Always clean the device thoroughly before and after each use. Use warm water and a mild, antibacterial soap or a specialized toy cleaner. Avoid using harsh chemicals, alcohol, or petroleum-based cleaners, as these can damage the silicone material.
- **Drying:** Rinse the device thoroughly to remove all soap residue. Pat dry with a lint-free cloth or allow it to air dry completely before storing.
- **Storage:** Store the device in a clean, dry place, away from direct sunlight and extreme temperatures. Keep it separate from other toys made of different materials to prevent material degradation.

8. CHARGING

The device is powered by a rechargeable Lithium Ion battery.

- **Charging Port:** The device features magnetic charging contacts.
- **Charging Process:** Connect the magnetic charging cable to the device and a USB power source. The LED indicator will illuminate or flash to show that charging is in progress.
- **Full Charge:** Once fully charged, the LED indicator will change (e.g., stop flashing or turn solid). Disconnect the charger when charging is complete.

9. TROUBLESHOOTING

If you encounter any issues, please refer to the following common solutions:

Problem	Possible Cause	Solution
Device does not turn on.	Low battery or incorrect power-on procedure.	Ensure the device is fully charged. Press and hold the Power button () for 2 seconds.
Vibration or inflation not working.	Low battery or device malfunction.	Charge the device fully. If the issue persists, contact customer support.
Cannot connect to Satisfyer Connect App.	Bluetooth not enabled on device or phone, or app permissions.	Ensure Bluetooth is enabled on your phone. Press and hold the Bluetooth button () on the device for 5 seconds until LEDs flash. Check app permissions on your phone.
Shaft does not inflate sufficiently.	Incorrect inflation procedure or device limitation.	Hold the Inflate/Deflate button () continuously to inflate. The shaft expands up to 15 mm. Ensure the device is fully charged.

10. SPECIFICATIONS

- **Model Number:** 7102840
- **Material:** Body-friendly Silicone

- **Color:** White
- **Dimensions:** Approximately 2.09 x 2.17 x 7.13 inches (5.3 x 5.5 x 18.1 cm)
- **Weight:** Approximately 5.54 ounces (157 grams)
- **Battery:** 1 Lithium Ion battery (included)
- **Inflatable Diameter:** Increases up to 15 mm



A top-down perspective of the device, highlighting its overall shape and the textured inflatable shaft.

11. WARRANTY

Satisfyer offers a **15-year warranty** on this product, ensuring long-lasting satisfaction and peace of mind. Please retain your proof of purchase for warranty claims.

12. SUPPORT

For further assistance, troubleshooting, or warranty inquiries, please visit the official Satisfyer website or contact their customer service department. Contact details can typically be found on the product packaging or the brand's official website.

© 2026 Satisfyer. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0B9S465Z8>

More documents and user manuals: <https://manuals.plus/>