

[Manuals.plus](#) /

› [X9 Performance](#) /

› X9 Performance X9 Wireless Keyboard and Mouse Combo User Manual

X9 Performance X9 Wireless Keyboard and Mouse Combo

X9 Performance X9 Wireless Keyboard and Mouse Combo User Manual

Model: X9 Wireless Keyboard and Mouse Combo

INTRODUCTION

This manual provides instructions for setting up and using your X9 Performance X9 Wireless Keyboard and Mouse Combo. This combo offers a full-size keyboard with 110 keys and a compact mouse, both connecting wirelessly via a single USB receiver. It is designed for compatibility with various operating systems including Windows, Chrome OS, and Mac OS.

IMPROVE VIBES. BOOST PRODUCTIVITY.



For PC and Chrome



Product color may vary due to lighting

Image: The X9 Performance Pink Wireless Keyboard and Mouse Combo, showcasing its design on a clean desk setup.

PACKAGE CONTENTS

- X9 Wireless Keyboard
- X9 Wireless Mouse
- USB 2.4G Receiver (stored inside the mouse battery compartment)
- 1 AA Battery (for mouse, included)
- 1 AAA Battery (for keyboard, included)

SETUP

1. **Insert Batteries:** Open the battery compartments on both the keyboard and the mouse. Insert the included AA

battery into the mouse and the AAA battery into the keyboard, ensuring correct polarity.

2. **Locate USB Receiver:** The USB 2.4G receiver is typically stored in the battery compartment of the mouse for safekeeping. Remove it carefully.
3. **Connect Receiver:** Plug the USB receiver into an available USB-A port on your computer (PC, laptop, or Chromebook).
4. **Power On:** Ensure both the keyboard and mouse are powered on. The mouse usually has a power switch on its underside. The keyboard may activate automatically once batteries are inserted.
5. **Automatic Connection:** The keyboard and mouse should automatically connect to your computer within a few seconds. No additional drivers are typically required.



ENJOY WIRELESS CONNECTIVITY.

A single USB-A receiver for both keyboard and mouse

Image: Diagram illustrating the USB receiver and the 30ft wireless range of the keyboard and mouse combo.

Plug and Play for PC and Chrome.

Connect the USB receiver into your computer and begin typing instantly




Image: Visual guide for plug-and-play setup, showing the keyboard and mouse connecting to a computer via a USB receiver.

Setup Video Guide

Your browser does not support the video tag.

Video: This video demonstrates the unboxing and initial setup process for the X9 Pink Wireless Keyboard and Mouse Combo, including battery installation and USB receiver connection.

Your browser does not support the video tag.

Video: A short video showing the wireless keyboard and mouse combo, including how to connect the USB receiver for immediate use.

OPERATING INSTRUCTIONS

Keyboard Usage

The keyboard features a full-size layout with 110 round keys, providing a tactile typing experience. It includes 18 shortcut keys for quick access to common functions.

- **Shortcut Keys:** Utilize the 18 dedicated shortcut keys for functions such as media control (play/pause, volume), web browser, email, calculator, and more. Refer to the keycap legends for specific functions.
- **Integrated Kickstand:** The keyboard features an integrated kickstand to provide an ergonomic typing angle, enhancing comfort during extended use.

MULTI-FUNCTIONAL SHORTCUT KEYS.




Image: The keyboard layout highlighting the multi-functional shortcut keys (F1-F12 and others) for quick access to various commands.

Keyboard for Any Task.

A full size layout with 110-
keys offers everything
you need for daily tasks



Image: An overhead view of the keyboard, emphasizing the 18 shortcut and media keys available for one-touch commands.

Integrated Typing Angle.

Type in comfort with an
integrated kickstand.
Helps during long hours




Image: A side profile of the keyboard, illustrating its integrated kickstand for an ergonomic typing angle.

Mouse Usage

The mouse features a simple 3-button layout with a scroll wheel and a 1200 DPI optical sensor for precise navigation.

- **Point and Click:** Use the left and right buttons for standard clicking functions.
- **Scroll Wheel:** The scroll wheel allows for smooth vertical scrolling through documents and web pages.
- **Ambidextrous Design:** The mouse is designed for comfortable use by both left and right-handed users.



Image: The X9 Performance mouse, highlighting its simple 3-button and scroll wheel layout for easy use.

Simple Point and Click.

A familiar 3 button and scroll wheel layout makes it easy to use



Image: A hand holding the X9 Performance mouse, demonstrating its ergonomic design for a comfortable grip.

Power Saving Features

Both the keyboard and mouse are designed with power-saving features to extend battery life.

- **Auto-Sleep:** The mouse will enter sleep mode after a period of inactivity. To reactivate, simply click any button.
- **Power-Saving Mode:** The keyboard also enters a power-saving mode when not in use.



SMOOTH AND COMFORTABLE.

A 1200 DPI optical sensor for precise navigation

Image: Visual representation of the mouse's power states: working, standby, auto-sleep, and how to activate it by pressing a button.



Batteries Included

AUTO POWER SAVING.

Enters sleep mode when not in use

Image: An illustration indicating the auto power-saving feature of the keyboard and mouse, which enters sleep mode when not in use.

Key Feel Demonstration

Your browser does not support the video tag.

Video: This video demonstrates the sound and feel of typing on the X9 Performance keyboard, highlighting its tactile feedback.

Your browser does not support the video tag.

Video: A demonstration of the keyboard's key presses, illustrating that the sound is not excessively loud.

MAINTENANCE

- **Cleaning:** Use a soft, dry cloth to clean the surfaces of the keyboard and mouse. For stubborn dirt, a slightly damp cloth can be used, ensuring no liquid enters the device.

- **Battery Replacement:** When the keyboard or mouse becomes unresponsive or exhibits lag, it may be time to replace the batteries. Open the battery compartment and replace the AA battery in the mouse and the AAA battery in the keyboard with new ones, observing correct polarity.
- **Storage:** When not in use for extended periods, remove the batteries to prevent leakage and store the USB receiver in the mouse's battery compartment.



Anti-Scratch Rubber Inserts.

Improves keyboard stability when typing, and prevents scrapes

Image: The underside of the keyboard, showing the anti-scratch rubber inserts that help maintain stability and protect surfaces.



Fits Perfectly in Your Hand.

Featuring a small ambidextrous body that fits snugly your palm

Image: The underside of the mouse, displaying the battery compartment and the 1200 DPI optical sensor.

TROUBLESHOOTING

Problem	Solution
---------	----------

Problem	Solution
Keyboard/Mouse is unresponsive or lagging.	• Check battery levels and replace if necessary. Low batteries are a common cause of unresponsiveness. • Ensure the USB receiver is securely plugged into a working USB port. • Move the keyboard/mouse closer to the USB receiver to ensure it is within the 30ft operating range. • If using a laptop with a docking station, try plugging the USB receiver directly into the docking station's USB port instead of the laptop itself to improve signal stability.
Keys are skipping or not registering input when typing quickly.	• Replace the keyboard batteries. • Ensure there are no obstructions under the keys. • Verify the USB receiver is not experiencing interference from other wireless devices.
Mouse cursor is erratic or jumps.	• Check battery levels and replace if necessary. • Ensure the mouse optical sensor is clean and free of debris. • Use the mouse on a suitable surface (e.g., a mouse pad) for optimal tracking.
Spacebar or other keys feel "sticky" or repeat characters.	• Clean around and under the affected key. • Replace the keyboard batteries.

SPECIFICATIONS

Feature	Detail
Brand	X9 Performance
Model	X9 Wireless Keyboard and Mouse Combo
Connectivity Technology	2.4G Radio Frequency
Wireless Range	Up to 30 feet
Compatible Devices	Laptop, Personal Computer, Television
Compatible Operating Systems	Android, Chrome OS, Mac OS, Windows
Keyboard Layout	QWERTY, 110 Keys
Keyboard Special Features	Round Key Design, 18 Shortcut Keys, Integrated Kickstand, Power-Saving

Feature	Detail
Mouse Movement Detection	Optical
Mouse DPI	1200 DPI
Mouse Hand Orientation	Ambidextrous
Power Source	Battery Powered (1 AA for mouse, 1 AAA for keyboard)
Item Weight	689 g

PERFECT SIZE
FOR YOUR DESK.




Image: Detailed dimensions of the X9 Performance keyboard and mouse for reference.

KEY FEATURES AT A GLANCE.

Power	Batteries	Large Text	No
Connectivity	RF 2.4G	Quiet Keys	No
Backlight	None	Round Keys	Yes
Compatibility	PC and Chrome	Kickstand	Fixed



Image: A summary table of key features including power, connectivity, backlight, compatibility, key type, and kickstand.

WARRANTY AND SUPPORT

The X9 Performance X9 Wireless Keyboard and Mouse Combo comes with a **2-year warranty**. For any product-related inquiries, technical assistance, or warranty claims, please contact X9 Performance customer support. You can find more information and support resources by visiting the official X9 Performance store: [X9 Performance Store](#)

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question