Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

vivicreate HT-G-2062

Vivicreate 2 Burner Propane Gas Stove (Model HT-G-2062) Instruction Manual

For Outdoor Cooking and Portable Use

1. Important Safety Information

Read all instructions and warnings carefully before using this appliance. Failure to follow these instructions may result in fire, explosion, property damage, personal injury, or death.

- **Outdoor Use Only:** This appliance is designed for outdoor use only. Do not operate indoors or in enclosed spaces.
- **Ventilation:** Ensure adequate ventilation when operating.
- **Propane Gas:** Use only propane gas. Do not connect to a natural gas supply.
- **Leak Check:** Always perform a leak check on all gas connections before each use. Apply a soapy water solution to connections; bubbles indicate a leak. Tighten connections or replace parts as necessary.
- **Flammable Materials:** Keep the stove clear of flammable materials, gasoline, and other flammable vapors and liquids. Maintain a minimum distance of 1 meter (3 feet) from walls and ceilings.
- **Children and Pets:** Keep children and pets away from the stove during operation and while it is cooling down.
- **Stable Surface:** Always operate the stove on a level, stable, non-combustible surface.
- **Hot Surfaces:** Surfaces will be hot during and after use. Allow to cool completely before handling or storing.
- **Regulator and Hose:** Use only the regulator and hose assembly provided with the stove. Do not modify or substitute.

2. Product Overview

Components Included

- Vivicreate 2 Burner Propane Gas Stove Unit

- Propane Gas Hose
- Gas Regulator

Key Features

- Dual High-Efficiency Burners: Provides consistent flame for efficient cooking.
- Durable Stainless Steel Body: Corrosion-resistant construction for outdoor conditions and easy cleaning.
- Stable Pan Support: Features anti-slip fixed pot stands to ensure cookware stability.
- Easy Flame Control Knobs: User-friendly knobs with ON/OFF markings for precise flame adjustment.
- Portable Design: Lightweight and compact, includes propane gas hose and regulator for convenient transport and setup.



Figure 2.1: Vivicreate 2 Burner Propane Gas Stove with regulator and hose.



Figure 2.2: Close-up view of the two burners with blue flames, indicating operation.



Figure 2.3: Detail of the stable pan support mechanism on the Vivicreate 2 Burner Propane Gas Stove.

3. Setup

3.1 Unpacking

1. Carefully remove all components from the packaging.
2. Inspect the stove and all parts for any damage. Do not use if damaged.
3. Remove any protective films or packaging materials from the stove surface.

3.2 Connecting the Propane Tank



Figure 3.1: Propane gas regulator and hose assembly.

1. Ensure both control knobs on the stove are in the "OFF" position.
2. Connect the gas hose to the stove's gas inlet. Hand-tighten securely.
3. Connect the regulator end of the hose to your propane tank valve. Hand-tighten firmly.
4. Ensure all connections are tight.
5. Perform a leak check: Open the propane tank valve slowly. Apply a soapy water solution to all gas connections. If bubbles appear, close the tank valve immediately, tighten connections, and re-test. Do not use if leaks persist.



Figure 3.2: Vivicreate 2 Burner Propane Gas Stove with the gas hose and regulator connected, ready for use.

4. Operating Instructions

4.1 Lighting the Burners

1. Ensure the propane tank valve is fully open.
2. Push in and slowly turn one of the control knobs counter-clockwise to the "ON" position. You should hear a click as the automatic ignition attempts to light the burner.
3. If the burner does not light within 5 seconds, turn the knob to "OFF", wait 5 minutes for gas to dissipate, and then repeat the lighting procedure.
4. Once lit, adjust the flame to your desired cooking intensity.

4.2 Adjusting Flame

The control knobs allow for precise flame adjustment from low to high. Turn the knob clockwise to decrease the flame and counter-clockwise to increase it.

4.3 Cooking Tips

- Place cookware centrally on the stable pan supports.
- The anti-slip fixed pot stands are designed to keep your pots and pans secure during cooking.
- Monitor food closely, especially when cooking at high temperatures.



Figure 4.1: The Vivicreate 2 Burner Propane Gas Stove in use, cooking two different dishes simultaneously outdoors.



Figure 4.2: An overhead view of the Vivicreate 2 Burner Propane Gas Stove with two pans, one frying meat and the other cooking a pancake.

5. Maintenance

5.1 Cleaning

1. Ensure the stove is completely cool before cleaning.
2. Disconnect the propane tank.
3. Wipe the stainless steel body with a damp cloth and mild detergent. Avoid abrasive cleaners or scouring pads that could scratch the surface.
4. Remove burner grates and clean separately if necessary.
5. Ensure all parts are dry before reassembly or storage.

5.2 Storage

1. Store the stove in a cool, dry place, away from direct sunlight and extreme temperatures.
2. Disconnect the propane tank and store it separately according to its manufacturer's instructions.
3. Cover the stove to protect it from dust and debris if storing for extended periods.

6. Troubleshooting

Common Issues and Solutions

Problem	Possible Cause	Solution
Burner does not light	Propane tank empty or valve closed Gas hose or regulator not properly connected Igniter not sparking	Check propane tank level and ensure valve is open Ensure all connections are tight and perform a leak check Check igniter for debris; use a long match or lighter if automatic igniter fails
Weak or inconsistent flame	Low propane level Partially closed tank valve Regulator issue or obstruction	Replace or refill propane tank Fully open propane tank valve Ensure regulator is correctly attached and not obstructed; replace if faulty
Smell of gas	Gas leak	Immediately turn off propane tank valve and stove knobs. Perform a thorough leak check with soapy water. Do not operate if a leak is detected. Move to a well-ventilated area and contact qualified service personnel if unable to resolve.

7. Specifications

Technical Data

Model Number: HT-G-2062

Material: Stainless Steel

Color: Silver

Heating Elements: 2 Burners

Product Dimensions: 15"D x 28"W x 4"H

Wattage: 6000 watts

Controls Type: Knob

Burner Type: Open

Power Source: Gas Powered (Propane)

Item Weight: 10 Pounds

Included Components: Regulator + Gas Pipe



Figure 7.1: Diagram showing the dimensions of the Vivicreate 2 Burner Propane Gas Stove: 28 inches wide, 15 inches deep, and 4 inches high.

8. Warranty and Support

8.1 Warranty Information

This Vivicreate product is covered by a manufacturer's warranty against defects in materials and workmanship. Specific warranty terms and duration may vary. Please retain your proof of purchase for warranty claims. For detailed warranty information, refer to the product packaging or the official Vivicreate website.

8.2 Customer Support

For technical assistance, warranty inquiries, or replacement parts, please contact Vivicreate customer support. Refer to the product packaging or the Vivicreate official website for current contact information and support channels.

© 2025 Vivicreate. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0B9T843BT

More documents and user manuals: **https://manuals.plus/**