Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

AWH aromatherapy diffuser

Kinscoter Flame Air Diffuser & Humidifier

Model: Aromatherapy Diffuser

Introduction

This manual provides essential information for the safe and effective operation of your Kinscoter Flame Air Diffuser and Humidifier. Please read this manual thoroughly before use and retain it for future reference.
The Kinscoter Flame Diffuser and Humidifier combines the benefits of an essential oil diffuser with a humidifying function, featuring a unique simulated flame effect to enhance your environment. It is designed to create a comfortable and cozy atmosphere in your home or office.

Safety Information

WARNING: Failure to follow these safety instructions may result in fire, electric shock, injury, or damage to the product or property.

- Always use essential oils with caution and follow the manufacturer's instructions for the essential oils.
- Keep the device and essential oils out of reach of children and pets.
- Avoid direct skin contact with undiluted essential oils.
- Ensure proper ventilation during use.
- Do not use the device without water in the reservoir to prevent dry usage and potential damage. The device features automatic shut-off when water is depleted.
- Use only the provided USB-C cable. The power supply (5V2A USB) is not included and must be purchased separately.
- Do not immerse the device in water or any other liquid.
- Do not block the mist outlet or air inlet during operation.
- Unplug the device before cleaning or refilling.

Package Contents

Please check the package for the following items:

- 1 x Kinscoter Flame Air Diffuser & Humidifier
- 1 x USB-C Cable

- 1 x Instruction Manual (this document)

Note: Essential oils and a 5V2A USB power supply are not included and must be purchased separately.

Product Overview



Figure 1: Front view of the Kinscoter Flame Air Diffuser, showing the mist outlet, control buttons, and decorative flame symbol.

The Kinscoter Flame Air Diffuser features a sleek, rectangular design with a black finish. Key components include:

- **Mist Outlet:** Located at the top, where the mist and simulated flame effect are emitted.
- **Water Tank:** Internal reservoir for water and essential oils.
- **Control Buttons:** Two buttons on the front for power and flame mode selection.
- **USB-C Port:** Located at the back for power connection.

Setup

1. **Unpack the Device:** Carefully remove the diffuser and all accessories from the packaging.
2. **Place on a Stable Surface:** Position the diffuser on a flat, stable, and water-resistant surface away from direct sunlight, heat sources, and electronic devices.
3. **Remove the Top Cover:** Gently lift the top cover of the diffuser to access the water tank.
4. **Fill the Water Tank:** Fill the water tank with clean tap water up to the 'MAX' line. Do not overfill. The capacity is 180ml.



Figure 2: Adding water and essential oil to the diffuser's water tank.

5. **Add Essential Oils (Optional):** Add 2-3 drops of your preferred essential oil directly into the water tank. Adjust the amount based on your preference and the oil's strength.
6. **Replace the Top Cover:** Securely place the top cover back onto the diffuser. Ensure it is properly aligned.
7. **Connect Power:** Insert the USB-C cable into the port on the back of the diffuser and connect the other end to a 5V2A USB power adapter (not included).

Operating Instructions

Once the diffuser is set up and connected to power, you can begin operation:



Figure 3: The diffuser in operation, displaying the flame effect.

- **Power On/Off:** Press the left button (power symbol) once to turn on the diffuser. Press it again to turn off.
- **Adjust Flame Mode:** Press the right button (flame symbol) to cycle through flame modes:
  - **First Press:** Activates full flame effect.
  - **Second Press:** Activates soft flame effect.
  - **Third Press:** Turns off the flame effect.
- **Automatic Shut-off:** The diffuser will automatically power off when the water level is too low or completely depleted. This feature prevents dry usage and ensures safety.



Figure 4: Automatic shut-off feature for water depletion.

Maintenance

Regular cleaning helps maintain the performance and longevity of your diffuser.

1. **Empty the Water Tank:** Before cleaning, unplug the diffuser and empty any remaining water from the tank.
2. **Wipe Down:** Use a soft, damp cloth to wipe the inside of the water tank and the exterior of the diffuser.
3. **Clean the Ultrasonic Plate:** Gently wipe the ultrasonic vibrating plate (located at the bottom of the water tank) with a cotton swab dipped in white vinegar or a mild cleaning solution. Do not scratch the plate.
4. **Rinse (Optional):** If using vinegar, rinse the tank with clean water, being careful not to get water into the air outlet.
5. **Dry Thoroughly:** Allow all parts to air dry completely before reassembling or storing the diffuser.

Note: Do not use corrosive detergents or hard brushes for cleaning. Clean the diffuser regularly, especially if using strong essential oils or hard water.

Troubleshooting

Problem	Possible Cause	Solution
No mist or weak mist	Low water level; Ultrasonic plate dirty; Mist outlet blocked.	Refill water; Clean ultrasonic plate; Clear mist outlet.
No power	Not plugged in; Power adapter faulty; Water level too low (auto shut-off).	Check power connection; Try another adapter; Refill water.
Unusual noise	Water level too low; Device not on a flat surface.	Refill water; Place on a stable, flat surface.
Flame effect not working	Flame mode not selected; LED light malfunction.	Press the flame button to cycle modes; If issue persists, contact support.

Specifications



Figure 5: Product dimensions.

Feature	Detail
Brand	AWH
Model Name	Aromatherapy Diffuser

Feature	Detail
Color	Black
Material	Plastic
Product Dimensions (L x W x H)	6.73" x 2.95" x 3.98" (17.1cm x 7.5cm x 10.1cm)
Item Weight	13 ounces
Water Tank Capacity	180 Milliliters
Power Source	Corded Electric (5V2A USB Power Supply, not included)
Runtime	Up to 12 hours
Auto Shutoff	Yes (when water is depleted)
Light Source Type	LED (Flame Effect)
Recommended Uses	Home, Office

Warranty and Support

For warranty information or technical support, please refer to the contact details provided by your retailer or visit the official AWH brand website. Keep your purchase receipt as proof of purchase.
For further assistance, please contact customer service through the platform where you purchased the product.

© 2023 AWH. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0B9VY358R

More documents and user manuals: **https://manuals.plus/**