

HUAWEI E5783-230a

Huawei 4G Mobile WiFi 3 (Model E5783-230a) User Manual

Portable LTE Wi-Fi Hotspot

1. INTRODUCTION

This manual provides essential instructions for setting up, operating, and maintaining your Huawei 4G Mobile WiFi 3 portable hotspot. Please read this guide thoroughly to ensure proper use and optimal performance of your device.

The Huawei 4G Mobile WiFi 3 (Model E5783-230a) is a compact and lightweight device designed to provide high-speed 4G LTE Wi-Fi connectivity on the go. It allows multiple devices to connect to the internet simultaneously via a single Micro-SIM card.

2. PRODUCT OVERVIEW

Key Features

- **Ultra-Fast 4G LTE:** Supports download speeds up to 300 Mbps and upload speeds up to 100 Mbps (CAT7+).
- **Dual-Band Wi-Fi:** Operates on both 2.4 GHz and 5 GHz frequencies, supporting up to 32 connected devices.
- **Long-Lasting Battery:** Equipped with a 1500 mAh rechargeable battery, offering up to 6 hours of continuous working time.
- **Compact and Portable:** Weighs only 87g, with dimensions similar to a credit card for easy portability.
- **Unlocked for All Networks:** Compatible with any Micro-SIM card from your preferred network provider.
- **Easy Management:** Control and monitor your network via the HUAWEI AI Life App or a web interface.

Package Contents

- Huawei 4G Mobile WiFi 3 Device
- Rechargeable Battery (removable)

- USB Cable (17 cm)
- USB Cable (100 cm)
- Charger
- Quick Start Guide (with safety information)
- Warranty Card

Device Layout



A black, rectangular Huawei 4G Mobile WiFi 3 device. The top surface features a glossy black strip with two green indicator lights, one for signal strength and one for battery status. The Huawei logo is visible on the right side of the device.

3. SETUP

1. **Install the Battery:** Open the back cover of the device. Insert the rechargeable battery into its compartment, ensuring the contacts align correctly. Close the back cover securely.
2. **Insert the Micro-SIM Card:** Locate the SIM card slot. Gently insert your Micro-SIM card into the slot with the gold contacts facing down and the notched corner oriented as indicated on the device. Ensure it clicks into place.
3. **Charge the Device:** Connect the device to the charger using the provided USB cable. Plug the charger into a power outlet. The battery indicator light will show charging status.
4. **Power On:** Press and hold the power button (usually located on the side or top) until the indicator lights illuminate.
5. **Initial Connection:** Once powered on, the device will broadcast a Wi-Fi network. The default Wi-Fi name (SSID) and password (Wi-Fi Key) are typically printed on a label inside the battery compartment or on the device itself.

4. OPERATING INSTRUCTIONS

Connecting Devices to Wi-Fi

1. Turn on your Huawei 4G Mobile WiFi 3.
2. On your computer, smartphone, or tablet, go to the Wi-Fi settings.
3. Select the Wi-Fi network name (SSID) of your hotspot from the list of available networks.
4. Enter the Wi-Fi password (Wi-Fi Key) when prompted.
5. Your device should now be connected to the internet.

Managing Your Hotspot

You can manage your hotspot settings through two primary methods:

- **HUAWEI AI Life App:** Download the official HUAWEI AI Life App from your device's app store. Connect your smartphone to the hotspot's Wi-Fi, then open the app to manage settings such as Wi-Fi name, password, connected devices, and data usage.
- **Web Management Page:** Open a web browser on a device connected to the hotspot. Enter the default IP address (usually 192.168.8.1 or 192.168.1.1) into the address bar. Log in using the default username and password (often 'admin' for both, or found on the device label). This interface provides comprehensive control over network settings, security, and advanced features like Guest Mode and WPS.

Dual-Band Wi-Fi

The device supports both 2.4 GHz and 5 GHz Wi-Fi bands. You can switch between these or configure them via the management interface:

- **2.4 GHz:** Offers wider coverage and better penetration through walls, suitable for general use and older devices.
- **5 GHz:** Provides faster speeds and less interference in crowded areas, ideal for streaming and gaming, but with a shorter range.

5. MAINTENANCE

Battery Care

- Charge the battery fully before first use.
- Avoid exposing the device to extreme temperatures.
- If the device will not be used for an extended period, charge it to about 50% and store it in a cool, dry place.

Cleaning

Use a soft, dry cloth to clean the device. Avoid using liquid cleaners or abrasive materials.

Software Updates

Periodically check for software updates through the HUAWEI AI Life App or the web management page to ensure optimal performance and security. Follow the on-screen instructions for any available updates.

6. TROUBLESHOOTING

- **No Internet Connection:**
 - Ensure the SIM card is correctly inserted and activated with a data plan.
 - Check the signal indicator on the device. If no signal, try moving to a different location.

- Restart the device and your connected devices.

- **Slow Speeds:**

- Check your network coverage.
- Reduce the number of connected devices.
- Try switching between 2.4 GHz and 5 GHz Wi-Fi bands.
- Ensure no background applications are consuming excessive bandwidth.

- **Cannot Connect to Wi-Fi:**

- Verify the Wi-Fi name (SSID) and password.
- Ensure the device is powered on and within range.
- Restart both the hotspot and the connecting device.

- **Battery Drains Quickly:**

- Reduce screen brightness (if applicable) and disable unnecessary features.
- Ensure the device is not in an area with poor signal, as this increases power consumption.
- Limit the number of connected devices.

7. SPECIFICATIONS

Feature	Specification
Brand	HUAWEI
Model Name	HUAWEI E5783-230a
Model Number	51071URW
Color	Black
Operating System	RouterOS
Connectivity Technology	USB, Wi-Fi
Wireless Communication Standard	802.11a, 802.11ac, 802.11b, 802.11g, 802.11n
Frequency Band Class	Dual-band (2.4 GHz, 5 GHz)
Max Download Speed	Up to 300 Mbps
Max Upload Speed	Up to 100 Mbps
Max Connected Devices	32
Special Features	Guest Mode, Access Point Mode, WPS
Total USB Ports	1
Compatible Devices	Computer, Smartphone, Tablet
Rechargeable Battery	1500 mAh Lithium-polymer

Battery Life	Up to 6 hours (continuous working time)
Weight	87g
Country of Origin	China

8. WARRANTY AND SUPPORT

Your Huawei 4G Mobile WiFi 3 device comes with a standard manufacturer's warranty. Please refer to the included Warranty Card for specific terms and conditions, including warranty duration and coverage.

For technical support, service, or inquiries regarding spare parts and software updates, please contact Huawei customer service or visit the official Huawei support website. Contact information can typically be found on the warranty card or the manufacturer's website.

© 2023 Huawei. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Email

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Details

Submit question