

[Manuals.plus](#) /

› [ROYMELO](#) /

› ROYMELO Double Glass Barn Door with Hardware Kit (18x84 inch) - Instruction Manual

ROYMELO SH-DR-07H-18-X2

ROYMELO Double Glass Barn Door with Hardware Kit (18x84 inch) - Instruction Manual

Model: SH-DR-07H-18-X2

INTRODUCTION

This manual provides detailed instructions for the assembly, installation, operation, and maintenance of your ROYMELO Double Glass Barn Door with Hardware Kit. This product features a durable PVC-coated LVL wood panel and tempered glass, designed for various indoor applications.

SAFETY INFORMATION


- Always wear appropriate safety gear, including gloves and eye protection, during assembly and installation.
- Ensure the wall structure is capable of supporting the weight of the barn door and hardware. Consult a professional if unsure.
- Keep children and pets away from the work area during installation.
- Handle glass panels with care to prevent breakage and injury. Tempered glass, while strong, can shatter into small pieces if damaged.
- Do not overtighten screws, as this may damage components.
- Ensure all hardware is securely fastened before operating the door.

PACKAGE CONTENTS

Before beginning assembly, verify that all components listed below are present and undamaged. If any parts are missing or damaged, please contact customer support.

PACKING LIST

Double 18" x 84" barn door + 6.6FT hardware kit



(Note: The headboard is not included)

Image: Overview of all components included in the ROYMELO Double Glass Barn Door package, including two door panels, a 6.6 FT hardware kit, handles, and fasteners. Note: The headboard is not included.

- 2 x Door Panels (each 18 inches wide, 84 inches high)
- 1 x 6.6 FT Barn Door Hardware Kit (includes track, rollers, floor guides, anti-jump pads, door stoppers)
- 2 x Door Handles
- Necessary Screws and Fasteners
- Assembly Instructions

Note: A headboard for mounting the track is not included and may be required depending on your wall structure and trim clearance.

SETUP AND INSTALLATION

The barn door comes in separate wood and glass panels for assembly. All wood boards are pre-cut and pre-drilled for ease of assembly. Follow these steps carefully.

Step 1: Door Panel Assembly



Image: Visual guide for assembling the door panels. The image illustrates how the pre-cut wood pieces and glass panels fit together to form a complete door. This process is designed for quick assembly, estimated at 30 minutes per door.

1. Unpack all wood and glass components for one door panel.
2. Carefully insert the tempered glass panels into the pre-routed grooves of the wood frame pieces.
3. Join the wood frame pieces using the provided fasteners and screws. Ensure all connections are tight and secure.
4. Repeat for the second door panel.
5. No staining is required as the panels are finished with a white PVC surface.

Step 2: Hardware Kit Installation

Install the barn door hardware kit according to the separate hardware instructions provided in your package. Key considerations include:

- **Wall Preparation:** Ensure the wall where the track will be mounted is structurally sound. If mounting directly into

drywall, locate wall studs or use a sturdy header board (not included) for secure attachment.

- **Track Placement:** Measure and mark the desired height for the track. Ensure it is level.
- **Roller Assembly:** Attach the rollers to the top edge of each assembled door panel using the provided bolts.
- **Floor Guides:** Install the floor guides to prevent the bottom of the doors from swinging out.



Image: Example of the ROYMELO Double Glass Barn Door installed, demonstrating its application in various rooms such as a cloakroom, kitchen, living room, bathroom, or bedroom.

OPERATING INSTRUCTIONS

To operate your barn door, simply grasp the handle and slide the door along the track. The rollers are designed for smooth and quiet operation.

- Ensure the path of the door is clear of obstructions.
- Slide the door gently to open or close. Avoid forcing the door.
- The floor guides will keep the bottom of the door aligned.

MAINTENANCE

Regular maintenance will ensure the longevity and smooth operation of your barn door.



Image: The PVC surface of the door is easy to clean. A hand is shown wiping the surface, demonstrating its low-maintenance quality and stable LVL wood structure.

- **Cleaning:** The PVC surface is waterproof and scratch-resistant, making it easy to clean. Use a soft, damp cloth with mild soap and water to wipe down the door panels and hardware. Avoid abrasive cleaners or harsh chemicals.
- **Glass Cleaning:** Clean the tempered glass panels with a standard glass cleaner and a soft cloth.
- **Hardware Check:** Periodically check all screws and fasteners to ensure they remain tight. Tighten if necessary.
- **Track Lubrication:** If the door does not slide smoothly, apply a silicone-based lubricant to the track and rollers.

PVC Surface

The surface is smooth & beautiful, the protection of door surface is strengthened, suitable for families with pets.



Water-Proof



Scratch-proof



Image: The PVC surface provides enhanced protection, making the door waterproof and scratch-proof, ideal for households with pets.

TROUBLESHOOTING

- **Door does not slide smoothly:**

- Check the track for any obstructions.
- Ensure the track is level.
- Lubricate the track and rollers with a silicone-based lubricant.
- Verify that all roller bolts are securely tightened.

- **Door is difficult to open/close:**

- Check if the floor guides are properly aligned and not causing friction.
- Inspect the rollers for any damage or debris.

- **Door rattles or wobbles:**

- Ensure all assembly screws for the door panels are tight.
- Verify that the track is securely mounted to the wall.
- Check the floor guides for proper installation.

SPECIFICATIONS

Feature	Detail
Model Number	SH-DR-07H-18-X2
Door Dimensions (each panel)	18 inches (width) x 84 inches (height)
Hardware Kit Length	6.6 feet (2 meters)
Material	LVL Wood with PVC surface, Tempered Glass
Color	White
Glass Type	Tempered, Frosted on one side, Transparent on the other
Assembly Required	Yes
Special Features	Waterproof, Scratch-resistant, Easy to clean, Anti-deformation, Stable structure
Package Dimensions	221.61 x 36.83 x 12.7 cm (87.25 x 14.5 x 5 inches)
Package Weight	39.46 kg (87 lbs)

Better Privacy

The glass is frosted on one side and transparent on the other, with a certain privacy and light transmission.



Privacy



Light



Image: Detail of the tempered glass panel, which is frosted on one side and transparent on the other, offering a balance of privacy and natural light.

SUPPORT AND CONTACT

For any questions regarding installation, specifications, or if any parts of your package are missing or damaged, please contact ROYMELO customer support. Our team is available to assist you.

Please refer to your purchase documentation for specific contact details or visit the ROYMELO official website.

© 2024 ROYMELO. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question