



Manuals.plus /

› **Samsung** /

› Samsung Galaxy Z Fold 4 (5G) User Guide: Complete Step-by-Step Manual

## Samsung Galaxy Z Fold 4

# Samsung Galaxy Z Fold 4 (5G) User Guide

Complete Step-by-Step Manual

## 1. PRODUCT OVERVIEW

---

The Samsung Galaxy Z Fold 4 is a foldable smartphone featuring a 12-inch full-HD+ display. It operates on Android 12L, designed to enhance the user experience for foldable devices. The device includes an enhanced rear camera system for improved photography and multitasking capabilities. It features three rear cameras and two front cameras, offering 3x optical zoom and 30x space zoom. The Galaxy Z Fold 4 supports 25W cable charging and introduces a new taskbar for a desktop-like interface.

# SAMSUNG GALAXY Z FOLD 4 (5G) USER GUIDE

## A COMPLETE STEP-BY-STEP MANUAL

for Beginners and Seniors on How to Setup the Samsung Galaxy  
Z Fold 4 & Flip 4 New Features and Functions on Your Smartphone

**LARGE  
PRINT  
EDITION**



**DENVEY EASTON**

Image 1.1: Front cover of the official user guide for the Samsung Galaxy Z Fold 4 (5G).

## 2. SETUP AND INITIAL CONFIGURATION

---

This section outlines the steps for setting up your new Samsung Galaxy Z Fold 4 device for the first time.

1. **Power On:** Press and hold the Power button until the Samsung logo appears.
2. **Initial Setup Wizard:** Follow the on-screen prompts to select your language, region, and agree to the terms and conditions.
3. **Connect to Wi-Fi:** Select your preferred Wi-Fi network and enter the password to establish an internet connection.
4. **Google Account Setup:** Sign in with your existing Google account or create a new one. This is essential for accessing the Google Play Store and other Google services.
5. **Data Transfer:** If you are upgrading from another device, follow the instructions to transfer your data, apps, and settings.
6. **Security Setup:** Configure your preferred screen lock method (PIN, pattern, password, fingerprint, or facial recognition).
7. **Samsung Account:** Sign in or create a Samsung account to access Samsung-specific features and services.
8. **Complete Setup:** Finish the remaining setup steps to personalize your device.

## 3. BASIC OPERATIONS

---

Learn how to perform fundamental tasks on your device.

### 3.1 Notes and Voice Recordings

- How to create notes
- How to edit notes
- How to create note options
- How to create notes menu
- How to create voice recordings

### 3.2 Samsung Pay

- How to use Samsung Pay
- How to use Quick Access for Samsung Pay
- How to use gift cards with Samsung Pay
- How to secure your payment information

## 4. CAMERA AND MEDIA MANAGEMENT

---

Explore the camera features and manage your photos and videos.

### 4.1 Camera Usage

- How to use the Galaxy Z Fold 4 5G Camera
- How to navigate the Camera Screen
- How to use the camera and its settings
- How to configure the shooting mode

- How to use the camera features
- How to use camera settings
- How to use other available features

## 4.2 Photo and Video Management

- How to view pictures
- How to edit pictures
- How to play videos
- How to adjust video brightness
- How to edit videos
- How to share pictures and videos
- How to delete pictures and videos
- How to take a screenshot
- How to use the Screen Recorder

## 5. BIXBY ASSISTANT

---

Utilize Bixby for voice commands and automated routines.

- How to use Bixby
- How to set up Bixby Home
- How to change Bixby settings
- How to use Bixby Voice
- How to use Bixby Vision
- How to use Bixby Routines

## 6. DISPLAY AND INTERACTION SETTINGS

---

Customize your screen and interaction preferences.

- How to use the Dark Mode
- How to apply Brightness settings
- How to add Motion smoothness
- How to set eye comfort shield
- How to use the screen Mode
- How to use Font size and Style
- Screen Layout and zoom adjustments
- How to expand to full-screen apps
- How to apply screen timeout
- How to manage accidental touch Protection
- How to adjust Touch Sensitivity
- How to display Charging Information

- How to add Screen Saver
- How to lift to Wake
- How to Double tap to turn on screen
- How to turn off your device's screen with a palm touch
- How to leave your screen on while viewing
- How to use One-handed Mode

## 7. CONNECTIVITY OPTIONS

---

Manage your device's network and connection settings.

- How to use Wi-Fi
- How to activate your Bluetooth
- How to use NFC and Payment
- How to apply Airplane Mode
- How to use your Mobile networks
- How to check your Data usage
- How to set your Mobile Hotspot
- How to use tethering
- How to use Nearby Device Scanning
- How to connect to a Printer
- How to set up and use Virtual Private Networks (VPNs)
- How to use Private DNS
- How to create your Ethernet connection

## 8. S PEN FUNCTIONALITY

---

Maximize your productivity with the S Pen features.

- How to use the S Pen
- How to use Air View
- How to use the Screen off Memo
- How to Air Command
- How to configure S Pen Settings

## 9. SPECIFICATIONS

---

Key technical details of the Samsung Galaxy Z Fold 4 (5G) User Guide book.

Feature	Detail
ASIN	B0BB5MCSX3
Publisher	Independently published
Publication date	August 19, 2022
Language	English
Print length	402 pages
ISBN-13	979-8847418409
Item Weight	1.5 pounds
Dimensions	6 x 0.91 x 9 inches

## 10. MAINTENANCE

---

Proper maintenance ensures the longevity and optimal performance of your device.

- **Cleaning:** Use a soft, lint-free cloth to gently clean the screen and body of the device. Avoid harsh chemicals.
- **Software Updates:** Regularly check for and install software updates to ensure your device has the latest features and security patches. Navigate to **Settings > Software update**.
- **Battery Care:** To prolong battery life, avoid extreme temperatures and do not let the battery completely drain frequently.
- **Storage Management:** Periodically review and delete unnecessary files, apps, and media to free up storage space and maintain performance.

## 11. TROUBLESHOOTING

---

Solutions for common issues you might encounter.

- **Device Unresponsive:** If your device is frozen, press and hold the Power button and Volume Down button simultaneously for about 7 seconds to force restart.
- **App Crashing:** Try clearing the app's cache (**Settings > Apps > [App Name] > Storage > Clear cache**) or reinstalling the app.
- **Connectivity Issues:** Toggle Wi-Fi or Bluetooth off and on. If the issue persists, restart your device or reset network settings (**Settings > General management > Reset > Reset network settings**).
- **Battery Draining Quickly:** Check battery usage in **Settings > Battery and device care > Battery** to identify power-hungry apps. Adjust display brightness and disable unnecessary features.
- **Factory Reset:** As a last resort for persistent issues, you can perform a factory data reset. **Warning: This will erase all data on your device.** Back up your data before proceeding. Navigate to **Settings > General management > Reset > Factory data reset**.

## 12. WARRANTY AND SUPPORT

---

Information regarding product warranty and customer support.

- **Warranty Information:** Refer to the warranty card included with your original product packaging for specific terms and conditions. Typically, Samsung devices come with a limited manufacturer's warranty covering defects in materials and workmanship.
- **Customer Support:** For technical assistance, service, or warranty claims, please visit the official Samsung support website or contact their customer service hotline.
- **Online Resources:** Additional support, FAQs, and software downloads can be found on the official Samsung website.