

CUISINE TALENT K08-WY601U

Joyoung K08-WY601U Mini Health Pot Electric Kettle User Manual

Model: K08-WY601U

INTRODUCTION

Thank you for purchasing the Joyoung K08-WY601U Mini Health Pot Electric Kettle. This compact and versatile appliance is designed for preparing various hot beverages and simple meals, such as soup, porridge, and tea, with ease. Its time-adjusting and heat preservation functions ensure your drinks and food are kept at the desired temperature. Please read this manual thoroughly before use to ensure safe and optimal operation.



Figure 1: The Joyoung K08-WY601U Mini Health Pot Electric Kettle, showcasing its clear glass pot and white base with control panel.

仅iPad mini大小

为您节省有限的桌面空间



Figure 2: The compact size of the Joyoung Mini Health Pot demonstrated next to an iPad mini, highlighting its space-saving design.

PRODUCT OVERVIEW AND COMPONENTS

The Joyoung K08-WY601U consists of a glass pot and a heating base with an integrated control panel. Key features include:

- **Glass Pot:** Transparent, allowing visibility of contents during preparation.
- **Lid:** With a handle for easy opening and closing.
- **Spout with Precision Filter Screen:** Designed for easy pouring and filtering, removable for cleaning.
- **Heating Base:** Contains the heating element and control interface.
- **Control Panel:** Features buttons for selection, start/cancel, and a digital display for time and temperature.

一人 mini 烹煮养生壶

Q萌造型 私人独享



Figure 3: The mini health pot filled with ingredients, demonstrating its capacity for preparing various health-focused beverages or light meals.

SETUP

1. **Unpacking:** Carefully remove all components from the packaging. Retain packaging for future storage or transport.
2. **Initial Cleaning:** Before first use, wash the glass pot and lid with warm soapy water, then rinse thoroughly and dry. Wipe the heating base with a damp cloth. Do not immerse the heating base in water.
3. **Placement:** Place the kettle on a stable, flat, heat-resistant surface, away from edges and out of reach of children. Ensure adequate ventilation around the unit.
4. **Power Connection:** Plug the power cord into a suitable electrical outlet.

放办公桌上 刚刚好

无需跑来跑去接水，小水库就在你手边。



Figure 4: The compact kettle positioned on an office desk next to a laptop, illustrating its suitability for personal use in a workspace.

OPERATING INSTRUCTIONS

The Joyoung K08-WY601U offers various functions for preparing different beverages and foods. The control panel allows for easy selection and adjustment.

General Operation:

1. **Fill the Pot:** Open the lid and fill the glass pot with water and/or ingredients. Do not exceed the maximum fill line.
2. **Place on Base:** Ensure the pot is securely placed on the heating base.
3. **Select Function:** Press the " " (Select) button to cycle through available functions (e.g., boiling, stewing, tea).
4. **Adjust Time/Temperature:** For functions like stewing or heat preservation, use the " " (Select) button to adjust the desired time or temperature. A long press on the " " button may allow for quick adjustment.
5. **Start Operation:** Press the " / " (Start/Cancel) button to begin the selected function. The display will show the remaining time or current temperature.
6. **Cancel Operation:** Press the " / " (Start/Cancel) button again to stop the current operation.

Stewing/Boiling Function Example:

This example illustrates how to use the " " (Stewing/Boiling) function, which allows for time adjustment to suit various ingredients.

汤粥茶饮 一键搞定

“炖煮”功能通过调节时间，可满足多种食材烹煮。



Figure 5: A visual guide to operating the stewing function, showing the sequence of button presses on the control panel.

1. Press " " (Select) to choose the " " (Stewing/Boiling) function. The indicator light will flash.
2. While the " " indicator light is flashing, press " / " (Start/Cancel) to confirm the function.
3. Press " " (Select) again to adjust the stewing duration.

4. Press " / " (Start/Cancel) to start the stewing process.

Note: A long press on the " " button allows for rapid time adjustment.

60-Second Pot Lift Memory:

The kettle features a convenient 60-second memory function. If you lift the pot from the base during operation, the program will pause. When the pot is returned to the base within 60 seconds, the operation will resume from where it left off, without needing to reset the program.

60S提壶记忆 中途拿取不忙乱

熬煮途中拿取不必重设程序。



Figure 6: A user pouring liquid from the kettle, demonstrating the practical application of the 60-second pot lift memory feature, which allows for temporary removal without interrupting the cooking cycle.

MAINTENANCE AND CLEANING

Regular cleaning ensures the longevity and hygienic operation of your Joyoung Mini Health Pot.

1. **Unplug:** Always unplug the kettle from the power outlet and allow it to cool completely before cleaning.
2. **Glass Pot and Lid:** Wash the glass pot and lid with warm water and a mild dish soap. Use a soft sponge or cloth. Rinse thoroughly to remove all soap residue.
3. **Precision Filter Screen:** The spout features a removable precision filter screen. Gently remove it for separate cleaning under running water. Ensure it is free of debris before reattaching.
4. **Heating Base:** Wipe the exterior of the heating base with a damp cloth. Do not immerse the base in water or any other liquid. Do not use abrasive cleaners or scouring pads, as they may damage the surface.
5. **Descaling:** Over time, mineral deposits (limescale) may build up, especially in hard water areas. To descale, fill the pot with a mixture of water and white vinegar (1:1 ratio) or a commercial descaling solution. Bring to a boil and let it soak for 30 minutes to an hour, then rinse thoroughly several times.
6. **Drying and Storage:** Ensure all parts are completely dry before storing the kettle. Store in a cool, dry place.

[减]去配件

炖盅、茶篮say-bye! 只在壶嘴处添加精密过滤网, 直接倒茶, 省去繁杂。



Figure 7: The kettle pouring liquid, highlighting the integrated precision filter screen in the spout, which can be removed for easy cleaning.

TROUBLESHOOTING

If you encounter any issues with your Joyoung Mini Health Pot, please refer to the following common problems and solutions:

Problem	Possible Cause	Solution
---------	----------------	----------

Problem	Possible Cause	Solution
Kettle does not turn on.	Not plugged in; power outlet malfunction; kettle not properly seated on base.	Ensure the power cord is securely plugged into a working outlet. Check if the kettle is correctly placed on the heating base.
Water not heating.	Function not selected or started; insufficient water.	Confirm that a function has been selected and the "Start" button pressed. Ensure water level is above the minimum mark.
Automatic shut-off not working.	Overfilling the pot; malfunction.	Do not fill above the maximum fill line. If the issue persists, contact customer support.
Unusual odors or sounds.	New product odor (temporary); mineral deposits.	Initial odors usually dissipate after a few uses. If persistent or strong, descale the kettle. If sounds are unusual or loud, discontinue use and contact support.

SPECIFICATIONS

Brand	CUISINE TALENT
Model Name	K08-WY601U
Color	Clear
Special Feature	Automatic Shut-Off
Recommended Uses	Preparing simple meals and beverages, especially in office settings
Product Care Instructions	Hand wash, Wipe clean
Capacity	800ml (for one person)

WARRANTY AND SUPPORT

For warranty information or technical support, please contact the manufacturer, CUISINE TALENT, or your retailer. Please have your model number (K08-WY601U) and purchase date available when contacting support.

For general inquiries, you may refer to the [product page on Amazon](#) for additional details or customer reviews.