
[Manuals.plus](#) /

› [OKP](#) /

› OKP K5 Robot Vacuum Cleaner User Manual

OKP K5

OKP K5 Robot Vacuum Cleaner User Manual

Model: K5 | Brand: OKP

INTRODUCTION

Thank you for choosing the OKP K5 Robot Vacuum Cleaner. This manual provides essential information for the safe operation, maintenance, and troubleshooting of your device. Please read it thoroughly before use to ensure optimal performance and longevity of your robot vacuum.




The OKP K5 Robot Vacuum Cleaner, shown with its charging dock and a smartphone displaying the control app. This image highlights the sleek design of the robot and its smart connectivity features.

SAFETY INFORMATION

To reduce the risk of injury or damage, read these safety instructions carefully and keep them handy for future reference.

- Do not operate the robot vacuum in wet environments or near water.
- Ensure the charging dock is placed on a level surface against a wall, with clear space around it.
- Keep loose cables, curtains, and other objects that could entangle the robot out of its path.
- Do not allow children or pets to play with the robot vacuum.
- Use only the original charger and accessories provided by OKP.
- Avoid using the robot vacuum to pick up large debris, liquids, or burning objects.
- The robot is equipped with anti-fall sensors. However, exercise caution near stairs or elevated surfaces.



The OKP K5 Robot Vacuum Cleaner is designed with anti-fall sensors to detect ledges and prevent accidental falls, ensuring safe operation near stairs or elevated areas.

PACKAGE CONTENTS

Verify that all items are present in the package:

- 1x OKP K5 Robot Vacuum Cleaner
- 1x Charging Dock
- 2x Side Brushes (additional pair)
- 1x User Manual
- 1x HEPA Filter (pre-installed)
- 1x Power Adapter



An overview of the items included in the OKP K5 Robot Vacuum Cleaner package, ensuring all components are present for initial setup.

SETUP

1. Charging Dock Placement

Place the charging dock against a wall on a hard, level surface. Ensure there is at least 1 meter (3 feet) of clear space in front of the dock and 0.5 meters (1.5 feet) on either side to allow the robot to return and dock successfully.

2. Initial Charge

Connect the power adapter to the charging dock and plug it into a wall outlet. Place the robot vacuum onto the charging dock, ensuring the charging contacts align. The robot will begin charging automatically. For first use, fully charge the robot (approximately 4-5 hours).

Retour automatique à la station de charge




The OKP K5 Robot Vacuum Cleaner automatically navigates back to its charging station when its battery is low or after completing a cleaning cycle, ensuring it's always ready for the next task.

3. Connecting to the OKP App

The OKP K5 can be controlled via the dedicated OKP app, available for smartphones. Follow these steps to connect:

1. Download the "OKP" app from your smartphone's app store (iOS or Android).
2. Register or log in to your account.
3. Ensure your phone's Bluetooth is activated.
4. In the app, select "Add Device" and choose the K5 model.
5. Turn on the robot vacuum's main power switch.
6. Press and hold the power button on the robot for 6 seconds until you hear a prompt.
7. Follow the in-app instructions to connect to your 2.4 GHz Wi-Fi network.
8. Wait for successful pairing.



Detailed steps for connecting the OKP K5 Robot Vacuum Cleaner to the OKP smartphone application, including Bluetooth activation, device selection, and Wi-Fi pairing.

OPERATING THE ROBOT VACUUM

Cleaning Modes

The OKP K5 offers multiple cleaning modes to suit different needs:

- **Automatic Cleaning:** The robot intelligently navigates and cleans the entire floor area.
- **Spot Cleaning:** Focuses on a specific dirty area, cleaning in a spiral pattern.
- **Edge Cleaning:** Cleans along walls and furniture edges.
- **Zig-zag Cleaning:** Covers larger areas efficiently in a systematic back-and-forth pattern.

Quatre modes de nettoyage



This image visually explains the four distinct cleaning modes of the OKP K5 Robot Vacuum: Spot, Edge, Random, and Automatic, demonstrating how the robot navigates for each specific cleaning task.

Smart Features

- **FreeMove 3.0 Obstacle Avoidance:** Advanced infrared sensors detect and avoid obstacles, walls, and stairs.
- **Automatic Recharging:** The robot automatically returns to its charging dock when the battery is low.
- **App Control:** Schedule cleanings, select cleaning modes, adjust suction power, and view cleaning maps via the OKP app.
- **Voice Control:** Compatible with Amazon Alexa and Google Assistant for hands-free operation.
- **Slim Design:** At 7cm (2.75 inches) tall, it can easily clean under furniture.

Technologie FreeMove 3.0

Détecte les obstacles dans le parcours de nettoyage
(Évite activement les obstacles)



The OKP K5 Robot Vacuum Cleaner utilizes FreeMove 3.0 technology to intelligently detect and navigate around obstacles, ensuring efficient and uninterrupted cleaning.

Capteur intelligent

Anti-collision

Franchissement d'obstacles

Anti-chute

This image showcases the intelligent sensor capabilities of the OKP K5, including anti-collision, ability to cross small obstacles like door thresholds, and anti-fall protection near stairs.

Application et commande vocale

Connectez-vous plus rapidement et plus facilement

"Alexa, allume K5"



Compatible avec
Amazon Alexa



Compatible avec
l'Google Assistant

The OKP K5 Robot Vacuum Cleaner supports voice control through Amazon Alexa and Google Assistant, allowing for convenient hands-free operation.

MAINTENANCE

Regular maintenance ensures your OKP K5 operates efficiently and extends its lifespan. Always turn off the robot and unplug the charging dock before performing any maintenance.

1. Emptying the Dustbin

Empty the dustbin after each cleaning cycle or when full. Press the dustbin release button, remove the dustbin, open its lid, and discard the collected debris. The K5 features a large dustbin capacity of 500ml.

2. Cleaning the Filter

The K5 uses a 3-layer filter system, including a high-performance HEPA filter. Tap the filter to remove loose dirt. For a deeper clean, you can gently brush off debris. Replace the HEPA filter every 3-6 months, depending on usage.

3. Cleaning Side Brushes

Regularly check and clean the side brushes for tangled hair or debris. If brushes are worn or damaged, replace them with new ones. The K5's brushless design minimizes hair entanglement compared to traditional roller brushes.



This image highlights the advantage of the OKP K5's brushless suction design, which prevents hair entanglement, compared to conventional robot vacuums with roller brushes that often get clogged with hair.

4. Cleaning Sensors and Charging Contacts

Wipe the anti-drop sensors, anti-collision sensors, and charging contacts on both the robot and the charging dock with a clean, dry cloth to ensure proper function.

TROUBLESHOOTING

If your OKP K5 is not functioning as expected, refer to the common issues and solutions below:

Problem	Possible Cause	Solution
Robot does not turn on.	Low battery; Power switch off.	Charge the robot; Ensure the main power switch is ON.
Robot cannot return to charging dock.	Dock is obstructed; Dock is unplugged; Robot is too far.	Clear obstructions around dock; Plug in dock; Manually place robot near dock.
Cleaning performance is poor.	Full dustbin; Clogged filter; Worn side brushes.	Empty dustbin; Clean/replace filter; Clean/replace side brushes.
Robot gets stuck frequently.	Loose cables; Small obstacles; Uneven surfaces.	Clear area of obstacles; Use virtual boundaries if available.
App connection issues.	Incorrect Wi-Fi password; 5GHz Wi-Fi; Robot not in pairing mode.	Verify password; Ensure 2.4GHz Wi-Fi; Re-enter pairing mode.

SPECIFICATIONS

Feature	Detail
Model	K5


Feature	Detail
Brand	OKP
Dimensions (L x W x H)	27.94 x 27.94 x 6.99 cm (11 x 11 x 2.75 inches)
Weight	3.14 kg (6.92 lbs)
Dustbin Capacity	500 Milliliters
Suction Power	Up to 2500 Pa (3 adjustable levels)
Battery Runtime	Up to 120 minutes
Noise Level	56 dB
Voltage	19.6 Volts
Power	19 Watts
Filter Type	HEPA Filter
Connectivity	Wi-Fi (2.4 GHz only), Bluetooth, App Control, Alexa, Google Assistant
Special Features	Anti-collision, Variable Suction Control, Ultrasonic Carpet Detection, Pet Hair Pickup, Obstacle Avoidance (FreeMove 3.0)

Puissance d'aspiration puissante

3 niveaux de réglage de la puissance d'aspiration



Plus d'enchevêtrement



The OKP K5 Robot Vacuum Cleaner boasts a powerful 2500 Pa suction, with three adjustable levels to effectively clean various surfaces from hard floors to carpets.

Ultra-sensible, ultra-silencieux

Conception ultra-mince de 7 cm, élimine facilement la saleté cachée



55db

7cm

The ultra-slim 7cm design of the OKP K5 allows it to easily clean under low-lying furniture like sofas, while operating at a quiet 55dB, minimizing disturbance.

WARRANTY AND SUPPORT

OKP products come with a standard warranty. For specific warranty details, please refer to the warranty card included in your product packaging or visit the official OKP website. For technical support, troubleshooting assistance, or to order replacement parts, please contact OKP customer service through the following channels:

- **OKP Official Website:** www.okprobot.com
- **Amazon Seller Page:** [OKP-FR Seller Page](#)
- **Customer Service Email:** Refer to your product manual or OKP website for contact email.

Please have your model number (K5) and purchase information ready when contacting support.

