TOZO A2

TOZO A2 Mini Wireless Earbuds User Manual

Model: A2

1. Product Overview

The TOZO A2 Mini Wireless Earbuds are designed for comfortable in-ear use, featuring Bluetooth 5.3 connectivity, a built-in microphone for calls, and IPX5 water resistance. This manual provides instructions for setup, operation, and maintenance.



Image: TOZO A2 Mini Wireless Earbuds and their charging case. The earbuds are white with a stem design, and the charging case is a compact white oval with indicator lights on the front.

2. Package Contents

Verify that all items are present in the package:

- TOZO A2 Mini Wireless Earbuds
- Charging Case

- Eartips (various sizes)
- USB-C (A to C) cable (30cm)
- User Manual

3. Setup Guide

3.1 Initial Charging

Before first use, fully charge the earbuds and the charging case.

1. Connect the provided USB-C cable to the charging port on the case and to a power source.
2. Place the earbuds into the charging case. The indicator lights on the case will show the charging status.
3. A full charge typically takes approximately 1 hour. The charging case provides up to 20 hours of additional playtime.



Image: Illustration of the TOZO A2 Mini Earbuds and charging case, highlighting the 20-hour total playtime. A single charge provides 5 hours, and the case has a 315 mAh battery capacity.

3.2 Pairing with Your Device

The earbuds support one-step pairing for convenience.

1. Open the charging case. The earbuds will automatically enter pairing mode.
2. On your device (smartphone, tablet, computer), navigate to the Bluetooth settings.
3. Search for available devices and select "TOZO-A2" from the list.
4. Once connected, a confirmation message will appear on your device. The earbuds will automatically reconnect to the last paired device when removed from the case.




Image: A visual guide demonstrating the one-step pairing process. The image shows the open charging case with earbuds, and a smartphone screen displaying successful Bluetooth connection to "TOZO-A2".

3.3 Wearing the Earbuds

For optimal sound quality and comfort, ensure a proper fit.

- Select the eartip size that provides a secure seal in your ear canal.
- Gently insert each earbud into your ear, rotating slightly until it feels snug and comfortable.
- The ergonomic design and lightweight construction (3.7g per earbud) are intended to provide a stable fit that does not protrude excessively.




Image: A person wearing a TOZO A2 Mini earbud, demonstrating the comfortable and secure in-ear fit. The image emphasizes the customizable in-ear design for optimal audio delivery.

4. Operating Instructions

4.1 Touch Controls

The TOZO A2 earbuds feature smart touch controls on each earbud for various functions:

- **Play/Pause:** Single tap on either earbud.
- **Next Song:** Double tap the right earbud.
- **Previous Song:** Double tap the left earbud.
- **Volume Up:** Triple tap the right earbud.
- **Volume Down:** Triple tap the left earbud.
- **Answer/End Call:** Single tap on either earbud.
- **Reject Call:** Press and hold either earbud for 2 seconds.

- **Activate Voice Assistant:** Press and hold either earbud for 3 seconds.

4.2 Call Functionality

The earbuds are equipped with a built-in microphone for clear communication.

- Ensure both earbuds are connected for optimal call quality.
- The microphone is designed to pick up your voice clearly during phone calls.



Image: A person wearing a TOZO A2 Mini earbud, demonstrating its use for making calls. The image highlights the clear call feature enabled by the built-in microphone.

4.3 Audio Experience

The TOZO A2 earbuds utilize 6mm dynamic drivers and advanced Bluetooth 5.3 technology for a stable and immersive sound experience.

- The 6mm diameter speakers provide a wide sound range with dynamic treble and powerful bass.
- Bluetooth 5.3 ensures a strong and stable connection up to 12 meters (approximately 39 feet).

- TOZO's ORIGX Acoustic technology aims to compensate for frequency loss in the ear canal, delivering sound close to its original form.



Image: A detailed cutaway view of a TOZO A2 Mini earbud, illustrating the internal components including the 6mm driver and the advanced Bluetooth 5.3 chip, emphasizing ORIGX Acoustic technology.

5. Maintenance

5.1 Cleaning

Regular cleaning helps maintain performance and hygiene.

- Use a soft, dry, lint-free cloth to wipe the earbuds and charging case.
- For eartips, remove them from the earbuds and clean with a mild soap solution, then rinse and dry thoroughly before reattaching.
- Avoid using abrasive materials, alcohol, or chemical cleaners.

5.2 Storage

Store the earbuds properly when not in use.

- Always store the earbuds in their charging case to protect them and keep them charged.
- Store in a cool, dry place away from extreme temperatures and direct sunlight.

6. Troubleshooting

If you encounter issues, try the following steps:

6.1 Earbuds Not Pairing/Connecting

- Ensure the earbuds are charged and removed from the charging case.
- Turn off and then on your device's Bluetooth.
- Forget/delete "TOZO-A2" from your device's Bluetooth list and attempt to re-pair.
- Place both earbuds back into the charging case, close the lid, wait a few seconds, then open the lid to reset.

6.2 No Sound from One Earbud

- Ensure both earbuds are charged.
- Try placing both earbuds back into the charging case, closing the lid, and then taking them out again.
- Perform a full reset of the earbuds (refer to the pairing section for steps, or consult TOZO support for specific reset instructions if needed).

6.3 Charging Issues

- Verify that the charging cable is securely connected to both the case and the power source.
- Ensure the charging contacts on the earbuds and inside the case are clean and free of debris.
- Try a different USB-C cable and power adapter.

7. Specifications

Feature	Specification
Model Name	A2
Bluetooth Version	5.3
Bluetooth Range	12 Meters
Ear Placement	In Ear
Water Resistance Level	IPX5 Waterproof
Battery Life (Earbuds)	5 Hours (single charge)
Total Playtime (with case)	20 Hours
Charging Time	1 Hour
Carrying Case Battery Capacity	315 mAh
Earbud Weight	3.7g (each)
Control Type	Touch

Microphone	Built-in
Audio Driver Size	6 Millimeters
Frequency Response	20Hz - 20,000Hz
Impedance	32 Ohm
Sensitivity	100 dB

8. Warranty and Support

8.1 Warranty Information

TOZO products typically come with a manufacturer's warranty. For specific details regarding your product's warranty period and terms, please refer to the warranty card included in your package or visit the official TOZO website.

8.2 Customer Support

If you require further assistance or have questions not covered in this manual, please contact TOZO customer support through their official website or the contact information provided in your product packaging.

You can also visit the TOZO Brand Store on Amazon for more product information and support resources.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question