

[Manuals.plus](#) /

› [Yawpet](#) /

› Yawpet Dog Training Collar User Manual

Yawpet B0BB7LJRZ2

Yawpet Dog Training Collar User Manual

Model: B0BB7LJRZ2

Your comprehensive guide to effective and humane dog training.

1. INTRODUCTION

Thank you for choosing the Yawpet Dog Training Collar. This device is designed to assist in training your dog effectively and humanely, helping to correct unwanted behaviors and reinforce positive ones. It features three safe and effective training modes: beep, vibration, and static stimulation, suitable for various training needs and dog sizes. Please read this manual thoroughly before use to ensure proper operation and the safety of your pet.

Before



Barking



Biting



Jumping



Chewing




Digging

KEEP UP THE GOOD BEHAVIOR!



After



Sit



Come



Stay



Follow

This image illustrates common dog behaviors before training (barking, biting, jumping, chewing, digging) and desired behaviors after training (sit, come, stay, follow), demonstrating the potential impact of effective training.

2. PACKAGE CONTENTS

- Remote Transmitter
- Receiver Collar
- Adjustable Nylon Strap
- USB Charging Cable (with dual charging head)
- Test Light Tool
- Short Contact Points (pre-installed)
- Long Contact Points (for dogs with thicker coats)
- User Manual (this document)

3. PRODUCT OVERVIEW



This image displays the Yawpet Dog Training Collar, showing both the remote transmitter and the receiver collar with its adjustable nylon strap.

3.1 Remote Transmitter

- **LCD Display:** Shows battery level, mode, intensity level, and channel.
- **Beep Button:** Activates an audible tone.
- **Vibration Button:** Activates vibration mode.
- **Shock Button:** Activates static stimulation mode.
- **+/- Buttons:** Adjust vibration (1-3 levels) and shock (1-99 levels) intensity.
- **Channel Button:** Switches between up to 4 receiver channels.
- **Security Keypad Lock:** Prevents accidental presses.
- **Charging Port:** For recharging the remote.

3.2 Receiver Collar

- **Contact Points:** Deliver static stimulation (short and long available).
- **Indicator Light:** Shows power status, charging status, and mode activation.
- **Charging Port:** For recharging the receiver.
- **Power Button:** Turns the receiver on/off and is used for pairing.
- **IPX7 Waterproof:** Designed to withstand water immersion, suitable for swimming.

4. SETUP AND INITIAL USE



This image illustrates the four key steps for initial setup: turning on the receiver, turning on the remote control, matching the receiver with the remote, and testing the vibration function.

4.1 Charging the Devices

Before first use, fully charge both the remote transmitter and the receiver collar. Use the provided USB charging cable. The indicator light on the receiver will be red during charging and turn green when fully charged. The remote's display will show a full battery icon. Charging typically takes 2-3 hours. The receiver can last up to 35 days on standby, and the remote up to 45 days.

4.2 Attaching the Collar

1. Thread the nylon strap through the receiver unit.
2. Ensure the contact points are securely attached. For dogs with thicker coats, use the longer contact points provided.

4.3 Fitting the Collar

Proper fit is crucial for effective and safe operation. The collar should fit snugly, allowing two fingers to slide comfortably between the strap and your dog's neck. Avoid overtightening, which can cause skin irritation, or leaving it too loose, which can reduce effectiveness and allow the receiver to move around.

4.4 Pairing the Receiver with the Remote

1. Turn on the Receiver: Press and hold the power button on the receiver until the indicator light flashes.
2. Turn on the Remote Control: Press any button on the remote to activate its display.
3. Match the Receiver with the Remote: Within 10 seconds of turning on the receiver, press and hold the Beep button on the remote. The receiver's indicator light will flash rapidly, then become solid, indicating successful pairing.
4. If pairing fails, turn off both devices and repeat the process.

4.5 Testing the Functions

To ensure all functions are working correctly:

- **Beep:** Press the Beep button on the remote. The receiver should emit an audible tone.
- **Vibration:** Press the Vibration button. The receiver should vibrate. Adjust intensity with +/- buttons.
- **Shock:** Attach the provided test light tool to the contact points on the receiver. Press the Shock button. The test light should illuminate, indicating the static stimulation is working. Adjust intensity with +/- buttons.

5. OPERATING MODES

The Yawpet training collar offers three distinct training modes to suit various behavioral correction needs.

5.1 Beep Mode (Standard)

This mode delivers an audible tone from the receiver collar. It is ideal for gaining your dog's attention or as a warning signal before applying a stronger correction. It's a gentle, non-physical cue.

5.2 Vibration Mode (1-3 Levels)

The receiver collar vibrates, providing a physical cue to your dog. This mode is effective for dogs that respond well to tactile stimulation. You can adjust the intensity from level 1 (mild) to level 3 (stronger) using the +/- buttons on the remote.

5.3 Static Stimulation Mode (1-99 Levels)

This mode delivers a safe, momentary static pulse. It should be used as a last resort or for more stubborn behaviors, always starting at the lowest effective level. The intensity can be adjusted from 1 to 99 using the +/- buttons on the remote. Always observe your dog's reaction and use the lowest level that elicits a response.

5.4 Security Keypad Lock

The remote features a security keypad lock to prevent accidental activation of training modes. To lock/unlock, slide the lock switch on the side of the remote. This is particularly useful when carrying the remote in your pocket or bag.

5.5 Remote Control Range

The remote control offers an impressive range of up to 1600 feet (approximately 487 meters), allowing for effective training both indoors and outdoors, even in open areas.

6. SAFETY GUIDELINES AND IMPORTANT CONSIDERATIONS

- **Not for Aggressive Dogs:** Do not use this product on aggressive dogs. Consult a professional dog trainer for such cases.
- **Age and Health:** This collar is suitable for dogs weighing 8-110 lbs with neck sizes from 8 to 25 inches. Do not use on puppies under 6 months old or dogs with health issues.
- **Collar Duration:** Do not leave the collar on your dog for more than 12 hours per day. Prolonged wear can lead to skin irritation or pressure sores.
- **Skin Checks:** Regularly check your dog's neck for any signs of irritation, redness, or sores, especially in the area of the contact points. If irritation occurs, discontinue use and consult a veterinarian.
- **Supervised Use:** Always supervise your dog when the collar is in use.
- **Avoid Over-Correction:** Use the lowest effective stimulation level. Over-correction can cause stress or fear in your dog.
- **Training, Not Punishment:** This tool is for training and behavior modification, not punishment. Use it consistently and in conjunction with positive reinforcement.

7. MAINTENANCE

- **Cleaning:** Clean the receiver collar and contact points regularly with a damp cloth. Ensure the charging port cover is securely closed before cleaning or exposing to water.
- **Battery Care:** Recharge the devices when the battery indicator is low. Avoid fully depleting the battery frequently to prolong its lifespan.
- **Storage:** Store the collar and remote in a cool, dry place when not in use.
- **Contact Points:** Periodically check the contact points for wear and tear. Replace if necessary.

8. TROUBLESHOOTING

Problem	Possible Cause	Solution
Collar not responding to remote.	Not paired, low battery, out of range.	Re-pair devices. Charge both devices. Ensure within 1600ft range.
No static stimulation.	Contact points not touching skin, intensity too low, low battery.	Adjust collar fit. Increase intensity. Charge receiver. Use longer contact points for thick-coated dogs.

Problem	Possible Cause	Solution
Receiver indicator light not on.	Receiver off, low battery.	Press power button to turn on. Charge receiver.
Short battery life.	Frequent use, aging battery.	Ensure full charge. Reduce frequency of high-intensity modes. Battery lifespan naturally decreases over time.

9. SPECIFICATIONS

- **Model:** B0BB7LJRZ2
- **Brand:** Yawpet
- **Training Modes:** Beep, Vibration (1-3 levels), Static Stimulation (1-99 levels)
- **Waterproof Rating:** IPX7 (Receiver Collar)
- **Remote Range:** Up to 1600 feet (approx. 487 meters)
- **Adjustable Collar Size:** 8 to 25 inches (for dogs 8-110 lbs)
- **Battery Life (Standby):** Receiver up to 35 days, Remote up to 45 days
- **Charging Time:** 2-3 hours
- **Material:** Durable Nylon strap
- **Item Weight:** 8.8 ounces
- **Manufacturer:** Shenzhen Kensonic Intelligent Technology Co.,Ltd.
- **First Available Date:** August 22, 2022

10. WARRANTY AND SUPPORT

Yawpet is committed to providing high-quality products. This product comes with a standard manufacturer's warranty against defects in materials and workmanship. For detailed warranty information, technical support, or any questions regarding the use of your training collar, please contact Yawpet customer service through the retailer's platform or visit the official Yawpet store online. Please retain your proof of purchase for warranty claims. For further assistance, you may visit the [Yawpet Store on Amazon](#).

© 2023 Yawpet. All rights reserved.

This manual is for informational purposes only. Product specifications are subject to change without notice.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question