

[Manuals.plus](#) /

› [ZJYWSCH](#) /

› ZJYWSCH Griddle Cover Instruction Manual

ZJYWSCH WC044

ZJYWSCH Griddle Cover Instruction Manual

Model: WC044

1. INTRODUCTION

This manual provides instructions for the proper use, installation, and maintenance of your ZJYWSCH Griddle Cover. Designed to protect your outdoor griddle from various environmental elements, this cover ensures the longevity and cleanliness of your appliance. Please read these instructions carefully before first use.



The ZJYWSCH Griddle Cover, shown installed on a griddle, providing full protection.

2. PRODUCT OVERVIEW

The ZJYWSCH Griddle Cover is constructed from durable materials to offer comprehensive protection for your griddle. Key features include:

- **Durable Material:** Made with heavy-duty 600D polyester with a waterproof PVC coating.
- **Weather Resistant:** Designed to resist rain, snow, UV rays, fading, tearing, and cold cracking.
- **Secure Fit:** Features additional Velcro closure straps for a snug and secure fit.
- **Easy Maintenance:** Simple to clean with a damp cloth or hose.

Material Construction



A diagram illustrating the multi-layered construction of the cover, including 600D polyester oxford fabric and qualified PVC coating for enhanced durability and weather resistance.



Close-up view of the cover's waterproof fabric, demonstrating its ability to repel water droplets.

3. COMPATIBILITY

This griddle cover is designed to fit a range of Blackstone griddle models. Please verify your griddle's dimensions and model number against the list below to ensure a proper fit.

Cover Dimensions: 62"W x 25"D x 37.5"H

Suitable for:

- Blackstone Culinary 30 inch Griddle Flat Top Grill (Models: 1934, 2092, 2163, 2257)
- Blackstone ProSeries 28 inch Griddle Grill (Models: 1855, 1858, 1886, 1901, 2007, 2080, 2104, 2152, 2316, 2342)
- Blackstone 28 inch Griddle with Air Fryer Combo Grill (Models: 1785, 1962)
- Other griddle grills with similar dimensions.

Note: This cover does **not** fit the Blackstone 28" rangetop griddle.

GRILL COVER SIZE

Cover Size: 62"W x 25"D x 37.5"H

Suitable for Blackstone 30" Griddle, Culinary 30" XL w/Air Fryer, Proseries 3-Burner 28" XL, 28 inch 3 Burner Griddle, 28" Griddle w/Air Fryer Combo, 28" Griddle w/Cabinet



Fits for Blackstone Griddle Model: 1785 1855 1858 1886 1901 1934 1962 2007 2080 2092 2104 2152 2163 2257 2316

*Please check your grill size before purchasing.

*Always choose a cover that is 2-3 inches larger than your grill.

Visual guide detailing the cover's dimensions and listing compatible Blackstone griddle models.

Model Guide



1858



1785



1934



2007

Images of various Blackstone griddle models (1858, 1785, 1934, 2007) to assist with compatibility identification.

4. SETUP AND INSTALLATION

Follow these steps to properly install your ZJYWSCH Griddle Cover:

1. Ensure your griddle is completely cool and clean before covering.
2. Carefully drape the cover over your griddle, aligning the top and sides.
3. Pull the cover down evenly until it fully covers the griddle, reaching the base.
4. Locate the Velcro closure straps on both sides of the cover.
5. Securely fasten the Velcro straps to tighten the cover around the griddle, preventing it from slipping or blowing off in windy conditions.



Detail of the Velcro strap, designed to secure the cover firmly to the griddle.

5. OPERATING AND USAGE

The ZJYWSCH Griddle Cover is designed for straightforward use. Once installed, it provides continuous protection. For optimal performance:

- Always ensure the griddle is cool before applying the cover to prevent damage to the cover material.
- Periodically check the Velcro straps to ensure they remain securely fastened, especially during periods of high wind.
- Remove any accumulated snow or debris from the top of the cover to prevent excessive weight and potential damage.

6. MAINTENANCE

Proper maintenance will extend the life of your griddle cover:

- 1. **Cleaning:** To clean the cover, simply wipe it with a damp cloth. For more stubborn dirt, you can hose it down with water.
- 2. **Drying:** After cleaning, allow the cover to air dry completely in the sun before storing or reapplying it to the griddle.
- 3. **Storage:** If storing the cover for an extended period, ensure it is clean and dry, then fold it neatly and store it in a cool, dry place away from direct sunlight.

7. TROUBLESHOOTING

Here are solutions to common issues you might encounter:

- **Cover blows off in wind:** Ensure the Velcro straps are tightly secured around the griddle's legs or frame. If the griddle is on wheels, consider locking the wheels for added stability.
- **Water pooling on top:** While the cover is waterproof, prolonged pooling can stress the fabric. Ensure the cover is taut and consider placing a small object (like an inverted bowl) under the cover's center to create a slight dome, allowing water to run off.
- **Fading or material degradation:** While UV resistant, extreme prolonged exposure to direct sunlight can affect any material over time. Ensure the cover is cleaned regularly to remove corrosive elements.

8. SPECIFICATIONS

Attribute	Detail
Brand	ZJYWSCH
Model Number	WC044
Material	Polyester, Polyvinyl Chloride (600D Heavy Duty)
Color	Black
Product Dimensions (L x W x H)	62" x 25" x 37.5"
Closure Type	Hook and Loop (Velcro Straps)
Item Weight	3.83 pounds
Manufacturer	Shenzhen ZJYWSCH
UPC	735209760133

9. IMPORTANT SAFETY INFORMATION

CAUTION: To ensure longevity, avoid exposing the cover to prolonged sunlight or extreme heat. After washing, ensure the cover is completely dry before storing.

10. WARRANTY AND SUPPORT

ZJYWSCH products are manufactured to high-quality standards. For information regarding product warranty or customer support, please refer to the retailer's return policy or contact the seller directly through your purchase platform. Keep your proof of purchase for any warranty claims.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0BB9K36XK>

More documents and user manuals: <https://manuals.plus/>