

AIDITIYMI 6711A90032L

AIDITIYMI 6711A90032L Replacement Remote Control User Manual

For LG Window-Type Room Air Conditioners

INTRODUCTION

This manual provides comprehensive instructions for the AIDITIYMI 6711A90032L replacement remote control. This remote is designed to operate various LG Window-Type Room Air Conditioner models, offering a direct replacement without the need for programming. Please read this manual thoroughly to ensure proper usage and maintenance of your remote control.

SETUP

Battery Installation

The remote control requires two (2) 1.5V AAA alkaline batteries for operation. Follow these steps to install the batteries:

1. Locate the battery compartment on the back of the remote control.
2. Slide the battery compartment cover downwards and remove it.
3. Insert two new AAA batteries, ensuring the positive (+) and negative (-) terminals match the diagrams inside the compartment.
4. Replace the battery compartment cover by sliding it back into place until it clicks securely.

Note: No programming or pairing is required. Once batteries are installed, the remote is ready for use with compatible LG Air Conditioner models.



This image illustrates the back of the AIDITIYMI 6711A90032L remote control. The battery compartment cover is removed, clearly showing the two slots designed for AAA batteries, along with the positive and negative terminals.

OPERATING INSTRUCTIONS

Point the remote control directly at the air conditioner's receiver. Ensure there are no obstructions between the remote and the air conditioner.



This image displays the front of the AIDITIYMI 6711A90032L remote control. It features a digital display at the top and various buttons for controlling an LG air conditioner, including power, mode, fan speed, and temperature adjustments.

Button Functions

- **Power Button (|):** Turns the air conditioner ON or OFF.
- **Mode Button (Sun/Rain/Snowflake/Fan icon):** Cycles through operating modes (e.g., Cool, Heat, Fan, Dry, Auto).
- **Temperature Adjustment (Up/Down arrows):** Increases or decreases the set temperature.
- **Fan Speed Button (Fan icon):** Adjusts the fan speed (e.g., Low, Medium, High, Auto).
- **Swing Button (Airflow icon):** Activates or deactivates the air swing function.
- **PLASMA Button:** Activates or deactivates the Plasma filter function (if available on your AC model).
- **ON-OFF Timer Button:** Sets the timer for the air conditioner to turn ON or OFF automatically.

- **SET Button:** Confirms timer settings or other advanced options.
- **CANCEL Button:** Cancels current timer settings or other operations.
- **AUTO CLEAN Button:** Initiates the auto-clean function for the indoor unit (if available).
- **RESET Button:** Resets the remote control to default settings.
- **2ndF Button:** Accesses secondary functions, typically used in combination with other buttons.



This image shows the AIDITIYMI 6711A90032L remote control with its protective lower cover slid open. This reveals secondary function buttons such as PLASMA, ON-OFF timer, SET, CANCEL, and AUTO CLEAN, providing access to advanced air conditioner settings.

MAINTENANCE

Battery Replacement

Replace batteries when the remote control's range decreases or if the display becomes dim. Always replace both batteries simultaneously with new AAA alkaline batteries. Do not mix old and new batteries, or different types of batteries.

Cleaning

Wipe the remote control with a soft, dry cloth. Do not use liquid cleaners, abrasive materials, or chemical solvents, as these can damage the remote's surface or internal components.

TROUBLESHOOTING

- **Remote not responding:**

- Check if the batteries are installed correctly with the correct polarity.
- Replace old batteries with new ones.
- Ensure there are no obstructions between the remote control and the air conditioner's receiver.
- Confirm the remote is pointed directly at the air conditioner.

- **Limited range:**

- Replace batteries.
- Ensure the remote is within the maximum operating range (approximately 32 feet).

- **Air conditioner not performing desired function:**

- Verify that the air conditioner model is listed as compatible with this remote control.
- Some advanced functions may require specific air conditioner models to be supported. Refer to your air conditioner's manual.

SPECIFICATIONS

Brand	AIDITIYMI
Model Number	6711A90032L (ADSUNCTY-6711A90032L-AD01)
Compatible Devices	LG Window-Type Room Air Conditioners (various models including LS-C/H/Q/J/R/L/T/K series, AS-C/H series, S/G series)
Connectivity Technology	Infrared
Battery Type	2 x AAA (Alkaline recommended)
Maximum Range	32 Feet
Button Quantity	15
Item Dimensions (L x W x H)	8"L x 2"W x 0.6"H
Item Weight	2.88 ounces

WARRANTY AND SUPPORT

Warranty Information

This AIDITIYMI remote control comes with a 1-year warranty from the date of purchase. This warranty covers manufacturing defects under normal use. It does not cover damage caused by misuse, accidents, unauthorized modifications, or battery leakage.

Customer Support

For any questions, technical assistance, or warranty claims, please contact the AIDITIYMI customer support. Refer to your purchase documentation for specific contact details or visit the manufacturer's official website.