Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

ChooChoo ET20002-E-S

ChooChoo Nightstand with Charging Station Instruction Manual

Model: ET20002-E-S

Product Overview

The ChooChoo Nightstand is a versatile bedside or end table designed for small spaces, featuring a built-in charging station with AC outlets and USB ports. It includes a drawer for storage and a metal shelf for additional organization. This manual provides detailed instructions for assembly, operation, maintenance, and troubleshooting.



Image: Two ChooChoo Nightstands, showcasing their rustic grey wood finish and black metal frames. The integrated power cords are visible, indicating the charging station feature.

Safety Information

Please read all safety warnings and instructions carefully before assembly and use. Keep this manual for future reference.

- Do not overload the charging station. Ensure total current draw does not exceed specified limits.
- Keep liquids away from the charging station and electrical components.
- Ensure all screws and fasteners are securely tightened before use. Periodically check and re-tighten as needed.
- Do not stand or sit on the nightstand.
- Place the nightstand on a flat, stable surface to prevent tipping.

Package Contents

Verify all components are present before beginning assembly. If any parts are missing or damaged, contact customer support.

Part	Description	Quantity
A	Tabletop with Charging Station	1

Part	Description	Quantity
B	Drawer Front Panel	1
C	Drawer Side Panels	2
D	Drawer Back Panel	1
E	Drawer Bottom Panel	1
F	Metal Frame Legs	4
G	Metal Bottom Shelf	1
H	Hardware Pack (Screws, Allen Wrench, etc.)	1

Setup and Assembly

Follow these steps carefully for proper assembly. It is recommended to assemble on a soft, clean surface to prevent scratches.

1. ### Step 1: Assemble the Drawer

   Connect the drawer side panels (C) and back panel (D) to the drawer front panel (B) using the provided screws from the hardware pack (H). Slide the drawer bottom panel (E) into the grooves. Ensure all connections are snug.



Image: A close-up view of the nightstand's top surface, illustrating the hidden charging station with its lid open, revealing two AC outlets and two USB ports. A smartphone is shown charging, demonstrating the functionality.

2. ### Step 2: Attach Metal Frame Legs

   Attach the four metal frame legs (F) to the tabletop (A) using the designated screws. Do not fully tighten yet.

3. ### Step 3: Install Bottom Metal Shelf

   Secure the metal bottom shelf (G) to the lower section of the metal frame legs (F). Once the shelf is in place, fully tighten all screws from Step 2 and Step 3.



Image: A composite image highlighting key features: a groove for cable management, the robust steel frame construction, the pleasing texture of the wood-look surface, and a close-up of the integrated power outlet.

4. **Step 4: Insert Drawer**

   Carefully slide the assembled drawer into the designated slot under the tabletop. Ensure it slides smoothly.

5. **Step 5: Connect Power**

   Plug the 6.5 ft extension cord from the charging station into a standard 120V AC wall outlet.



Image: The ChooChoo Nightstand positioned next to an armchair in a living room, demonstrating its use as an end table. A smartphone is actively charging on its surface, highlighting the convenience of the built-in charging station.

Operating Instructions

Using the Charging Station

The nightstand is equipped with 2 AC outlets and 2 USB ports for convenient charging of your electronic devices.

- Lift the hinged lid on the tabletop to access the charging outlets.
- Plug your devices into the appropriate AC or USB ports.
- Close the lid when not in use or to keep cables tidy. The tabletop features a groove for cable management, allowing cables to exit with the lid closed.



Image: The ChooChoo Nightstand placed beside a bed in a bedroom. The tabletop holds a lamp, a picture frame, and a charging smartphone. The drawer is slightly ajar, revealing internal storage space.

Drawer and Shelf Usage

- The integrated drawer provides concealed storage for personal items.

- The metal bottom shelf offers additional open storage space for books, magazines, or decorative items.

Maintenance and Care

- **Cleaning:** Wipe surfaces with a soft, damp cloth. Avoid harsh chemicals or abrasive cleaners.
- **Dusting:** Regularly dust the nightstand to prevent buildup.
- **Fasteners:** Periodically check all screws and connections to ensure they remain tight. Re-tighten if necessary to maintain stability.
- **Electrical Components:** Do not attempt to service the charging station yourself. If issues arise, contact qualified personnel.

Troubleshooting

Problem	Possible Cause	Solution
Charging station not working	Not plugged in; outlet issue; overloaded circuit.	Ensure the power cord is securely plugged into a working wall outlet. Check if the wall outlet has power by plugging in another device. Reduce the number of devices connected to the charging station.
Nightstand is wobbly	Loose fasteners; uneven floor.	Check and tighten all assembly screws. Move the nightstand to a level surface or use furniture pads to stabilize.
Drawer sticks or doesn't slide smoothly	Improper assembly; debris in runners.	Ensure the drawer was assembled correctly and is aligned with the runners. Check for any obstructions or debris in the drawer slides and remove them.

Specifications

- **Model:** ET20002-E-S
- **Dimensions (L x W x H):** 15.75" x 15.75" x 23.62" (40cm x 40cm x 60cm)
- **Weight:** Approximately 19.5 lbs (8.85 kg)
- **Material:** Engineered Wood, Metal
- **Color:** Grey
- **Charging Station:** 2 AC Outlets (120V/12A), 2 USB Ports (5V/2A)
- **Power Cord Length:** 6.5 ft



Image: A technical diagram illustrating the key dimensions of the ChooChoo Nightstand, including its length (15.7 inches), width (15.7 inches), and height (23.6 inches), along with the internal drawer dimensions.

Warranty and Support

ChooChoo stands behind the quality of its products. For any questions, missing parts, or issues, please contact ChooChoo customer service. Refer to your purchase documentation for specific warranty details.

Customer Service: Please refer to the contact information provided with your product packaging or visit the official ChooChoo website.

Returns: This product is eligible for 30-day easy returns. Please refer to the retailer's return policy for details.

© 2023 ChooChoo. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0BBG2CQ34

More documents and user manuals: **https://manuals.plus/**