

GiveBest PTC-906EO

GiveBest Digital Space Heater User Manual

Model: PTC-906EO

Brand: GiveBest

1. INTRODUCTION

This manual provides essential information for the safe and efficient operation of your GiveBest Digital Space Heater, model PTC-906EO. This portable electric heater offers 1500W/750W heating, an ECO mode, and a fan-only option, designed for indoor use. It features rapid heating, a digital display, and multiple safety protections. Please read all instructions carefully before use and retain this manual for future reference.

2. IMPORTANT SAFETY INSTRUCTIONS

When using electrical appliances, basic precautions should always be followed to reduce the risk of fire, electric shock, and injury to persons, including the following:

- Read all instructions before using this heater.
- This heater is hot when in use. To avoid burns, do not let bare skin touch hot surfaces. Use handles when moving this heater. Keep combustible materials, such as furniture, pillows, bedding, papers, clothes, and curtains at least 3 feet (0.9 m) from the front of the heater and keep them away from the sides and rear.
- Extreme caution is necessary when any heater is used by or near children or invalids and whenever the heater is left operating and unattended.
- Always unplug heater when not in use.
- Do not operate any heater with a damaged cord or plug or after the heater malfunctions, has been dropped or damaged in any manner. Discard heater, or return to authorized service facility for examination and/or repair.
- Do not use outdoors.
- This heater is not intended for use in bathrooms, laundry areas and similar indoor locations. Never locate heater where it may fall into a bathtub or other water container.
- Do not run cord under carpeting. Do not cover cord with throw rugs, runners, or similar coverings.

Arrange cord away from traffic area and where it will not be tripped over.

- To disconnect heater, turn controls to off, then remove plug from outlet.
- Do not insert or allow foreign objects to enter any ventilation or exhaust opening as this may cause an electric shock or fire, or damage the heater.
- To prevent a possible fire, do not block air intakes or exhaust in any manner. Do not use on soft surfaces, like a bed, where openings may become blocked.
- This heater has hot and arcing or sparking parts inside. Do not use it in areas where gasoline, paint, or flammable liquids are used or stored.
- Use this heater only as described in this manual. Any other use not recommended by the manufacturer may cause fire, electric shock, or injury to persons.
- Always plug heaters directly into a wall outlet/receptacle. Never use with an extension cord or relocatable power tap (outlet/power strip).
- This heater includes an **Overheat Protection** feature that automatically shuts off the unit if it overheats.
- A **Tip-Over Protection** switch automatically turns off the heater if it is accidentally knocked over.
- The heater also includes a **24H Unattended Auto Off** function for added safety.
- The product is **ETL Listed**, ensuring it meets recognized safety standards.



Image: The GiveBest Digital Space Heater in operation, showing heat being emitted from the front grille.



Image: Visual representation of the heater's safety features: V0 Flame Retardancy, Tip-over Protection, Overheat Protection, and 24H Unattended Auto Off, with a 'Safety Certified' badge.

3. PRODUCT OVERVIEW

The GiveBest Digital Space Heater is a compact and portable heating solution designed for personal spaces. Its dimensions are 6.1 inches (D) x 7.8 inches (W) x 10.1 inches (H), and it weighs approximately 3 pounds, making it easy to move with its built-in carry handle. The unit features a digital display for easy temperature and mode adjustments.



Image: The GiveBest Digital Space Heater showcasing its compact dimensions (10.1"H, 6.1"D, 7.8"W) and the integrated easy-to-carry handle.

Key Features:

- **Instant Safe and Stable Heating:** Equipped with PTC heating elements for rapid and consistent warmth.
- **4 Modes in 1:** Includes 1500W (High), 750W (Low), ECO (Economical), and Fan-only modes.
- **Quiet Operation:** Operates at a noise level below 45 decibels, suitable for bedrooms and offices.
- **Digital Display:** High-definition display for clear readings in various lighting conditions.
- **Portable Design:** Lightweight with a built-in handle for easy relocation.

Noiseless Companion

Low-noise operation makes you sleep well
and work better



Image: The GiveBest Digital Space Heater positioned beside a bed where a child is sleeping, illustrating its low-noise operation. An accompanying graph compares its sound level (below 50dB) to other heaters.

4. SETUP

1. **Unpacking:** Carefully remove the heater from its packaging. Retain packaging for off-season storage.
2. **Placement:** Place the heater on a firm, level surface. Ensure there is at least 3 feet (0.9 meters) of clearance from any walls, furniture, curtains, or other combustible materials. Do not place the heater on soft surfaces like rugs or carpets that could block the air intake.
3. **Power Connection:** Plug the heater directly into a standard 120 Volt AC, 60 Hz electrical outlet. Do not use extension cords, power strips, or surge protectors with this appliance. Ensure the outlet is not overloaded with other high-wattage devices.
4. **Initial Check:** Before first use, inspect the power cord and plug for any signs of damage. If any damage is found, do not operate the heater and contact customer support.

5. OPERATING INSTRUCTIONS

The GiveBest Digital Space Heater features an intuitive control panel with a digital display.




Image: The GiveBest Digital Space Heater illustrating its four operating modes: High heat, Low heat, Fan-only, and ECO mode.

Control Panel:

- **Power Button:** Turns the heater ON or OFF.
- **Mode Button:** Cycles through the available heating and fan modes.
- **Temperature Adjustment Buttons (+/-):** Increases or decreases the desired temperature setting.
- **Timer Button:** Sets the auto-off timer.

Operating Modes:

1. **High Heat (1500W):** Provides maximum heating output for quick warming of a room.
2. **Low Heat (750W):** Offers a lower heating output for sustained warmth or smaller spaces.
3. **ECO Mode:** The heater automatically adjusts its power consumption (between 750W and 1500W) to maintain a set temperature, optimizing energy efficiency.
4. **Fan Mode:** Operates as a fan without heat, circulating air.

Setting the Temperature:

In High, Low, or ECO modes, use the temperature adjustment buttons to set your desired room temperature. The digital display will show the set temperature. The heater will cycle on and off to maintain this temperature.

Using the Timer:

Press the Timer button to activate the auto-off timer. Each press will increase the timer duration. The heater will automatically turn off once the set time has elapsed. The timer can be set for up to 24 hours.

6. MAINTENANCE

Regular maintenance ensures optimal performance and longevity of your heater.

Cleaning:

1. Always turn off the heater and unplug it from the wall outlet before cleaning.
2. Allow the heater to cool down completely.
3. Use a soft, damp cloth to wipe the exterior surfaces of the heater. Do not use abrasive cleaners or solvents.
4. Gently vacuum or wipe the air intake and exhaust grilles to remove dust and lint. Do not allow water to run into the interior of the heater.
5. Ensure the heater is completely dry before plugging it back in and operating.

Storage:

When not in use, store the heater in a cool, dry location. It is recommended to store it in its original packaging to protect it from dust and damage.

7. TROUBLESHOOTING

If you experience issues with your heater, please refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Heater does not turn on.	No power to the unit. Tip-over switch activated. Overheat protection activated.	Ensure the power cord is securely plugged into a working outlet. Place the heater on a firm, level surface. Unplug the heater, let it cool for 10-15 minutes, then plug it back in.
Heater is on but not producing heat.	Fan-only mode selected. Temperature setting is too low.	Press the Mode button to select a heat setting (High, Low, or ECO). Increase the desired temperature using the '+' button.

Problem	Possible Cause	Solution
Heater suddenly turns off.	Overheat protection activated. Tip-over switch activated. Timer has expired. 24H Unattended Auto Off activated.	Unplug and allow to cool, then check for obstructions. Ensure the heater is upright on a stable surface. Check the timer setting and reset if necessary. If left unattended for 24 hours, the unit will turn off. Restart as needed.
Reduced airflow or heating efficiency.	Dust or lint blocking air inlets/outlets.	Unplug the heater and clean the grilles as described in the Maintenance section.

If the problem persists after attempting these solutions, please contact customer support.

8. SPECIFICATIONS

Feature	Specification
Brand	GiveBest
Model Number	PTC-906EO
Power Settings	1500W / 750W
Voltage	120 Volts
Product Dimensions (D x W x H)	6.1" x 7.8" x 10.1"
Item Weight	3 pounds
Heating Coverage	Up to 200 sq.ft
Max Temperature Setting	95 Degrees Fahrenheit
Fuel Type	Electric
Burner Type	High-efficient PTC
Special Features	Digital Display, Energy Efficient, On Off Timer, Overheat Protection, Tip-over Protection, 24H Unattended Auto Off, Portable, Digital Thermostat
Indoor/Outdoor Usage	Indoor
UPC	630128803810

9. WARRANTY AND SUPPORT

For technical assistance, warranty information, or to report any issues with your GiveBest Digital Space Heater, please contact GiveBest customer service. Please have your model number (PTC-906EO) and purchase details available when contacting support.

While specific warranty terms are not detailed in this manual, GiveBest is committed to product quality and customer satisfaction. Please refer to your purchase documentation or the official GiveBest website for the most current warranty policy.

© 2025 GiveBest. All rights reserved.