Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

DOMO DO9252I

DOMO DO9252I Ice Cream and Yogurt Maker User Manual

Model: DO9252I | Brand: DOMO

1. Introduction

The DOMO DO9252I Ice Cream and Yogurt Maker is a versatile appliance designed for preparing homemade ice cream, gelato, sorbet, and yogurt. Featuring an integrated compressor, a quiet DC motor, and an intuitive XL Smart-Touch display, this machine simplifies the process of creating delicious frozen desserts and fresh yogurt. Its durable stainless steel housing and removable 1.5-liter stainless steel bowl ensure ease of use and cleaning. The appliance offers four automatic programs and allows for individual adjustment of stirring speed and hardness, providing precise control over the texture of your creations.

2. Safety Instructions

- Read all instructions before using the appliance.
- Ensure the voltage indicated on the appliance matches your local mains voltage before connecting.
- Do not immerse the appliance, cord, or plug in water or other liquids.
- Keep hands and utensils out of the freezer bowl during operation to reduce the risk of injury to persons or to the appliance itself.
- Unplug from outlet when not in use, before putting on or taking off parts, and before cleaning.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been dropped or damaged in any manner.
- The use of accessory attachments not recommended by the manufacturer may cause fire, electric shock, or injury.
- Do not use outdoors.
- Do not let cord hang over edge of table or counter, or touch hot surfaces.
- Do not place on or near a hot gas or electric burner, or in a heated oven.
- Always ensure the lid is securely in place before operating.
- This appliance is for household use only.

3. Product Components

Familiarize yourself with the main components of your DOMO DO9252I Ice Cream and Yogurt Maker.



Figure 3.1: The DOMO DO9252I Ice Cream and Yogurt Maker, showcasing its sleek design and the digital display. Two bowls of freshly made ice cream and a small jar of yogurt are placed in front of the machine, demonstrating its versatility.



Figure 3.2: A diagram illustrating the dimensions of the DOMO DO9252I. The machine measures approximately 40 cm in length, 27

cm in width, and 26.5 cm in height, highlighting its compact design.



Figure 3.3: A side view of the appliance, clearly showing the ventilation grilles essential for the integrated compressor's operation and heat dissipation.

Figure 3.4: Included accessories: a clear plastic measuring cup for precise ingredient measurement and a white plastic spatula for serving or scraping the bowl.




Figure 3.5: The white plastic mixing paddle, designed to churn and aerate the ingredients during the ice cream making process.



Figure 3.6: An overhead view of the appliance, showing the transparent lid in place, allowing visibility of the mixing process. The mixing paddle is visible through the lid.



Figure 3.7: Another overhead view, this time showing the ice cream mixture actively being churned inside the bowl, demonstrating the machine in operation.





Figure 3.8: The removable 1.5-liter stainless steel bowl, featuring a convenient handle for easy lifting and cleaning. This bowl is where the ice cream or yogurt is prepared.



Figure 3.9: A hand demonstrating the insertion of the stainless steel bowl into the main unit of the ice cream maker, showing the ease of assembly.



Figure 3.10: A close-up of a hand scooping finished ice cream from the stainless steel bowl, illustrating the final step of the preparation process.

4. Setup and First Use

1. **Unpack:** Carefully remove all components from the packaging. Retain packaging for future storage or transport.
2. **Clean:** Before first use, wash the removable stainless steel bowl, mixing paddle, and lid in warm, soapy water. Rinse thoroughly and dry completely. Wipe the main unit with a damp cloth. Do not immerse the main unit in water.
3. **Assemble:**
    - Place the main unit on a stable, flat, and dry surface. Ensure adequate ventilation around the unit.
    - Insert the clean, dry stainless steel bowl into the main unit's chamber. Ensure it sits securely.
    - Place the mixing paddle into the center of the bowl, ensuring it engages with the drive shaft.
    - Place the transparent lid onto the main unit, aligning it properly and twisting if necessary to lock it in place (refer to markings on the lid and unit).
4. **Connect Power:** Plug the power cord into a grounded electrical outlet. The display will illuminate, indicating the machine is in standby mode.

5. Operating Instructions

The DOMO DO9252I features an intuitive XL Smart-Touch display and four automatic programs for ease of use.

5.1. Preparing Ingredients

- Ensure all ingredients are properly measured and mixed according to your recipe.
- For best results, chill your ice cream or sorbet mixture in the refrigerator for at least 2-4 hours, or overnight, before adding it to the machine. This is not strictly necessary due to the integrated compressor, but it can improve freezing time and consistency.
- Do not exceed the maximum fill line of the 1.5-liter bowl, as the mixture will expand during freezing.

5.2. Using the Smart-Touch Display

The display allows you to select programs and adjust settings:

- **Power Button:** Turns the appliance on/off or puts it into standby mode.
- **Program Selection:** Cycle through the four automatic programs:
    - **Ice Cream:** For traditional ice cream and gelato.
    - **Cool:** Cooling function without mixing, ideal for chilling ingredients or keeping desserts cold.
    - **Mix:** Mixing function without cooling, useful for combining ingredients or preparing yogurt.
    - **Yogurt:** Specific program for making homemade yogurt.
- **Time Adjustment (+/-):** Adjust the operating time for manual mode or modify program durations.
- **Hardness Control:** Allows you to select the desired hardness level for your frozen desserts.
- **Stirring Speed Adjustment:** Modify the mixing paddle's rotation speed. Higher speeds create airier ice cream, while lower speeds result in a denser texture with fewer ice crystals.

5.3. Step-by-Step Operation

1. Ensure the machine is assembled correctly and plugged in.
2. Pour your prepared mixture into the stainless steel bowl.
3. Secure the lid.

4. Press the Power button to turn on the machine.
5. Select your desired program (Ice Cream, Cool, Mix, or Yogurt) using the program selection button.
6. Adjust the time, hardness, or stirring speed as desired using the respective controls.
7. Press the Start/Pause button to begin the process. The machine will automatically churn and cool.
8. Once the program is complete, the machine will automatically switch to a "keep-cool" mode to maintain the consistency of your dessert.
9. Unplug the appliance and remove the lid. Carefully lift out the stainless steel bowl using its handle.
10. Serve your freshly made ice cream or yogurt.

6. Maintenance and Cleaning

Regular cleaning ensures the longevity and hygienic operation of your appliance.

- **Before Cleaning:** Always unplug the appliance from the power outlet before cleaning.
- **Removable Parts:** The stainless steel bowl, mixing paddle, and lid are removable and can be washed by hand with warm, soapy water. Rinse thoroughly and dry completely with a soft cloth. These parts are generally not dishwasher safe unless specified by the manufacturer.
- **Main Unit:** Wipe the exterior of the main unit with a soft, damp cloth. For stubborn stains, use a mild detergent. Do not use abrasive cleaners or scouring pads. Never immerse the main unit in water or any other liquid.
- **Storage:** Ensure all parts are completely dry before storing the appliance. Store in a cool, dry place, away from direct sunlight.

7. Troubleshooting

Problem	Possible Cause	Solution
Appliance does not turn on.	Not plugged in; power outage; faulty outlet.	Check power cord connection; check circuit breaker; try a different outlet.
Ice cream is not freezing or is too soft.	Mixture not cold enough; too much mixture; program time too short; ingredients not suitable.	Pre-chill mixture; do not overfill; extend program time; ensure recipe is suitable for ice cream makers.
Mixing paddle is not rotating.	Paddle not correctly installed; mixture too thick.	Ensure paddle is properly engaged with the drive shaft; thin the mixture slightly if too dense.
Unusual noise during operation.	Bowl or paddle not seated correctly; foreign object in bowl.	Stop the machine, check bowl and paddle alignment; remove any foreign objects.

8. Technical Specifications

Specification	Value
Brand	DOMO
Model Number	DO9252I

Specification	Value
Capacity	1.5 Liters
Power	150 Watts
Voltage	230 Volts
Material	Stainless Steel
Dimensions (L x W x H)	40.1 x 27.2 x 25.5 cm
Item Weight	6 Kilograms
Special Features	Integrated Compressor, Quiet DC Motor (<60 dB), XL Smart-Touchscreen, 4 Automatic Programs (Ice, Cool, Mix, Yogurt), Adjustable Stirring Speed, Keep-Cool Function

9. Warranty and Support

For warranty information, technical support, or service inquiries, please refer to the warranty card included with your product or contact DOMO customer service directly. Keep your proof of purchase for warranty claims.
You can find more information and contact details on the official DOMO website or through your retailer.

© 2023 DOMO. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0BBH3DF82

More documents and user manuals: **https://manuals.plus/**