

[Manuals.plus](#) /

› [Impecca](#) /

› Impecca 32" LED TV 720P HD, HDMI & USB Ports Full Function Remote Control Built-in Stereo Speakers Wall Mountable Frameless Design, None-Smart 2023

Impecca TL3202H

Impecca 32" LED TV Instruction Manual

Model: TL3202H

Brand: Impecca

1. INTRODUCTION AND OVERVIEW

Welcome to the instruction manual for your new Impecca 32" LED TV. This television is designed to provide a high-definition viewing experience with its 720P HD display and frameless full glass design, offering a modern aesthetic that complements any room. It features versatile connectivity options, including HDMI and USB ports, built-in stereo speakers, and comes with a full-function remote control for easy operation. This manual will guide you through the setup, operation, maintenance, and troubleshooting of your TV.



Figure 1.1: Impecca 32" LED TV

2. WHAT'S INCLUDED

Please check the packaging for the following items:

- Impecca 32" LED TV
- Full-Function Remote Control
- TV Stand (2 pieces)
- Screws for Stand Assembly
- Power Cord
- Instruction Manual

3. SETUP

3.1 Attaching the TV Stand

If you plan to place the TV on a tabletop, follow these steps to attach the stand:

1. Carefully place the TV screen-down on a soft, clean surface (e.g., a blanket or foam packaging) to prevent scratches.
2. Align each stand piece with the corresponding slots on the bottom of the TV.
3. Secure each stand piece using the provided screws. Ensure they are tightened firmly.
4. Carefully lift the TV and place it upright on a stable, flat surface.

3.2 Connecting Devices

Your Impecca TV offers various ports for connecting external devices:

- **HDMI Ports (x2):** Connect high-definition devices such as Blu-ray players, gaming consoles, cable boxes, or streaming devices.
- **USB Ports (x2):** Insert USB flash drives to view photos, play music, or watch videos.
- **A/V Input (L-R):** Connect older devices using RCA cables for audio and video input.
- **Optical Audio Output:** Connect to a soundbar or home theater system for enhanced audio.
- **RF Input (ANT 75Ω):** Connect an antenna for over-the-air broadcast channels or a cable TV connection.
- **Power Port:** Connect the supplied power cord to this port and then to a wall outlet.



Figure 3.1: TV in a typical setup

3.3 Wall Mounting

The Impecca 32" LED TV is wall mountable and compatible with VESA M4 100x100 mounting standards. For safe and secure wall mounting, it is highly recommended to consult a professional installer or refer to a dedicated wall mount instruction guide. Ensure the wall mount can support the weight of the television.

4. OPERATING INSTRUCTIONS

4.1 Basic Operation

- **Power On/Off:** Press the **Power** button () on the remote control or on the TV to turn the unit on or off.
- **Channel Selection:** Use the **CH +/-** buttons to navigate through available channels. You can also use the number buttons to directly enter a channel number.
- **Volume Control:** Adjust the volume level using the **VOL +/-** buttons.
- **Input Source:** Press the **SOURCE** button to cycle through and select the desired input source (e.g., HDMI1, HDMI2, USB, TV).
- **Menu Navigation:** Press the **MENU** button to access the TV's settings. Use the arrow keys to navigate through options and the **ENTER** button to confirm selections.




Figure 4.1: Enjoying content on the TV

4.2 Remote Control Functions

The included full-function remote control allows you to operate all features of your Impecca TV. Familiarize yourself with the buttons:





Figure 4.2: Full-Function Remote Control

- **Power:** Turns the TV on or off.
- **Number Buttons (0-9):** Directly select channels.
- **VOL +/-:** Increase or decrease volume.
- **CH +/-:** Change channels up or down.
- **MTS:** Multi-channel Television Sound (Stereo/SAP/Mono).
- **EPG:** Electronic Program Guide (if available).
- **FAV +/-:** Navigate through favorite channels.
- **MENU:** Access the main menu.
- **SOURCE:** Select input source.
- **Arrow Keys (Up/Down/Left/Right):** Navigate menus and options.
- **ENTER:** Confirm selection.
- **EXIT:** Exit current menu.

- **DISPLAY:** Show current channel information.
- **Colored Buttons (RED, GREEN, YELLOW, CYAN):** Specific functions depending on the menu or application.
- **Playback Controls (Rewind, Play/Pause, Fast Forward, Previous, Stop, Next):** Control media playback from USB.
- **ZOOM:** Adjust screen zoom.
- **CC:** Closed Captioning.

4.3 Audio Settings

The TV features a BTSC/M/N audio system with stereo sound. You can customize the audio experience:

- **Equalizer:** Access the equalizer with 4 pre-set modes to adjust sound profiles.
- **Effects:** Explore additional sound effects if available in the audio menu.
- **Maximum Audio Output:** The TV provides 2x8 Watts (8Ω10W) of audio output.

5. MAINTENANCE

Proper care and maintenance will extend the life of your Impecca TV.

5.1 Cleaning the Screen

- Always turn off the TV and unplug the power cord before cleaning.
- Gently wipe the screen with a soft, lint-free microfiber cloth.
- For stubborn marks, slightly dampen the cloth with water or a specialized screen-cleaning solution. Do not spray liquid directly onto the screen.
- Avoid using harsh chemicals, abrasive cleaners, or solvents as they can damage the screen surface.

5.2 Cleaning the TV Body

- Use a soft, dry cloth to wipe the exterior surfaces of the TV.
- Do not allow water or other liquids to enter the TV's interior.

5.3 Ventilation

- Ensure there is adequate space around the TV for proper ventilation.
- Do not block the ventilation openings on the back or sides of the TV.
- Avoid placing the TV in an enclosed cabinet without sufficient airflow.

6. TROUBLESHOOTING

If you encounter any issues with your TV, please refer to the following common problems and solutions before contacting customer support.

6.1 No Power

- Ensure the power cord is securely plugged into both the TV and a working electrical outlet.
- Check if the power outlet is active by plugging in another device.
- Press the power button on the TV itself, not just the remote, to rule out a remote issue.

6.2 No Picture

- Verify that the correct input source is selected using the **SOURCE** button on the remote control.
- Check all cable connections (HDMI, RF, A/V) to ensure they are secure and properly connected to both the TV and the source device.
- Try connecting a different device to the TV to determine if the issue is with the TV or the source device.
- If using an antenna, ensure it is properly connected and positioned for optimal signal reception.

6.3 No Sound

- Check the volume level and ensure the TV is not muted. Press the **Mute** button on the remote.
- If using external audio devices (soundbar, home theater), ensure they are properly connected, powered on, and set to the correct input.
- Check the audio settings in the TV's menu to ensure they are configured correctly.

6.4 Remote Control Not Working

- Replace the batteries in the remote control with new ones.
- Ensure there are no obstructions between the remote control and the TV's infrared (IR) sensor.
- Point the remote control directly at the TV's IR sensor.

6.5 Picture Quality Issues

- Adjust picture settings (brightness, contrast, color, sharpness) in the TV's menu.
- Ensure the input source is providing a high-quality signal. Lower resolution sources may appear less clear on an HD screen.
- Check for interference from other electronic devices.

7. SPECIFICATIONS

Detailed technical specifications for the Impecca 32" LED TV (Model: TL3202H):

7.1 Display

- **Screen Size:** 32 Inches (31.5" diagonal DLED Display)
- **Resolution:** 1366 x 768 (720p HD)
- **Aspect Ratio:** 16:9, 4:3
- **Brightness:** 180cd/m2
- **Contrast:** 3000:1
- **Viewing Angle:** 178°x178°
- **Refresh Rate:** 60Hz
- **Response Time:** 8.5ms
- **Maximum Display Colors:** 16.7 million

7.2 Audio

- **Audio System:** BTSC/M/N
- **Sound:** Stereo
- **Maximum Audio Output:** 2x8 Watts (8Ω10W)
- **Equalizer:** 4-Modes

7.3 Connectivity

- **HDMI Ports:** x2
- **USB Ports:** x2
- **A/V Input:** L-R
- **Optical Audio Output:** x1
- **RF Input:** ANT 75Ω

7.4 Power

- **Power Consumption (Operational):** 56W
- **Power Consumption (Standby):** ≤0.5W
- **Power Requirement:** AC 100-240V 50/60Hz

7.5 Physical

- **Dimensions (D x W x H):** 2.96 x 31.5 x 16.21 inches
- **Weight:** 11.62 pounds
- **Wall Mountable:** VESA M4 100x100

7.6 Certifications

- ETL (cETLus)
- FCC
- Energy Star
- DOE
- CEC
- RoHS/Pb

8. WARRANTY AND SUPPORT

8.1 Warranty Information

For detailed information regarding the warranty coverage for your Impecca 32" LED TV, please refer to the warranty card included in your product packaging. You may also visit the official Impecca website for the most up-to-date warranty terms and conditions.

8.2 Customer Support

If you encounter any issues that are not covered in this instruction manual, or if you require further assistance with your Impecca TV, please contact Impecca customer support. Contact details, including phone numbers and email addresses, can typically be found on the Impecca website ([Visit the Impecca Store on Amazon](#)) or on your product packaging.