

[Manuals.plus](#) /

> [UTEX](#) /

> UTEX 3-in-1 Pop Up Play Tent with Tunnel and Ball Pit Instruction Manual

UTEX B0BBLF94VW

UTEX 3-in-1 Pop Up Play Tent with Tunnel and Ball Pit Instruction Manual

Model: B0BBLF94VW

1. PRODUCT OVERVIEW

The UTEX 3-in-1 Pop Up Play Tent with Tunnel and Ball Pit is designed to provide an engaging and safe play environment for children. This versatile set includes a play tent, a connecting tunnel, and a ball pit, offering multiple configurations for indoor and outdoor use. Constructed from durable 190T polyester taffeta, it is resistant to wear and tear, ensuring lasting enjoyment.



Image 1.1: The complete UTEX 3-in-1 Play Tent, Tunnel, and Ball Pit set assembled.

2. SAFETY INFORMATION

Please read and understand all safety instructions before assembly and use. Failure to follow these instructions may result in injury.

- **Adult Supervision Required:** Always supervise children during play to prevent accidents.
- **Age Recommendation:** Suitable for children aged 3 years and up.

- **Clear Area:** Ensure the play area is clear of obstacles, sharp objects, and furniture to prevent collisions.
- **Fire Hazard:** Keep the product away from open flames, heat sources, and electrical heaters.
- **Outdoor Use:** When used outdoors, secure the tent to prevent it from being blown away by wind.
- **Structural Integrity:** Regularly inspect the product for any damage, tears, or broken components. Discontinue use if damaged.
- **Choking Hazard:** If using play balls, ensure they are appropriately sized for the child's age to avoid choking hazards. (Play balls are not included with this product).

3. PACKAGE CONTENTS

Verify that all components are present before beginning assembly:

- 1 x Play Tent House (with mesh window)
- 1 x Play Tunnel
- 1 x Ball Pit
- 1 x Carry Bag

Note: Play balls are not included and must be purchased separately.

4. SETUP INSTRUCTIONS

The UTEX 3-in-1 Play Tent set features a pop-up design for tool-free and quick assembly.

1. **Unpack:** Carefully remove all components from the carry bag. The items are spring-loaded and will expand quickly.
2. **Unfold the Tent:** The play tent will pop open automatically. Gently shape it to ensure it stands upright.
3. **Unfold the Tunnel:** The tunnel will also pop open. Extend it to its full length.
4. **Unfold the Ball Pit:** The ball pit will pop open. Ensure its sides are fully extended to form the pit shape.
5. **Connect Components:**
 - Align the opening of the play tent with one end of the tunnel. Secure them using the attached ties or Velcro fasteners.
 - Align the other end of the tunnel with the opening of the ball pit. Secure them using the attached ties or Velcro fasteners.
6. **Positioning:** Place the assembled play set on a flat, stable surface, either indoors or outdoors.




Image 4.1: The three components (tent, tunnel, ball pit) shown separately before connection.

5. OPERATING INSTRUCTIONS (USAGE)

The 3-in-1 play set offers various ways for children to play:

- **Full Configuration:** Children can crawl through the tunnel from the tent to the ball pit, or vice versa.
- **Individual Use:** Each component (tent, tunnel, ball pit) can be used separately. Simply detach the ties/Velcro fasteners to separate them.
- **Ball Pit Fun:** Fill the ball pit with play balls (not included) for an engaging sensory experience. The ball pit may include a small basketball hoop for added activity.
- **Imaginative Play:** The tent provides a private space for reading, resting, or imaginative role-playing.




Image 5.1: Children can crawl through the tunnel between the tent and ball pit.



Image 5.2: The ball pit component, often used with play balls.

6. MAINTENANCE AND CARE

- **Cleaning:** Wipe down surfaces with a damp cloth and mild soap. Do not use harsh chemicals or abrasive cleaners. Allow to air dry completely before storing.
- **Inspection:** Periodically check for any signs of wear, tear, or damage to the fabric, mesh, or structural poles.
- **Storage:** Ensure the product is clean and dry before folding and storing it in the provided carry bag to prevent mold or mildew.

7. STORAGE INSTRUCTIONS

Folding the play set for storage requires a specific technique due to its pop-up design. Practice may be needed to master the folding process.

1. **Separate Components:** Detach the tent, tunnel, and ball pit from each other.
2. **Flatten Each Piece:** Gently push down on each component to flatten it as much as possible.
3. **Twist and Fold:** For each piece, hold opposite sides and twist them in opposite directions, allowing the flexible frame to collapse into a smaller, circular shape. This may require some force and careful maneuvering.
4. **Secure:** Once folded into a compact circle, use any integrated elastic bands or ties to secure the shape.
5. **Store:** Place all folded components into the provided carry bag for convenient storage.




Image 7.1: The play tent set is suitable for both indoor and outdoor use, and can be easily stored.

8. TROUBLESHOOTING

Problem	Possible Cause	Solution
Components do not stay connected securely.	Ties or Velcro fasteners are not properly secured, or the connection points are misaligned.	Ensure all ties are tightly fastened and Velcro strips are fully engaged. If connections remain loose, consider adding additional securing methods (e.g., small clips, not included) for stability.
Difficulty folding the product back into the carry bag.	Incorrect folding technique for the pop-up frame.	Refer to the "Storage Instructions" section (Section 7) and practice the twist-and-fold method. The flexible frame requires specific manipulation to collapse correctly.
Tent or ball pit does not hold its shape well.	Frame may be slightly bent or not fully expanded.	Gently reshape the frame by hand. Ensure the product is placed on a flat surface. For ball pits, filling with balls can help maintain shape.

9. SPECIFICATIONS

- **Product Dimensions (Assembled):** Approximately 90 x 39 x 35 inches (Length x Width x Height)
- **Item Weight:** 3 pounds
- **Material:** 190T Polyester Taffeta
- **Manufacturer Recommended Age:** 3 years and up
- **Model Number (ASIN):** B0BBLF94VW




Image 9.1: Visual representation of the product dimensions.

10. WARRANTY AND SUPPORT

For warranty information or product support, please contact UTEX customer service directly. Refer to the product packaging or the official UTEX website for contact details.

Manufacturer: UTEX