

Bear YSH-C18S2

Bear YSH-C18S2 Health Pot Electric Kettle Tea Maker User Manual

Model: YSH-C18S2 | Brand: Bar

1. IMPORTANT SAFETY INSTRUCTIONS

Please read all instructions carefully before using the appliance. Failure to follow these instructions may result in electric shock, fire, or serious injury.

- Always ensure the voltage of the appliance matches your local power supply before connecting.
- Do not immerse the power base, cord, or plug in water or other liquids.
- Keep the appliance out of reach of children. Close supervision is necessary when the appliance is used by or near children.
- Do not operate the appliance with a damaged cord or plug, or after the appliance malfunctions or has been damaged in any manner.
- Use only attachments and accessories recommended by the manufacturer.
- Do not place the appliance on or near a hot gas or electric burner, or in a heated oven.
- Always ensure the lid is securely closed during operation to prevent scalding from hot steam.
- Exercise extreme caution when moving an appliance containing hot liquid.
- Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts, and before cleaning the appliance.
- This appliance is intended for household use only. Do not use outdoors.
- Do not fill above the maximum fill line to avoid overflow.
- The kettle, stew pot, and infuser are made of food-grade high borosilicate glass. Handle with care as glass can break.

2. PRODUCT OVERVIEW

The Bear YSH-C18S2 Health Pot is a versatile electric kettle and tea maker designed for various culinary preparations. It features a 1.8L capacity kettle, a 0.5L stew pot, and an infuser, allowing for multiple cooking styles.



The Bear YSH-C18S2 Health Pot, showcasing its main components including the glass kettle, infuser, and control base.



The Bear Health Pot positioned on a table, ready for use.

Components:

- **Kettle Body (1.8L):** Main glass vessel for boiling and brewing.
- **Stew Pot (0.5L):** Inner glass pot for stewing ingredients within the kettle.
- **Infuser:** For steeping tea leaves or other ingredients.
- **Egg Rack:** Allows for cooking up to 5 eggs simultaneously.
- **Control Panel & Knob:** For selecting functions and adjusting settings.
- **Lids:** Includes a main kettle lid and a separate lid for the stew pot.



An exploded view illustrating all components: Top Lid, Kettle Lid, Stew Pot Lid, Stew Pot, Glass Infuser, Egg Rack, Kettle Body, Panel, and Knob.

Key Features:

- **16 Boil Functions:** Pre-programmed menus for various preparations like scented tea, porridge, soup, bird's nest, etc.
- **4 Types of Stew:** Direct boil, boil with infuser, stew in water, and boil outside/stew inside.
- **Preset & Keep Warm:** Up to 9.5 hours preset timer and 8 hours automatic keep warm (40-90°C).
- **Food-grade Material:** Kettle, stew pot, and infuser are made of high borosilicate glass.
- **360° Circumferential Heating Bottom:** Ensures even heating and prevents sticking.

360° Circumferential Heating Bottom



The kettle features a 360° circumferential heating bottom for efficient and even heat distribution.

- **Dual Lid Design:** Separate lids for the main kettle and the stew pot to retain heat and preserve nutrition.

Design of 2 Lids



The product includes a Kettle Lid to retain heat and taste, and a Stew Pot Lid to preserve nutrition.

- **1.8L Large Capacity:** Suitable for preparing beverages and meals for 1-3 people.

1.8L Large Capacity

One pot for 1-3 people



The 1.8L large capacity kettle is ideal for serving 1-3 individuals.

3. SETUP

1. **Unpacking:** Carefully remove all components from the packaging. Retain packaging for future storage or transport.
2. **Initial Cleaning:** Before first use, wash the kettle body, stew pot, infuser, egg rack, and lids with warm soapy water. Rinse thoroughly and dry. Wipe the control panel and base with a damp cloth. Do not immerse the base in water.
3. **Placement:** Place the appliance on a stable, flat, heat-resistant surface, away from edges and out of reach of children. Ensure there is adequate ventilation around the unit.
4. **Power Connection:** Plug the power cord into a grounded electrical outlet. Ensure the voltage matches the appliance's requirements (120V).
5. **First Use (Water Only):** Fill the kettle with water up to the MAX line. Boil the water once or twice and discard it to remove any manufacturing residues.

4. OPERATING INSTRUCTIONS

The Bear YSH-C18S2 offers 16 pre-set menu options for various preparations. The control panel features a rotary knob for selection and a "Press to Confirm" function.

Rotary Button Selection Function Press to Confirm



The central rotary knob allows for menu selection. Press the knob to confirm your choice.



16 Cooking & Boiling Styles

Flower tea, soup, herbal meal and porridge | Meet Your Needs



Overview of the 16 pre-programmed functions available on the control panel.

Basic Operation:

1. **Fill Water:** Add desired amount of water to the kettle. Do not exceed the 1.8L MAX line.
2. **Add Ingredients:**
 - For direct boiling (e.g., tea, soup): Add ingredients directly into the kettle.
 - For stewing: Place ingredients into the 0.5L stew pot, then place the stew pot inside the kettle. Ensure the stew pot lid is on.
 - For infusing: Place ingredients into the infuser, then place the infuser inside the kettle.
 - For eggs: Place eggs on the egg rack, then place the rack inside the kettle.
3. **Select Function:** Rotate the central knob to cycle through the 16 menu options (e.g., Boil, Scented Tea, Porridge, Soup, Bird's Nest, etc.).
4. **Confirm Selection:** Press the central knob to confirm your desired function. The appliance will begin operation.
5. **Keep Warm Function:** After cooking, the appliance automatically enters an 8-hour keep warm mode (40-90°C range). You can adjust the keep warm temperature using the "Keep Warm" button.
6. **Preset Function:** Use the "Timer" button to set a delayed start time, up to 9.5 hours.
7. **Pot Lift Memory:** The appliance supports pot lift memory, meaning it will resume operation if the kettle is briefly lifted from the base.

and returned.

Cooking Styles:

The design allows for four primary cooking methods:

- **Direct Boil:** Ingredients are placed directly in the main kettle (e.g., boiling water, large volume soups).
- **Boil with Infuser:** Ingredients are placed in the infuser for steeping (e.g., loose leaf tea).
- **Stew in Water:** Ingredients are placed in the inner stew pot, which is then submerged in water within the main kettle. This method provides gentle, even cooking.
- **Boil Outside and Stew Inside:** Similar to "Stew in Water," but emphasizes the separation of the stewed contents from the boiling water.



Visual representation of the four versatile cooking methods: direct boiling, infusing, and two methods of stewing.

5. MAINTENANCE AND CLEANING

Regular cleaning ensures optimal performance and extends the lifespan of your appliance. Always unplug the kettle and allow it to cool completely before cleaning.

- **Kettle Body, Stew Pot, Infuser, Egg Rack, Lids:** These parts are made of glass and can be washed by hand with warm soapy water. Rinse thoroughly and dry completely.
- **Control Panel and Base:** Wipe the exterior of the control panel and power base with a soft, damp cloth. Do not use abrasive cleaners or scourers. Never immerse the power base in water or any other liquid.
- **Descaling:** Over time, mineral deposits (limescale) may build up inside the kettle, especially in hard water areas.
 - Fill the kettle with a mixture of equal parts water and white vinegar (or a commercial descaling solution).
 - Let it soak for at least 30 minutes, or boil the mixture if the scale is severe.
 - Pour out the solution and rinse the kettle thoroughly several times with fresh water to remove any vinegar residue.
- **Storage:** When not in use, ensure the appliance is clean and dry. Store it in a cool, dry place.

6. TROUBLESHOOTING

If you encounter issues with your Bear YSH-C18S2 Health Pot, please refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Appliance does not turn on.	Not plugged in; power outage; kettle not properly seated on base.	Check power connection; verify power supply; ensure kettle is correctly placed on the base.
Water not heating.	Function not selected; insufficient water; heating element malfunction.	Select a cooking function; ensure water level is above MIN mark; contact customer service if issue persists.

Problem	Possible Cause	Solution
Kettle boils over.	Overfilled; ingredients causing excessive foam.	Do not fill above the MAX line; reduce ingredients that may foam excessively.
Unusual odor or taste.	New appliance odor; residue from previous use; limescale buildup.	Perform initial water-only boil; clean thoroughly; descale the kettle.
Display shows error code.	Internal malfunction.	Unplug the appliance for 5 minutes, then plug back in. If the error persists, contact customer service.

If the problem persists after attempting these solutions, please contact customer support.

7. SPECIFICATIONS

Brand:	Bar
Model Name:	YSH-C18S2
Color:	Green
Capacity:	1.8 Liters (Kettle), 0.5 Liters (Stew Pot)
Voltage:	120V
Special Feature:	Multi-use Kettle, Programmable, 16 Menus, 9.5h Preset, 8h Keep Warm
Product Dimensions:	9.02"L x 8.78"W x 10.16"H
Item Weight:	5 Pounds
Material:	Food-grade High Borosilicate Glass
Included Components:	Kettle, Stew Pot, Infuser, Egg Rack
UPC:	743388205765



Detailed dimensions of the Bear YSH-C18S2 Health Pot.

8. WARRANTY AND SUPPORT

Your Bear YSH-C18S2 Health Pot comes with a 1-year warranty from the date of purchase, covering manufacturing defects.

Warranty Coverage:

- Covers defects in material and workmanship under normal household use.
- Does not cover damage resulting from misuse, abuse, accident, alteration, or commercial use.
- Does not cover normal wear and tear, including glass breakage due to impact.

Customer Service:

For warranty claims, technical support, or any questions regarding your product, please contact our customer service team. Refer to the contact information provided in your product packaging or visit the official Bear website for support details.

Please have your model number (YSH-C18S2) and proof of purchase ready when contacting support.

© 2025 Bar. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question