

[Manuals.plus](#) /

› [Sea Gull Lighting](#) /

› Generation Lighting Keaton 2-Light Vanity Fixture (Model 4465002-05) Instruction Manual

Sea Gull Lighting 4465002-05

Generation Lighting Keaton 2-Light Vanity Fixture (Model 4465002-05) Instruction Manual

Model: 4465002-05 | Brand: Sea Gull Lighting

INTRODUCTION

Thank you for purchasing the Generation Lighting Keaton 2-Light Vanity Fixture. This manual provides detailed instructions for the safe installation, operation, and maintenance of your new lighting fixture. Please read all instructions carefully before beginning installation and retain this manual for future reference.



Image: Front view of the Generation Lighting Keaton 2-Light Vanity Fixture, showcasing its chrome finish and two satin etched glass shades.

SAFETY INFORMATION

- **WARNING:** Risk of electric shock. Disconnect power at the circuit breaker or fuse box before installation or servicing.
- All electrical connections must be in accordance with local codes, ordinances, or the National Electric Code (NEC). Consult a qualified electrician if you are unfamiliar with proper electrical wiring connections.
- Use only the specified bulb type and wattage. Exceeding the maximum wattage may cause overheating and damage to the fixture.
- Do not install this fixture in wet locations. It is designed for indoor use only.
- Handle glass components with care to prevent breakage.

PACKAGE CONTENTS

Verify that all parts listed below are included in your package:

- Vanity Fixture Body (1)
- Satin Etched Glass Shades (2)
- Mounting Hardware Kit (includes mounting strap, outlet box screws, wire connectors, ground screw) (1)
- T10 Medium 40 Watt Light Bulbs (2)

SETUP AND INSTALLATION

Follow these steps to properly install your vanity fixture:

1. **Turn Off Power:** Before starting, ensure the power to the electrical outlet box is turned off at the circuit breaker or fuse box.
2. **Prepare Mounting:** Attach the mounting strap to the outlet box using the provided outlet box screws. Ensure the strap is securely fastened.
3. **Wiring Connections:** Connect the fixture's wires to the corresponding household wires using the wire connectors. Connect the black wire (hot) to the black wire, the white wire (neutral) to the white wire, and the bare copper or green wire (ground) to the household ground wire and the ground screw on the mounting strap. Ensure all connections are secure.
4. **Mount Fixture:** Carefully align the fixture body with the mounting strap and secure it with the provided mounting screws.
5. **Install Glass Shades:** Gently place the satin etched glass shades onto the fixture. Ensure they are seated properly and secured according to the fixture design.
6. **Install Bulbs:** Screw the two T10 Medium 40 watt light bulbs into the sockets. Do not overtighten.
7. **Restore Power:** Once installation is complete, restore power at the circuit breaker or fuse box.



Image: Side view of the Keaton Vanity Fixture, illustrating its profile and the cylindrical glass shades.

OPERATING INSTRUCTIONS

The Generation Lighting Keaton Vanity Fixture operates via a standard wall switch connected to its electrical circuit. Simply toggle the wall switch to turn the light on or off.

- **Light Source:** This fixture uses two T10 Medium 40 watt bulbs.
- **Control Method:** The fixture is controlled by an external wall switch.

MAINTENANCE

Regular maintenance will help preserve the appearance and functionality of your fixture.

- **Cleaning:** To clean the fixture, turn off the power and wipe with a soft, dry or slightly damp cloth. Do not use abrasive cleaners, solvents, or polishes as they may damage the finish.
- **Glass Shades:** The satin etched glass shades can be removed for cleaning. Wash with mild soap and water, rinse thoroughly, and dry completely before reattaching.
- **Bulb Replacement:** Ensure power is off before replacing bulbs. Allow bulbs to cool completely. Unscrew old bulbs and replace with new T10 Medium 40 watt bulbs.



Image: Detailed view of the Keaton Vanity Fixture, highlighting the chrome base and the texture of the satin etched glass.

TROUBLESHOOTING

If you encounter issues with your fixture, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Light does not turn on	No power to fixture; Loose wiring; Faulty bulb	Check circuit breaker/fuse; Verify wire connections; Replace bulb
Light flickers	Loose bulb; Loose wiring; Incorrect bulb type	Tighten bulb; Check wire connections; Ensure correct bulb type and wattage
Bulb burns out quickly	Incorrect wattage bulb; Poor ventilation	Use specified 40W T10 bulbs; Ensure proper air circulation around fixture

SPECIFICATIONS

Brand	Sea Gull Lighting
Model Number	4465002-05
Product Dimensions	10"L x 5"W x 16"H
Item Weight	2.64 pounds
Color	Chrome
Material	Alloy Steel (Fixture Body), Glass (Shades)
Style	Modern
Light Fixture Form	Vanity
Number of Light Sources	2
Light Source Type	T10
Bulb Base	E26 Medium
Wattage	40 watts per bulb (80 total watts)
Voltage	120 Volts
Indoor/Outdoor Usage	Indoor
Installation Type	Surface Mount
Assembly Required	No

WARRANTY INFORMATION

All products purchased have a 30-day replacement parts policy to ensure a fully working item. All products are covered under a 1-year warranty when purchased on Amazon. The warranty period begins on the day the product is originally shipped. The warranty

covers all of the items and conditions identified in the original manufacturer's warranty. Some of the items specifically not covered by the warranty are loss and theft, water damage, customer abuse, and finish deterioration due to UV or coastal exposure.

SUPPORT

For further assistance, technical support, or to inquire about replacement parts, please contact Sea Gull Lighting customer service. Refer to your purchase documentation or the official Sea Gull Lighting website for contact details.

© 2023 Sea Gull Lighting. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question