

[Manuals.plus](#) /

› [Ameriwood Home](#) /

› Ameriwood Home Luna Fireplace TV Stand (Model 8800335COM) User Manual

Ameriwood Home 8800335COM

Ameriwood Home Luna Fireplace TV Stand User Manual

Model: 8800335COM

PRODUCT OVERVIEW

The Ameriwood Home Luna Fireplace TV Stand is designed to accommodate most flat-screen televisions up to 65 inches and 120 lbs. It features an integrated electric fireplace insert, LED lighting, and storage shelves. This manual provides essential information for the safe and efficient use of your TV stand.



Image: The Luna Fireplace TV Stand in black oak, featuring an electric fireplace and illuminated shelves, supporting a large television.

SAFETY INFORMATION

Please read all safety warnings and instructions carefully before assembly and use. Failure to follow these instructions may result in electric shock, fire, property damage, or personal injury.

- Always unplug the fireplace insert from the power outlet before cleaning or performing maintenance.
- Do not overload the TV stand. Ensure the weight of your television and other items does not exceed the specified weight limits.
- Keep flammable materials at least 3 feet (0.9 meters) away from the front of the fireplace heater.
- Do not insert or allow foreign objects to enter any ventilation or exhaust opening as this may cause an electric shock or fire, or damage the heater.
- This product contains formaldehyde. Ensure adequate ventilation during and after assembly.

SETUP AND ASSEMBLY

The Luna Fireplace TV Stand ships flat and requires assembly. Two adults are recommended for assembly. Ensure all parts are present and undamaged before beginning.

Unpacking and Part Identification

- Carefully open the packaging and remove all components.
- Verify all parts against the included parts list in your separate assembly instructions. Contact customer support immediately if any parts are missing or damaged.
- Keep packaging materials until assembly is complete to avoid misplacing small parts.

Assembly Steps (General Guidelines)

1. Prepare a clean, flat, and spacious area for assembly.
2. Follow the step-by-step instructions provided in the separate assembly manual included with your product.
3. Securely fasten all connections. Do not overtighten screws.
4. Install the electric fireplace insert into the designated opening.
5. Place the adjustable glass shelves into the desired positions.
6. Utilize the wire pass-throughs located at the back of each section for cable management.



Image: Rear view of the TV stand highlighting the wire management cutouts for organizing cables.

OPERATING INSTRUCTIONS

Electric Fireplace Operation

The AltraFlame electric heater provides warmth and ambiance. It can heat rooms up to 400 sq. ft. and operates on a standard 120V outlet.

- **Power On/Off:** Use the power button on the front panel touchscreen or the included remote control to turn the fireplace on or off.
- **Flame Effects:** Adjust the flame brightness and color settings using the remote or touchscreen. The crystal ember bed provides a modern look.

- **Heat Function:** The heater can be operated with or without the flame effect. Use the remote to switch the heat option on or off.
- **Temperature Control:** Set your desired room temperature (range 64°-82°F) using the controls. The unit features automatic room temperature controls and a timer.



Image: Diagram illustrating the features of the 23-inch fireplace insert, including remote control, touch panel, flame settings, crystal ember bed, and temperature range.

LED Under Cabinet Lighting

The integrated LED light strips illuminate the shelves, creating mood lighting.

- **Activation:** The LED lights are controlled separately, typically via a switch or remote. Refer to your specific assembly instructions for details on activating and changing light settings.
- **Color Changing:** The LED lights offer color-changing options to customize the ambiance.



Image: Close-up view of a glass shelf within the TV stand, illuminated by blue LED lighting.

MAINTENANCE

Regular maintenance ensures the longevity and optimal performance of your TV stand and fireplace insert.

- **Cleaning the Stand:** Wipe the surfaces of the TV stand with a dry, soft cloth. Avoid abrasive cleaners or harsh chemicals that may damage the finish.
- **Cleaning the Fireplace Insert:** Ensure the fireplace insert is unplugged and cool before cleaning. Wipe the glass and exterior surfaces with a soft, damp cloth. Do not spray water directly onto the unit.
- **Ventilation:** Periodically check that the air intake and exhaust vents of the fireplace insert are clear of dust and obstructions.

TROUBLESHOOTING


If you encounter issues with your Luna Fireplace TV Stand, refer to the following common solutions:

Problem	Possible Cause	Solution
Fireplace not turning on.	No power, unit unplugged, or power switch off.	Check power cord connection, ensure outlet is functional, and verify the main power switch on the unit is on.
No heat from fireplace.	Heat function is off, or thermostat setting is too low.	Activate the heat function via remote or touchscreen. Increase the thermostat setting.
Remote control not working.	Dead batteries, or obstruction between remote and unit.	Replace remote batteries. Ensure a clear line of sight to the fireplace receiver.
LED lights not working.	Power connection issue, or light switch off.	Check the power connection for the LED strips. Ensure the light switch is in the 'on' position.

If the problem persists after attempting these solutions, please contact customer support.

SPECIFICATIONS

• Model Name: Luna • Model Number: 8800335COM • Brand: Ameriwood Home • Product Dimensions: 60.87"W x 15.67"D x 23.27"H • Material: Engineered Wood • Color: Black Oak • Maximum TV Size: Up to 65 inches • Maximum Top Weight Capacity: 120 lbs • Shelf Weight Capacity: 15 lbs per shelf • Item Weight: 102 lbs • Fireplace Heat Output: 5000 British Thermal Units (BTU) • Heating Coverage: Up to 400 sq ft • Power Source: Corded Electric (120V) • Number of Shelves: 2 (adjustable glass)
--



Product Dimensions

60.9 in. W x 15.7 in. D x 23.3 in. H
 Weight Limit: Top - 120 lbs.
 Each Shelf: 15 lbs.



Black Oak

Image: Diagram showing the dimensions of the Luna Fireplace TV Stand, including width, depth, and height measurements.

WARRANTY INFORMATION

The Ameriwood Home Luna Fireplace TV Stand comes with a **1-year limited warranty**. This warranty covers manufacturing defects under normal use. Please retain your proof of purchase for warranty claims. For specific terms and conditions, refer to the warranty documentation included with your product or contact Ameriwood Home customer service.

CUSTOMER SUPPORT

For assistance with assembly, missing parts, or operational questions, please contact Ameriwood Home customer support. Contact information can typically be found on the product packaging or on the official Ameriwood Home website.

Note: Always refer to the specific assembly instructions included in your product packaging for detailed, step-by-step guidance.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0BBPN3G56>

More documents and user manuals: <https://manuals.plus/>