

[Manuals.plus](#) /

› [Varta](#) /

› Varta Wireless Charger Multi 20W User Manual

Varta 57906101111

Varta Wireless Charger Multi 20W User Manual

Model: 57906101111

INTRODUCTION

Welcome to the user manual for your Varta Wireless Charger Multi 20W. This device is designed to provide convenient and efficient wireless charging for up to two Qi-compatible devices simultaneously. Please read this manual carefully before using the product to ensure safe and optimal performance.

IMPORTANT SAFETY INSTRUCTIONS

To ensure safe operation and prevent damage, please observe the following safety guidelines:

- Do not expose the device to water, moisture, or extreme temperatures.
- Keep the charger away from children and pets.
- Use only with compatible devices and power adapters.
- Do not disassemble, modify, or attempt to repair the charger.
- Avoid placing metal objects or magnetic cards on the charging surface.
- Unplug the charger during lightning storms or when unused for long periods.

PACKAGE CONTENTS

Verify that all items are present in your package:

- 1 x Varta Wireless Charger Multi 20W
- 1 x USB-C to USB-C Cable (1m)





VARTA

WIRELESS CHARGER MULTI

BATTERY EXPERTS
SINCE 1887



20W
FAST
WIRELESS
CHARGING*



CHARGES
EARPHONES**



CHARGES
2 DEVICES
AT ONCE

Image: The retail packaging for the Varta Wireless Charger Multi, highlighting its 20W fast wireless charging capability and ability to charge two devices simultaneously.

PRODUCT OVERVIEW

The Varta Wireless Charger Multi features a sleek, black design with two distinct charging pads, indicated by wireless charging symbols. It is equipped with a USB-C input port and LED indicators to show charging status.



Image: A top-down view of the Varta Wireless Charger Multi, showcasing its dual charging surfaces and minimalist design.

				• Ultraschnelles kabelloses Laden mit bis zu 20 W* Gesamtleistung: 10 W + 10 W* • Doppelspulenttechnologie ermöglicht gleichzeitiges Laden von bis zu 2 Geräten • Kompatibel mit allen Qi-kompatiblen Geräten: Smartphones, Kopfhörer und mehr • Schutzhüllenfreundlich • Mehrfarbige LED für die Ladeanzeige • Rutschfeste Gummifüße garantieren maximale Stabilität • USB Typ C PD Eingang • Premium Optik dank hochwertiger Materialien und ultradünnem Produktdesign • Inkl. 1m USB Typ C zu USB Typ C Ladekabel * Bei Verwendung eines 27 W Adapters oder höher und eines Schnellladekabels
20 W FAST WIRELESS CHARGING*	CHARGES 2 DEVICES AT ONCE	CHARGES HEADPHONES	INCL. TYPE C CABLE	

Image: An infographic illustrating the key features of the charger, including its 20W total output, dual coil technology, Qi compatibility, case-friendly design, multi-color LED indicator, non-slip rubber feet, USB Type-C PD input, premium aesthetics, and the included 1-meter USB Type-C cable.

SETUP

Follow these steps to set up your Varta Wireless Charger Multi:

1. Connect one end of the provided USB-C to USB-C cable to the USB-C input port on the Varta Wireless Charger Multi.
2. Connect the other end of the USB-C cable to a compatible USB Power Delivery (PD) wall adapter. For optimal 20W charging, a 27W or higher power adapter is recommended (not included).
3. Place the charger on a flat, stable surface, ensuring adequate ventilation around the device.

OPERATING INSTRUCTIONS

Charging Your Device

1. Ensure the Varta Wireless Charger Multi is properly connected to a power source.
2. Place your Qi-compatible device (e.g., smartphone, wireless earbuds case) directly onto one of the charging pads.
3. The LED indicator on the charger will illuminate to confirm that charging has begun.
4. For efficient charging, ensure your device is centered on the charging pad.

Dual Device Charging

The Varta Wireless Charger Multi is designed with dual coil technology, allowing you to charge two Qi-compatible devices simultaneously. Simply place one device on each charging pad.



Image: The Varta Wireless Charger Multi positioned on a desk alongside a laptop, demonstrating its seamless integration into a typical workspace or home environment.

MAINTENANCE

Proper care will extend the life of your Varta Wireless Charger Multi:

- **Cleaning:** Use a soft, dry, lint-free cloth to clean the surface of the charger. Do not use abrasive cleaners, solvents, or harsh chemicals.
- **Storage:** When not in use, store the charger in a cool, dry place away from direct sunlight and extreme temperatures.
- **Handling:** Avoid dropping or subjecting the charger to strong impacts.

TROUBLESHOOTING

If you encounter issues with your Varta Wireless Charger Multi, refer to the table below for common problems and solutions:

Problem	Possible Solution
---------	-------------------

Problem	Possible Solution
Device is not charging.	Ensure the USB-C cable is securely connected to both the charger and the power adapter. Verify that the power adapter is functioning and providing sufficient power (27W or higher recommended). Confirm that your device is Qi-compatible. Reposition your device on the charging pad to ensure proper alignment with the charging coils. Remove any thick phone cases that might interfere with wireless charging.
Charging is slow.	Ensure you are using a power adapter of 27W or higher. Check if your device supports fast wireless charging. Remove any phone cases that might be too thick. Avoid charging in excessively hot environments.
LED indicator is not lighting up.	Check if the charger is receiving power. Ensure the device is correctly placed on the charging pad.

SPECIFICATIONS

Technical specifications for the Varta Wireless Charger Multi 20W:

Feature	Detail
Brand	Varta
Model Number	57906101111
Color	Black
Connectivity Technology	USB-C, Wireless
Connector Type	USB
Compatible Devices	Mobile phone, Qi-compatible earbuds
Total USB Ports	1 (USB-C input)
Special Feature	Wireless, Dual Coil, Case-friendly, Non-slip feet
Power Output	20 Watts (Max. 10W + 10W)
Included Components	1 Varta Wireless Charger Multi, 1m USB-C to USB-C cable

WARRANTY AND SUPPORT

For detailed warranty information and customer support, please refer to the official Varta website or contact your local retailer where the product was purchased. Please retain your proof of purchase for any warranty claims.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question