

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [LEGO](#) /
- › [LEGO Disney Pixar Up House 43217 Building Set Instruction Manual](#)

LEGO 43217

LEGO Disney Pixar Up House 43217 Building Set

Instruction Manual

INTRODUCTION

Welcome to the instruction manual for your LEGO Disney Pixar Up House 43217 building set. This set allows you to construct a detailed model of the iconic house from Disney and Pixar's 'Up' movie, complete with Carl Fredricksen, Russell, and Dug minifigures. Designed for builders aged 9 and above, this set contains 598 pieces, offering an engaging and rewarding building experience.

Please read through these instructions carefully to ensure proper assembly and care of your LEGO set. For additional support or digital building instructions, please refer to the official LEGO website or the LEGO Builder App.

SETUP AND ASSEMBLY

Before beginning assembly, ensure you have a clean, well-lit workspace. It is recommended to sort the LEGO pieces by color and size to facilitate the building process. Follow the step-by-step instructions provided in the included building guide.



This image displays the complete LEGO Disney Pixar 'Up' House set, featuring the iconic house with its colorful balloons, along with the minifigures of Carl Fredricksen, Russell, and the dog Dug. The set is ready for display or play.



The front packaging of the LEGO Disney Pixar 'Up' House set, model 43217, illustrating the fully built house with balloons and the included Carl, Russell, and Dug minifigures.



The reverse side of the LEGO Disney Pixar 'Up' House box, showcasing various interior rooms and interactive elements of the set, including the minifigures in different scenes.

Key Assembly Tips:

- **Follow the Numbered Bags:** LEGO sets typically come with numbered bags. Open them in sequence as indicated in the instruction manual.
- **Identify Pieces:** Before attaching, carefully identify each piece to ensure you are using the correct component.
- **Secure Connections:** Press bricks firmly together to ensure a stable and durable model.
- **Minifigure Assembly:** Assemble the Carl, Russell, and Dug minifigures as shown in the instructions.



A detailed view of the LEGO minifigures included in the set: Carl Fredrickson with his walker, Russell with his Wilderness Explorer badges, and the loyal dog Dug.



A child is shown engaged in the building process of the LEGO 'Up' House, focusing on connecting bricks, illustrating the hands-on assembly experience.

OPERATING AND PLAY

Once assembled, the LEGO Disney Pixar Up House offers various opportunities for imaginative play and display. The set features multiple rooms and details that allow you to recreate scenes from the movie or invent new adventures.

Play Features:

- **Interior Access:** The house design allows for easy access to its interior, enabling interaction with the furniture and characters.
- **Minifigure Interaction:** Position Carl, Russell, and Dug in different areas of the house or around the exterior to tell stories.
- **Display:** The completed model makes an excellent display piece for fans of the movie and LEGO collectors.



This image shows the detailed interior of the LEGO 'Up' House, with Carl and Russell minifigures interacting within the rooms, demonstrating the set's playability.



Two children are depicted playing together with the completed LEGO 'Up' House set, highlighting the imaginative play opportunities it offers.

MAINTENANCE AND CARE

To ensure the longevity and appearance of your LEGO set, follow these simple maintenance guidelines:

- **Cleaning:** Use a soft brush or a damp cloth with mild soap and water to clean LEGO bricks. Avoid harsh chemicals or abrasive materials.
- **Storage:** Store the set in a cool, dry place away from direct sunlight to prevent discoloration or damage to the plastic.
- **Handling:** Handle the assembled model with care, especially when moving it, to prevent pieces from detaching.



This image captures a child's hands sorting and assembling LEGO bricks, with the partially built 'Up' House and various pieces spread on a table, demonstrating the construction phase.

TROUBLESHOOTING

While LEGO sets are designed for high quality and completeness, occasional issues may arise.

Common Issues:

- **Missing Pieces:** If you find any pieces missing from your set, please visit the official LEGO Customer Service website to request replacement parts. Have your set number (43217) ready.
- **Assembly Difficulties:** If you encounter difficulty with a specific step, double-check the instruction manual and ensure all previous steps were completed correctly. Sometimes, a small piece might be misplaced.
- **Loose Connections:** Ensure all bricks are pressed firmly together. Loose connections can lead to instability in the model.

SPECIFICATIONS

Feature	Detail
Product Model Number	43217
Number of Pieces	598
Recommended Age	9 years and up
Product Dimensions	26.2 x 38.2 x 7.05 cm
Material Type	Plastic
Assembly Required	Yes
Batteries Required	No

WARRANTY AND SUPPORT

LEGO products are manufactured to high-quality standards. For information regarding product warranty, missing parts, or any other support needs, please visit the official LEGO Customer Service website. You can typically find detailed warranty information and contact options there.

Online Support: For the most up-to-date support resources, including digital building instructions and replacement parts, please visit LEGO.com/service.

PRODUCT VIDEO DEMONSTRATION

A short animated video showcasing the assembled LEGO Disney Pixar Up House set.

No embeddable video URL (m3u8) was provided in the product data. Please refer to the product page for any available video demonstrations.