Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Seatcraft Virtuoso 88-3610

Seatcraft Virtuoso Home Theater Seating Instruction Manual

Model: Virtuoso 88-3610

Introduction

Thank you for choosing the Seatcraft Virtuoso Home Theater Seating. This manual provides essential information for the safe and efficient use of your new recliner. Please read these instructions carefully before assembly and operation, and retain them for future reference.

The Seatcraft Virtuoso is designed for comfort and functionality, featuring Italian leather, powered recline, powered headrest, powered lumbar support, heat, and massage functions. It also includes convenient amenities such as lighted cupholders with USB charging, hidden in-arm storage, and ambient base lighting.



Image: The Seatcraft Virtuoso single recliner in brown, showcasing its luxurious design and features.

Safety Information

For safe use of your Seatcraft Virtuoso recliner, please observe the following guidelines:

- Do not exceed the maximum weight capacity of 350 lbs (158 kg).
- Ensure the chair is placed on a hard, flat, and stable surface to prevent tipping.
- Use the swivel function carefully to avoid instability or tipping.
- Keep hands and feet clear of moving parts during recline and adjustment operations.
- Keep children and pets away from the chair's moving mechanisms.
- Do not stand on the chair or armrests.
- Unplug the power cord from the outlet before cleaning or performing any maintenance.

Setup and Assembly

The Seatcraft Virtuoso recliner requires minimal assembly, typically taking 30 minutes or less. Follow these steps for proper setup:

1. **Unpack Components:** Carefully remove all parts from the packaging. Ensure all components are present: backrest, seat base, power adapter, and remote control.
2. **Attach Backrest:** Align the metal brackets on the backrest with the corresponding slots on the seat base. Slide the backrest down firmly until it locks into place. You should hear a click.
3. **Connect Power Cables:** Locate the power cables extending from the back of the seat base and the backrest. Connect them securely.
4. **Connect Power Adapter:** Plug the power adapter into the chair's power input, then plug the adapter into a standard electrical outlet.
5. **Position Chair:** Place the chair in your desired location, ensuring there is at least 6 inches of clearance from the wall for full recline.




Image: The remote control for the Seatcraft Virtuoso, used to operate various functions.



Image: A diagram illustrating the key features of the Seatcraft Virtuoso, including power adjustable headrest, lumbar, heat & massage, hidden storage, lighted cupholders, swivel tray table, power recline, and ambient base lights.

Operating Instructions

Your Seatcraft Virtuoso recliner is operated using the attached quad-control remote. Familiarize yourself with the remote's buttons for optimal use.

Remote Control Functions:

- **Headrest Adjustment:** Use the 'head rest' buttons to adjust the powered headrest to your desired angle.
- **Recline Adjustment:** Use the 'recline' buttons to adjust the chair's recline position. Push to extend recline, pull to return.
- **Lumbar Adjustment:** Use the 'lumbar' buttons to adjust the powered lumbar support for personalized back comfort.
- **Heat & Massage:**
    - **Power Button (PWR):** Turns all massage zones on/off.
    - **Heat Button:** Activates or deactivates the deep heat relief function in the backrest.
    - **Massage Modes (1, 2, 3):** Select from Pulse, Wave, or Alternating Zones massage modes.
    - **Massage Zones (1, 2, 3, 4):** Customize your massage experience by activating or deactivating specific zones. LEDs indicate active zones. If no zones are selected, the massage will turn off.
- **Home Button:** Press this button to return the chair to its default, upright position.

Additional Features:

- **Lighted Cupholders & USB Charging:** The cupholders illuminate and include USB charging ports. These are typically activated via the remote or a dedicated button near the cupholder.
- **Hidden In-Arm Storage:** Lift the armrest covers to access storage compartments for your tray table or other small items.

- **360° Swivel Tray Table:** The included tray table can be inserted into the accessory grommet and swivels for convenience. It can be stored in the armrest when not in use.
- **Ambient Base Lights:** Activate the ambient LED lights located beneath the chair with a button on the remote or near the cupholder.



Image: The Seatcraft Virtuoso recliner shown in its upright position, ready for use.

Comfort View™
TOTAL CONTROL MASSAGE REMOTE

AIR MASSAGE SYSTEM

- DEEP HEAT RELIEF
- POWERED HEADREST
- POWERED LUMBAR
- POWERED RECLINE




Image: The Seatcraft Virtuoso recliner fully extended in a reclined position.



Image: A close-up of the lighted cupholder and integrated USB charging port on the Seatcraft Virtuoso.

Maintenance and Care

Proper care will extend the life and appearance of your Seatcraft Virtuoso recliner.

Leather Care:

- **Regular Cleaning:** Dust the leather regularly with a soft, dry cloth.
- **Spills:** Blot spills immediately with a clean, absorbent cloth. Do not rub. For stubborn stains, use a mild leather cleaner specifically designed for Italian leather, following the product instructions. Test on an inconspicuous area first.
- **Avoid Direct Sunlight:** Prolonged exposure to direct sunlight can cause fading and drying of the leather.
- **Avoid Harsh Chemicals:** Do not use abrasive cleaners, solvents, or household detergents, as these can damage the leather finish.

General Maintenance:

- **Mechanism Check:** Periodically check all moving parts and connections to ensure they are secure. Do not attempt to lubricate the recline mechanism yourself; contact customer support if it becomes stiff or noisy.
- **Power Cord:** Inspect the power cord regularly for any damage. If damaged, discontinue use and contact customer support for replacement.

Troubleshooting

If you encounter issues with your Seatcraft Virtuoso recliner, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Chair does not recline or power functions are unresponsive.	Power cord disconnected; outlet not working; internal wiring issue.	Ensure power cord is securely plugged into both the chair and a working wall outlet. Check circuit breaker. Verify all internal connections are secure.
Heat or massage functions are not working.	Function not activated; internal wiring issue.	Ensure the 'Heat' or 'PWR' button on the remote is pressed. For massage, ensure at least one zone is selected. Check power connections.
Headrest or lumbar adjustment is not working.	Function not activated; internal wiring issue.	Ensure the correct buttons on the remote are being used. Check power connections.
Chair makes unusual noises during operation.	Loose components; mechanism friction.	Check for any loose bolts or connections. Do not attempt to lubricate the mechanism. Contact customer support.
USB port not charging devices.	Chair not powered; device cable faulty; device incompatible.	Ensure the chair is powered on. Try a different USB cable or device.

If the problem persists after attempting these solutions, please contact Seatcraft customer support for further assistance.

Specifications

Detailed specifications for the Seatcraft Virtuoso Home Theater Seating:

Feature	Detail
Model Name	Virtuoso

Feature	Detail
Model Number	88-3610
UPC	819262015734
Color	Brown
Material	Italian Leather (Top Grain)
Product Dimensions (D x W x H)	38"D x 83"W x 44"H (Note: This dimension appears to be for a larger configuration, for a single recliner, refer to the diagram below.)
Seat Height	43 Inches
Seat Depth	38 inches
Maximum Weight Recommendation	350 Pounds (158 kg)
Frame Material	Engineered Wood
Fill Material	Foam (2.2 High Resilience Foam with Cool Gel)
Assembly Required	Yes
Number of Cupholders	2 (for single recliner)
Features	Powered Headrest, Powered Lumbar, Heat & Massage, Power Recline, Lighted Cupholders, USB Charging, Hidden In-Arm Storage, Ambient Base Lights, 360° Swivel Tray Table



Image: A diagram showing the dimensions and configurations for the Seatcraft Virtuoso single recliner, including upright, TV position, and full recline measurements, and wall clearance needed.

Warranty and Support

Seatcraft is committed to providing quality products. For specific warranty details regarding your Virtuoso Home Theater Seating, please refer to the warranty card included with your purchase or visit the official Seatcraft website.
For technical support, troubleshooting assistance beyond what is listed in this manual, or to inquire about replacement parts, please contact Seatcraft Customer Service:

- **Online:** Visit the Seatcraft official website for support resources and contact forms.
- **Phone:** Refer to your product documentation for the customer service phone number.

When contacting support, please have your model number (Virtuoso 88-3610) and purchase information readily available.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0BBSLC5ZC

More documents and user manuals: **https://manuals.plus/**