

Ninja CFP307

Ninja DualBrew Pro Specialty Coffee System

MODEL: CFP307 USER MANUAL

Introduction

This manual provides essential information for the safe and efficient operation, maintenance, and troubleshooting of your Ninja DualBrew Pro Specialty Coffee System. Please read all instructions carefully before first use and retain this manual for future reference.

What's Included

Your Ninja DualBrew Pro Specialty Coffee System (CFP307) includes the following components:

- Ninja DualBrew Pro Specialty Coffee Maker
- 12-Cup Glass Carafe
- Ninja Smart Scoop
- Fold-away Frother
- K-Cup Pod Adapter
- Permanent Filter



Figure 1: Ninja DualBrew Pro Specialty Coffee System with its components and examples of beverages it can create.

Setup

1. **Unpack:** Carefully remove all components from the packaging.
2. **Clean:** Wash the carafe, permanent filter, K-Cup pod adapter, and frother whisk in warm, soapy water. Rinse thoroughly and air dry. Wipe the exterior of the coffee maker with a clean, damp cloth.
3. **Position Water Reservoir:** The 60-oz water reservoir can be positioned on either the side or the back of the machine to fit your counter space. Ensure it is securely attached.
4. **Initial Clean Cycle:** Before first use, perform a clean cycle with water only. Fill the water reservoir to the FULL line, place the carafe on the warming plate, and select the 'CLEAN' function. Follow the on-screen prompts.



Figure 2: The water reservoir can be positioned on the side or back of the coffee maker for flexible placement.

Operating Instructions

Your Ninja DualBrew Pro offers versatile brewing options for both ground coffee and K-Cup pods, along with an independent hot water system and frother.

Brewing with Ground Coffee

1. **Insert Permanent Filter:** Ensure the permanent filter is securely placed in the brew basket.
2. **Add Ground Coffee:** Use the Ninja Smart Scoop to add your desired amount of ground coffee to the permanent filter. Refer to the scoop markings for recommended amounts based on brew size.
3. **Select Brew Size:** Use the dial on the control panel to select your desired brew size (Small Cup, XL Cup, Travel, XL Travel Mug, ¼ Carafe, ½ Carafe, ¾ Carafe, Full Carafe).
4. **Select Brew Style:** Choose from Classic, Rich, Over Ice, or Specialty using the 'BREW STYLE' button.
5. **Start Brewing:** Place your mug or carafe under the dispenser and press the 'START BREW' button.



Figure 3: The coffee maker offers Classic, Rich, Over Ice, and Specialty brew styles.

Brewing with K-Cup Pods

1. **Insert Pod Adapter:** Slide the brew basket cover back and insert the K-Cup pod adapter.
2. **Insert K-Cup Pod:** Place a K-Cup pod into the adapter.
3. **Select Brew Size:** Use the dial to select a pod brew size (6, 8, 10, or 12 ounces).
4. **Select Brew Style:** Choose from Classic, Rich, Over Ice, or Specialty.
5. **Start Brewing:** Place your mug under the dispenser and press the 'START BREW' button.



Figure 4: The K-Cup pod adapter allows for convenient single-serve brewing.

Using the Independent Hot Water System

1. **Rotate Dial:** Rotate the dial on the side of the machine to the water droplet icon.
2. **Select Water Temperature:** Choose between 'boil' or 'hot' temperature settings.
3. **Select Water Volume:** Use the dial to select the desired water volume.
4. **Start Dispensing:** Place your mug or bowl under the hot water dispenser and press the 'START BREW' button.



Figure 5: The independent hot water system provides hot or boiling water for various uses without coffee contamination.

Using the Built-in Frother

1. **Extend Frother Arm:** Pull the frother arm out from the side of the machine.
2. **Add Milk:** Pour cold or hot milk (or milk alternative) into a mug.
3. **Froth:** Submerge the frother whisk into the milk and press the button on top of the frother arm to activate. Froth until desired consistency is achieved.
4. **Clean:** After use, remove the frother whisk for easy cleaning.



Figure 6: The integrated frother creates silky-smooth foam for specialty beverages.

Maintenance and Cleaning

Regular cleaning ensures optimal performance and longevity of your coffee maker.

- **Daily Cleaning:** Wash the carafe, permanent filter, K-Cup pod adapter, and frother whisk after each use. These parts are dishwasher-safe.
- **Exterior Cleaning:** Wipe down the exterior of the machine with a damp cloth.
- **Descaling:** The 'CLEAN' light will illuminate when descaling is required. Follow the descaling instructions in the full product manual or on the Ninja website.

Troubleshooting

- **Coffee Not Brewing:** Ensure the water reservoir is filled, the brew basket is correctly inserted, and the carafe/mug is in place. Check if the 'OPEN' indicator is lit, and if so, close the drip stop.
- **Weak Coffee:** Increase the amount of ground coffee used or select the 'Rich' brew style. Ensure the permanent filter is clean.
- **Frother Not Working:** Ensure the frother whisk is clean and properly attached. Check that the frother arm is fully extended.
- **'CLEAN' Light On:** This indicates the machine needs descaling. Follow the descaling procedure.

Specifications

Brand	Ninja
Model Name	Ninja CFP307
Product Dimensions	11.39"D x 9.12"W x 15.54"H
Item Weight	9.69 pounds
Color	Black
Voltage	120V
Coffee Input Type	Grounds and Pods
Filter Type	Reusable
Special Features	Dishwasher-safe parts, Delay Brew, Milk Frother, Keep Warm function

Warranty and Support

For warranty information and customer support, please refer to the documentation included with your product packaging or visit the official Ninja website. Extended protection plans may also be available for purchase.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0BBSN3NXD>

More documents and user manuals: **<https://manuals.plus/>**