

[manuals.plus](#) /› [vidaXL](#) /› [vidaXL 4-Tier Telescopic Shower Corner Shelf \(Model 344382\) Instruction Manual](#)**vidaXL 344382**

# vidaXL 4-Tier Telescopic Shower Corner Shelf Instruction Manual

Model: 344382

## 1. INTRODUCTION

Thank you for purchasing the vidaXL 4-Tier Telescopic Shower Corner Shelf. This manual provides essential information for the safe assembly, installation, operation, and maintenance of your new shower shelf. Please read these instructions carefully before use and retain them for future reference.

## 2. SAFETY INSTRUCTIONS

- Ensure all components are present and undamaged before assembly. Do not use if any parts are missing or broken.
- Install the shelf in a stable corner of your shower or bathroom. The telescopic pole relies on tension for stability.
- Do not overload the shelves. Each shelf is designed to hold standard bathroom items like shampoo bottles and soap. Excessive weight may compromise stability.
- Keep small parts away from children during assembly to prevent choking hazards.
- Regularly check the tension of the pole and the stability of the shelves to ensure safe operation.
- Clean the product with mild soap and water. Avoid abrasive cleaners that may damage the finish.

## 3. PACKAGE CONTENTS

Before beginning assembly, verify that all the following components are included in your package:

- Telescopic pole sections (upper and lower)
- 4 x Storage trays with drainage slits
- Adjustable rings/collars for trays
- Top spring-loaded tension mechanism

- Bottom foot/base



Image: All components of the vidaXL 4-Tier Telescopic Shower Corner Shelf, including the telescopic pole, four grey storage trays, and adjustment mechanisms.

## 4. SETUP AND INSTALLATION

---

Follow these steps to assemble and install your shower corner shelf:

1. **Assemble the Telescopic Pole:** Connect the upper and lower sections of the telescopic pole. Ensure they are securely fitted together.

2. **Position the Pole:** Place the assembled pole in the desired corner of your shower or bathroom. Extend the pole until the top spring-loaded mechanism makes firm contact with the ceiling and the bottom foot rests securely on the floor.
3. **Adjust Pole Tension:** Rotate the upper section of the pole or the tensioning knob (if present) to create sufficient tension between the floor and ceiling. The pole should be held firmly in place without wobbling.



Image: Detail of the top section of the telescopic pole, showing the spring-loaded mechanism and adjustment knob for securing the pole between the floor and ceiling.

4. **Attach Storage Trays:** Slide the adjustable rings/collars onto the pole at your desired heights. Place a storage tray onto each ring, ensuring it sits securely. The trays can be rotated for optimal

positioning.



Image: The shower shelf with four trays, illustrating how the trays can be moved up or down the pole to customize storage height.

5. **Final Check:** Gently push and pull the installed shelf to confirm its stability. Readjust tension or tray positions if necessary.



Image: The vidaXL 4-Tier Telescopic Shower Corner Shelf fully installed in a shower corner, holding various bathroom products.

## 5. USAGE

The vidaXL 4-Tier Telescopic Shower Corner Shelf is designed for convenient storage of bathroom essentials. Place items such as shampoo, conditioner, body wash, soap, and sponges on the four adjustable trays. The trays feature drainage slits to prevent water accumulation.

To adjust the height of a tray, simply lift the tray slightly, slide its supporting ring up or down the pole to the desired position, and then lower the tray back onto the ring until it is secure.

## 6. MAINTENANCE AND CARE

- **Cleaning:** Wipe the aluminum pole and plastic trays regularly with a soft cloth dampened with mild soap and water. Rinse thoroughly and dry to prevent water spots and soap scum buildup.
- **Avoid Harsh Chemicals:** Do not use abrasive cleaners, scouring pads, or strong chemical detergents, as these can damage the finish of the aluminum and plastic components.
- **Check Stability:** Periodically check the tension of the telescopic pole to ensure it remains firmly secured between the floor and ceiling. Retighten if any looseness is detected.
- **Drainage:** Ensure the drainage slits on the trays remain clear of debris to allow proper water runoff.

## 7. TROUBLESHOOTING

Problem	Possible Cause	Solution
Shelf is wobbly or unstable.	Insufficient tension in the telescopic pole.	Increase the tension by rotating the pole or adjustment knob until it is firmly secured between the floor and ceiling.
Trays slide down the pole.	Tray not properly seated on the adjustable ring, or ring is loose.	Ensure the tray is fully engaged with its supporting ring. Check if the ring is tightened sufficiently around the pole.
Water accumulates on trays.	Drainage slits are blocked.	Clear any debris or soap residue from the drainage slits on the trays.

## 8. SPECIFICATIONS

Feature	Detail
<b>Model Number</b>	344382
<b>Material</b>	Aluminium (pole), PS (polystyrene), PA (polyamide), TPE (Thermoplastic elastomers) (trays and fittings)
<b>Color</b>	Silver (pole), Grey (trays)
<b>Dimensions (W x D x H)</b>	19 x 19 x (235-280) cm (7.48"D x 7.48"W x 92.52"-110.2"H)
<b>Adjustability</b>	Height adjustable (235-280 cm), Tray positions adjustable
<b>Number of Tiers</b>	4
<b>Special Features</b>	Drainage holes in trays, Freestanding (tension-mounted)
<b>Item Weight</b>	1.1 Kilograms (approx. 2.42 pounds)




Image: Dimensional diagram indicating the adjustable height range of 235-280 cm (92.5-110.2 inches) and tray width of 19 cm (7.5 inches).

## 9. WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the documentation provided with your purchase or contact vidaXL customer service directly. Keep your proof of purchase for any warranty claims.

**Contact Information:** Please visit the official vidaXL website for the most up-to-date contact details for your region.

