

[Manuals.plus](#) /

> [QearFun](#) /

> QearFun Kids Bluetooth Headphones Model QF3DCHPPu User Manual

QearFun QF3DCHPPu

QearFun Kids Bluetooth Headphones Model QF3DCHPPu User Manual

Model: QF3DCHPPu

1. INTRODUCTION

Thank you for choosing the QearFun Kids Bluetooth Headphones. This manual provides essential information for the safe and effective use of your headphones. Please read it thoroughly before use and retain it for future reference.

2. SAFETY INFORMATION

- **Volume Control:** These headphones feature volume limiting options (50dB/85dB/100dB) to protect children's hearing. Ensure the appropriate volume limit is selected. Prolonged exposure to high volumes can cause hearing damage.
- **Supervision:** Adult supervision is recommended for young children using these headphones.
- **Cleaning:** Clean the headphones with a soft, dry cloth. Do not use liquid cleaners or immerse in water.
- **Battery Safety:** The headphones contain a Lithium Ion battery. Do not attempt to replace the battery. Do not expose to extreme temperatures or dispose of in fire.
- **Choking Hazard:** Keep small parts away from young children.

3. PACKAGE CONTENTS

Verify that all items are present in the package:

- QearFun Kids Bluetooth Headphones (Model QF3DCHPPu)
- USB Charging Cable
- 3.5mm Audio Cable
- User Manual (This document)

PERFECT GIFT



Image 3.1: Contents of the QearFun Kids Bluetooth Headphones package, including the headphones, charging cable, audio cable, and user manual, presented in a gift box.

4. PRODUCT OVERVIEW

Familiarize yourself with the various parts of your headphones.



Image 4.1: Front view of the QearFun Kids Bluetooth Headphones, showcasing the purple and green color scheme and the cat design on the earcups.

4.1 Key Features

- **Bluetooth 5.0:** For stable wireless connectivity.
- **7-Color LED Lights:** Integrated lights on the earcups.
- **Built-in Microphone:** For calls and online learning.
- **Volume Limiting:** Adjustable safety volume levels (50dB/85dB/100dB).
- **Foldable Design:** For easy storage and portability.
- **Wired/Wireless Modes:** Can be used via Bluetooth or 3.5mm audio cable.



Image 4.2: The headphones displaying their cool RGB lighting feature, with a visual guide to different light modes.



Image 4.3: Illustration of the headphones' two-way folding design, demonstrating their compact storage capability.

5. SETUP

5.1 Charging the Headphones

Before first use, fully charge the headphones.

1. Connect the small end of the USB charging cable to the charging port on the headphones.
2. Connect the large end of the USB charging cable to a USB power adapter (not included) or a computer's USB port.
3. The LED indicator light will show charging status (e.g., red for charging, off or blue for fully charged).
4. A full charge typically takes approximately 2 hours.

5.2 Power On/Off

- **To Power On:** Press and hold the Power button for approximately 3 seconds until the LED indicator lights up.

- **To Power Off:** Press and hold the Power button for approximately 3-5 seconds until the LED indicator turns off.

5.3 Bluetooth Pairing

To connect the headphones wirelessly to a device:

1. Ensure the headphones are powered off.
2. Press and hold the Power button for approximately 5-7 seconds until the LED indicator flashes blue and red alternately, indicating pairing mode.
3. On your device (smartphone, tablet, computer), enable Bluetooth and search for available devices.
4. Select "QearFun Headphones" (or similar name) from the list of found devices.
5. Once connected, the LED indicator on the headphones will typically show a solid blue light or flash blue slowly.
6. The headphones will automatically attempt to reconnect to the last paired device when powered on.

6. OPERATING INSTRUCTIONS

6.1 Wired Mode (3.5mm Audio Cable)

The headphones can be used in wired mode even if the battery is depleted.

1. Connect one end of the 3.5mm audio cable to the audio input jack on the headphones.
2. Connect the other end of the 3.5mm audio cable to the audio output jack of your device.
3. In wired mode, Bluetooth functionality and LED lights may be disabled to conserve battery.



Image 6.1: The headphones demonstrating both wireless (Bluetooth) and wired (3.5mm audio cable) connectivity options.

6.2 Volume Control

Use the volume buttons on the headphones or your connected device to adjust the sound level.

- **Volume Up:** Press the "+" button.
- **Volume Down:** Press the "-" button.
- **Volume Limiting:** The headphones offer 50dB, 85dB, and 100dB volume limits. Refer to the specific product documentation or device settings for how to switch between these modes, if applicable.

6.3 LED Lights Operation

The headphones feature multi-color LED lights.

- **To Turn On/Off Lights:** Locate the dedicated light control button (if present) or refer to the specific button functions in your product's quick start guide. Often, a short press of a specific button controls the lights.

- **To Change Light Mode:** Repeatedly press the light control button to cycle through different light patterns or colors.

6.4 Using the Microphone

The built-in microphone allows for hands-free calls and voice communication.

- Ensure the headphones are connected via Bluetooth to a device that supports microphone input.
- During a call or voice chat, the microphone will automatically activate.
- For optimal clarity, ensure the microphone is not obstructed.

7. MAINTENANCE

- **Cleaning:** Wipe the headphones with a soft, dry, lint-free cloth. Do not use abrasive cleaners, alcohol, or solvents.
- **Storage:** When not in use, store the headphones in a cool, dry place, away from direct sunlight and extreme temperatures. The foldable design allows for compact storage.
- **Battery Care:** To prolong battery life, avoid fully discharging the headphones frequently. Charge them regularly, even if not in constant use.
- **Cable Care:** Handle the charging and audio cables gently. Avoid sharp bends or excessive pulling to prevent damage.

8. TROUBLESHOOTING

Problem	Possible Cause	Solution
Headphones do not power on.	Low battery.	Charge the headphones for at least 30 minutes.
Cannot pair via Bluetooth.	Headphones not in pairing mode; Bluetooth disabled on device; device too far.	Ensure headphones are in pairing mode (flashing red/blue). Enable Bluetooth on your device. Move device closer to headphones (within 10 meters). Forget previous pairings on your device and try again.
No sound in wireless mode.	Volume too low; headphones not connected; incorrect audio output selected on device.	Increase volume on headphones and device. Re-pair headphones. Check device's audio output settings.
No sound in wired mode.	3.5mm cable not fully inserted; cable damaged; incorrect audio output selected on device.	Ensure 3.5mm cable is fully inserted into both headphone and device jacks. Try a different 3.5mm cable. Check device's audio output settings.
LED lights not working.	Lights turned off; low battery.	Press the light control button to activate. Charge the headphones.
Microphone not working.	Not connected via Bluetooth; microphone muted on device; application settings.	Ensure Bluetooth connection is active. Check device and application microphone settings.

9. SPECIFICATIONS

Model Name	QF3DCHPPu
Connectivity Technology	Wireless (Bluetooth 5.0), Wired (3.5 mm Jack)
Bluetooth Range	Up to 15 meters
Battery Life	Up to 20 hours
Charging Time	Approximately 2 hours
Headphones Jack	3.5 mm Jack
Material	Faux Leather
Item Weight	15.8 ounces (449 Grams)
Product Dimensions	7.48 x 6.69 x 3.54 inches
Age Range (Description)	Over 3 years old
Manufacturer	QearFun

10. WARRANTY INFORMATION

QearFun products are typically covered by a limited warranty against defects in materials and workmanship. Please refer to the warranty card included with your product or visit the official QearFun website for detailed warranty terms and conditions. Retain your proof of purchase for warranty claims.

11. SUPPORT

For technical assistance, troubleshooting beyond this manual, or customer service inquiries, please contact QearFun customer support through their official website or the retailer where the product was purchased.

Online Support: [Visit the QearFun Store on Amazon](#)

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0BBTZB7Y8>

More documents and user manuals: <https://manuals.plus/>