**GLAKER HC2022**

# GLAKER HC2022 Hair Clipper Instruction Manual

Model: HC2022 | Brand: GLAKER

## Introduction

Thank you for choosing the GLAKER HC2022 Hair Clipper. This cordless 2-in-1 versatile hair trimmer is engineered for precision and ease of use, offering a professional-grade haircutting experience in the comfort of your home. With its powerful motor, ceramic blade, and comprehensive accessory kit, achieving your desired look has never been simpler.




*GLAKER HC2022 Hair Clipper with all included accessories: clipper, various guide combs, charging cable, cleaning brush, oil, and barber cape.*

## Safety Information

To reduce the risk of burns, fire, electric shock or injury to persons: This appliance is for household use only. An appliance should never be left unattended when it's plugged in, except when it is rechargeable appliance and is being charged. Close supervision is necessary when this appliance is used by, on, or near children or persons with reduced abilities. Use this appliance only for its intended use as described in this manual. Do not use attachments not recommended by the manufacturer. Keep the cord away from heated surfaces. Never operate this appliance if it has a damaged cord or plug, if it is not working properly, if it has been dropped or damaged, or if it has been dropped into water. If any of these things happen, return the appliance to an authorized service center for examination and repair. Never drop or insert any object into any of the appliance's openings. Do not use it outdoors or operate where aerosol (spray) products are being used, or where oxygen is being administered. Make sure the cord is disconnected from the clipper while storing them and make sure they are stored in a moisture-free area. Do not store them in temperatures exceeding 140°F (60°C). Do not use this appliance with a damaged or broken cutter unit, as injuries may occur. Always make sure the blades are aligned properly.

## What's Included

Your GLAKER HC2022 Hair Clipper kit includes the following items:

- GLAKER HC2022 Clipper (with Ceramic blade)
- 8 ABS Guide Combs (various lengths for versatile styling)
- Barber Cape
- Blade Cleansing Brush
- Comb
- Blade Oil
- Type-C Charging Cable
- Additional Interchangeable Head (U-shaped for specific detailing)




*The kit includes various guide combs and an adjustable blade for multiple hair lengths.*

# Setup

## Initial Charging

Before first use, fully charge your GLAKER HC2022 Hair Clipper. Connect the provided Type-C charging cable to the clipper and a compatible USB power source. The LED indicators on the clipper will show the charging progress. A full charge provides up to 300 minutes of run time.




*The clipper features convenient Type-C charging and clear battery indicators.*

## Attaching Guide Combs

Select the desired guide comb based on the hair length you wish to achieve. Align the comb with the clipper blade and firmly push it until it clicks into place. Ensure it is securely attached before use.

## Changing Clipper Heads

The GLAKER HC2022 comes with interchangeable heads for different grooming needs. To remove a head, gently pull it away from the clipper body. To attach a new head, align it with the slot and push until it snaps securely into place.



*The clipper head can be easily removed for cleaning or to switch to a different head type.*

# Operating Instructions

## Powering On/Off and Speed Settings

Press the power button to turn the clipper on. The clipper features two speed settings: 6000 RPM for normal and curly hair, and 7000 RPM (Turbo+ mode) for coarse or thick hair. Toggle between speeds by pressing the power button again.




*The clipper offers two speed settings for different hair types.*

## Adjusting Blade Length

The built-in precision dial allows for 5 adjustable lengths from 0.5mm to 2.5mm. Rotate the dial to select your desired cutting length. This feature is ideal for fading and blending.




*Adjust the blade length with the precision dial for detailed cuts.*

## Haircutting Techniques

For best results, ensure hair is clean and dry. Use the comb to detangle hair before cutting. Start with a longer guide comb and gradually move to shorter lengths if desired. For fading, use progressively shorter combs from the bottom up. For blending, ensure smooth transitions between different lengths.




*The GLAKER HC2022 is suitable for various haircutting needs for the entire family.*

# Maintenance

## Cleaning the Blades

After each use, turn off the clipper and remove the guide comb. Detach the clipper head by gently pulling it off. Use the provided cleaning brush to remove any loose hair from the blades and the clipper body. The blades are washable; you can rinse them under running water. Ensure the blades are completely dry before reattaching or storing.




*The clipper head is designed for easy removal and cleaning.*

### Oiling the Blades

Regular oiling is crucial for maintaining blade sharpness and longevity. After cleaning and drying the blades, apply a few drops of the included blade oil onto the teeth of the blades. Turn the clipper on for a few seconds to distribute the oil evenly. Wipe off any excess oil.

### Storage

Store the clipper and all accessories in a dry, moisture-free area. Avoid storing in extreme temperatures.

## Troubleshooting

If your GLAKER HC2022 Hair Clipper is not performing optimally, consider the following:

- **Clipper not turning on:** Ensure the clipper is fully charged.
- **Blades pulling hair or not cutting effectively:**Check if the blades are clean and free of hair debris. Apply blade oil as per maintenance instructions. Ensure the correct guide comb is securely attached.

- **Reduced battery life:** Ensure the clipper is charged for the recommended duration. Battery performance may decrease over time with prolonged use.

For persistent issues, please refer to the full user manual or contact GLAKER customer support.

## Specifications

| Feature | Detail |
|---|---|
| Product Dimensions | 1.8 x 2 x 6.6 inches |
| Item Weight | 5.76 ounces |
| Model Number | HC2022 |
| Battery Type | 1 Lithium Ion battery required |
| Runtime | 5 hours (300 minutes) |
| Manufacturer | GLAKER |
| Country of Origin | China |

## Warranty & Support

GLAKER is committed to quality and service. Your GLAKER HC2022 Hair Clipper comes with a**1-YEAR WARRANTY**. For detailed warranty information, troubleshooting, or further assistance, please refer to the official user manual PDF or contact GLAKER customer support.
Official User Manual (PDF): Download Here

© 2023 GLAKER. All rights reserved.